HCD-C5

SERVICE MANUAL

Ver 1.1 2001.09





AEP Model **UK Model** E Model Australian Model

HCD-C5 is the Amplifier, CD player, MD Deck and Tuner section in CMT-C5.

	Model Name Using Similar Mechanism	New
CD	CD Mechanism Type	TN-CCD1001Z
Section	Base Unit Name	TT BASE ASSY
	Optical Pick-up Name	OPTIMA-720L1E
MD	Model Name Using Similar Mechanism	New
Section	MD Mechanism Type	MDM-7B4M
	Optical Pick-up Name	KMS-260E/Z-NP

Power requirements European model: Australian model:

Power consumption

Dimensions (w/h/d)

Supplied accessories

European model:

Other models:

Other models:

SPECIFICATIONS

Amplifier section

European model:
DIN power output (rated): 15 + 15 W
(6 ohms at 1 kHz, DIN)
(6 ohms at 1 kHz, DIN) Continuous RMS power output (reference): 20 + 20 W

(6 ohms at 1 kHz, 10% THD)

Music power output (reference): 45 + 45 W

Australian model:

Australian model:
The following measured at 230 V AC, 60 Hz
DIN power output (rated): 15 + 15 W
(6 ohms at 1 kHz, DIN)
Continuous RMS power output (reference):
20 + 20 W
(6 ohms at 1 kHz, 10%
THD)

Other models:

Other models:
The following measured at 220 V AC, 60 Hz
DIN power output (rated): 15 + 15 W
(6 ohms at 1 kHz, DIN)
Continuous RMS power output (reference):
20 + 20 W
(6 ohms at 1 kHz, 10%
THD)

Inputs
TAPE IN (stereo minijack):
Sensitivity 250 mV,
impedance 47 kilohms

DIGITAL OPTICAL IN (Supported sampling frequencies: 32 kHz, 44.1 kHz and 48 kHz)

Outputs

TAPE OUT (stereo minijack):

Sensitivity 250 mV, impedance 1 kilohmes

PHONES (stereo minijack):

Accepts headphones with an impedance of 8 ohms or more

CD player section

Compact disc and digital audio system Semiconductor laser $(\lambda = 780 \text{ nm})$

Emission duration: 2 Hz – 20 kHz

Frequency response

MD deck section System MiniDisc digital audio

system Semiconductor laser (λ=780 nm) Emission duration:

Sampling frequency 44.1 kHz 5 Hz – 20 kHz Frequency response

Tuner section

FM stereo, FM/AM superheterodyne tuner

FM tuner section

Tuning range 87 5 - 108 0 MHz (50-kHz step) FM wire antenna 75 ohm unbalanc 10.7 MHz Antenna Antenna terminals Intermediate frequency

Intermediate frequency

Tuning range European model:

531 - 1.602 kHz (with the tuning interval set at 9 kHz) 530 – 1,710 kHz (with the tuning interval

set at 10 kHz) 531 – 1.602 kHz (with the tuning interval

at 9 kHz)

Design and specifications are subject to change

230 V AC, 50/60 Hz 230 V AC, 50/60 Hz 220 V AC, 50/60 Hz

See the nameplate 0.5 W (at the power saving mode) See the nameplate

Approx. $145 \times 125 \times 273$ mm incl. projecting parts and controls

Remote commander (1)

AM loop antenna (1) FM wire antenna (1)

MICRO HI-FI COMPONENT SYSTEM

9-873-244-02 200111600-1

Sony Corporation Home Audio Company

© 2001.9 **Shinagawa Tec Service Manual Production Group** SONY

SELF-DIAGNOSIS FUNCTION

The self-diagnosis function consists of error codes for customers, which are displayed automatically when errors occur, and error codes, which show the error history in the test mode during servicing. For details on how to view error codes for the customer, refer to the following box in the instruction manual. For details on how to check error codes during servicing, refer to the following "Procedure for using the Self-Diagnosis Function (Error History Display Mode)".

Self-diagnosis display

This system has a Self-diagnosis display function to let you know if there is a system malfunction. The display shows a code made up of 3 or 5 letters and a message alternately to show you the problem. To solve the problem refer to the following list. If any problem persists, consult your nearest Sony dealer.



C11/Protected

The MD is protected against erasure.

→ Remove the MD and slide the tab to close the slot (see page 18).

C12/Cannot Copy

You tried to record a CD or MD with a format that the system does not support, such as a CD-ROM.

→Remove the disc and turn off the system once, then turn it on again.

C13/REC Error

Recording could not be performed properly.

→Move the system to a stable place, and start recording over from the beginning.

The MD is dirty or scratched, or the MD does not meet the standards.

→Replace the MD and start recording over from the beginning.

C13/Read Error

The MD deck cannot read the disc information properly.

→Remove the MD once, then load it again.

C14/Toc Error

The MD deck cannot read the disc information properly.

→Replace the MD.

Erase all the recorded contents of the MD using All Erase Function (see page 29).

C41/Cannot Copy

The sound source is a copy of a commercially available music software, or you tried to record a CD-R (Recordable CD).

→The Serial Copy Management System prevents making a digital copy (see page 48). You cannot record a CD-R.

C71/Check OPT-IN

This appears momentarily because of the signal of the digital broadcast during recording.

→There is no affect on the recorded contents. No component is connected to the DIGITAL OPTICAL IN jack, or a digital component is not connected properly.

→ Connect a digital component to the DIGITAL OPTICAL IN jack properly using a digital connecting cable (not supplied, see page 43).

The connected digital component is not turned on.

→ See the operating instructions supplied with the connected component and confirm whether the component is turned on.

The digital connecting cable connected to the DIGITAL OPTICAL IN jack is pulled out, or the connected digital component is turned off during digital recording.

→Connect the cable, or turn on the digital component.

E0001/MEMORY NG

There is an error in the internal data that the system needs in order to operate.

→Consult your nearest Sony dealer.

E0101/LASER NG

There is a problem with the optical pickup.

→The optical pickup may have failed. Consult your nearest Sony dealer.

TABLE OF CONTENTS

SEL	F-DIAGNOSIS FUNCTION	2
1.	SERVICING NOTES	4
2.	GENERAL	7
3.	DISASSEMBLY	9
4.	TEST MODE	24
5.	ELECTRICAL ADJUSTMENTS CD Section	
6. 6-1.	DIAGRAMS NOTE FOR PRINTED WIRING BOARDS AND SCHEMATIC DIAGRAMS	45
6-2. 6-3. 6-4.	Block Diagram – CD Servo Section –	46 47
6-5. 6-6. 6-7. 6-8.	Printed Wiring Boards – CD Section –	50 51
6-9. 6-10.	Schematic Diagram – BD (MD) Board (1/2) –	53 54
6-12. 6-13. 6-14.	Printed Wiring Board – UCOM Board –	56 57 58
6-16. 6-17.	Schematic Diagram – AUDIO Section –	60 61
6-19. 6-20.	Printed Wiring Boards – POWER Section –	63 64
7.	EXPLODED VIEWS	76
8.	ELECTRICAL PARTS LIST	86

SECTION 1 SERVICING NOTE

NOTES ON HANDLING THE OPTICAL PICK-UP BLOCK OR BASE UNIT

The laser diode in the optical pick-up block may suffer electrostatic break-down because of the potential difference generated by the charged electrostatic load, etc. on clothing and the human body. During repair, pay attention to electrostatic break-down and also use the procedure in the printed matter which is included in the repair parts.

The flexible board is easily damaged and should be handled with care.

FOR CD

NOTES ON LASER DIODE EMISSION CHECK

The laser beam on this model is concentrated so as to be focused on the disc reflective surface by the objective lens in the optical pick-up block. Therefore, when checking the laser diode emission, observe from more than 30 cm away from the objective lens.

FOR MD

NOTES ON LASER DIODE EMISSION CHECK

Never look into the laser diode emission from right above when checking it for adjustment. It is feared that you will lose your sight.

Laser component in this product is capable of emitting radiation exceeding the limit for Class 1.

CLASS 1 LASER PRODUCT LUOKAN 1 LASERLAITE KLASS 1 LASERAPPARAT

This appliance is classified as a CLASS 1 LASER product. The CLASS 1 LASER PRODUCT MARKING is located on the bottom exterior.

CAUTION: INVISIBLE LASER RADIATION WHEN OPEN AND INTERLOCKS DEFEATED. AVOID EXPOSURE TO BEAM.

ADVARSEL: USYNLIG LASERSTRÄLING VED ÄBNING NÄR SIKKERHEDSAFBRYDERE ER UDE AF FUNKTION. UNDGÅ UDSAETTELSE FOR STRÄLING.

VORSICHT: UNSICHTBARE LASERSTRÄHLUNG, WENN ABDECKUNG GEÖFFNET UND SICHEREITSVERRIEGELUNG ÜBERBRÜCKT. NICHT DEM STRÄHL AUSSETZEN.

VAROJ: AVATAESSA JA SUOJALUKITUS OHTETTAESSA OLET ALTTINA NÄKYMÄTTÖMÄLLE LÄSERSÄTELYLLE, ÄLÄ KATSO SÄTEESEEN.

VARNING: OSYNLING LASERSTRÄLING NÄR DENNA DEL ÄR ÖPPNAD OCH SPÄRREN ÄR URKOPPLAD, BETRAKTALEN.

ADVERSEL: USYNLIG LASERSTRÄLING NÄR DEKSEL ÄPNES OG SIKKERHEDSLÅS BRYTES. UNNGÅ EKSPONERING FOR STRÅLEN.

VIGYAZATJ: A BURKOLAT NYITÄSAKOR LÄTHATATLAN LÉZERSUGÄRVESZĖLY! KERÜLJE A BESUGÄRZÄST!

This caution label is located inside the unit.

CAUTION

Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

Notes on chip component replacement

- Never reuse a disconnected chip component.
- Notice that the minus side of a tantalum capacitor may be damaged by heat.


Flexible Circuit Board Repairing

- Keep the temperature of soldering iron around 270°C during repairing.
- Do not touch the soldering iron on the same conductor of the circuit board (within 3 times).
- Be careful not to apply force on the conductor when soldering or unsoldering.


SAFETY-RELATED COMPONENT WARNING!!

COMPONENTS IDENTIFIED BY MARK \triangle OR DOTTED LINE WITH MARK \triangle ON THE SCHEMATIC DIAGRAMS AND IN THE PARTS LIST ARE CRITICAL TO SAFE OPERATION. REPLACE THESE COMPONENTS WITH SONY PARTS WHOSE PART NUMBERS APPEAR AS SHOWN IN THIS MANUAL OR IN SUPPLEMENTS PUBLISHED BY SONY.

SERVICE POSITION OF THE CD MECHANISM DECK



SERVICE POSITION OF THE MD MECHANISM DECK



JIG FOR CHECKING BD (MD) BOARD WAVEFORM

The special jig (J-2501-196-A) is useful for checking the waveform of the BD (MD) board. The names of terminals and the checking items to be performed are shown as follows.

I+3V: For measuring IOP (Check the deterioration of the optical pick-up laser) IOP: For measuring IOP (Check the deterioration of the optical pick-up laser)


GND: Ground

TE : Tracking error signal (Traverse adjustment)

FE : Focus error signal

VC : Reference level for checking the signal

RF : RF signal (Check jitter)



SECTION 2 GENERAL


This section is extracted from instruction manual.



The items are arranged in alphabetical order.

Refer to the pages indicated in parentheses () for details.

Main unit



CD SYNC HIGH $\boxed{7}$ (19, 51) CD SYNC NORMAL $\boxed{8}$ (19) CD \triangleq $\boxed{2}$ (10, 51) FUNCTION $\boxed{1}$ (9, 11, 13, 14, 16, 21–37, 44) MD \triangleq $\boxed{6}$ (15, 18, 26) REC/REC IT $\boxed{8}$ (20, 21, 24, 26, 44, 51) Remote sensor $\boxed{9}$ TUNING +/- $\boxed{5}$ (36, 37) VOL +/- $\boxed{10}$ (40)

BUTTON DESCRIPTIONS

V⁽¹⁾ (power) 1 (7, 18, 26, 27, 37, 40, 42)

►II 3 (9–11, 14–16, 19, 20, 25, 44)


■ 4 (10, 11, 15, 16, 19–21, 26, 44)

■ 5 (10, 11, 13, 15, 16, 22–35)

■ ► 5 (10, 15, 30, 32)

4

Remote control



CD **■ 16** (10) CD **II 22** (10) CD **23** (9, 11, 20) CLEAR 9 (11, 16, 28, 38) CLOCK/TIMER SELECT 6 CLOCK/TIMER SET 7 (8, 40, CURSOR ←/→ **26** (8, 13, 28) DBFB 14 (39) DISPLAY **28** (8, 12, 17, 38) ENTER/YES 8 (8, 11, 13, 14, 16, 21–36, 38, 40–42) FM MODE 17 (37) FUNCTION 20 (9, 11, 13, 14, 16, 19, 21–37, 44) Letter/Number buttons 27 (10, 13, 15, 16, 27, 28, 37)

MD ■ 12 (15) MD **II 24** (15) MD **25** (14, 16, 19, 20, 25) MENU/NO 10 (13, 14, 22–26, 28 - 36NAME EDIT/SELECT 3 (13, 27, 28, 38) PLAY MODE 18 (9, 11, 14, 16, 26, 34, 35) PRESET EQ 15 (39) REPEAT 17 (10, 15) SCROLL (12, 14, 17, 28) SLEEP 1 (39) TIME 2 (8, 11, 12, 16, 17) TUNER BAND 21 (36, 37) TUNING MODE 18 (36, 37) TUNING +/- 19 (36, 37)

VOL +/- 13 (40)

BUTTON DESCRIPTIONS

I/Û (power) 4 (7, 18, 26, 27, 37, 40, 42)

I ← → → I [1] (10, 11, 13–16, 22–35, 40–42)

-/+ [1] (8, 40, 42)

← → ≥ (10, 15, 30, 32, 42)

Setting the time

- 1 Turn on the system.
- 2 Press CLOCK/TIMER SET on the remote.

If you are setting the clock for the first time, go to step 5.

- 3 Press or + (I◄◄ or ►►I) on the remote repeatedly until "CLOCK SET?" appears in the display.
- 4 Press ENTER/YES on the remote.
 The day indication flashes.
- 5 Press or + (I◄◄ or ►►I) on the remote repeatedly to set the day, and then press ENTER/YES or CURSOR→ on the remote.

The hour indication flashes.

6 Press – or + (I◄◀ or ▶►I) on the remote to set the hour, and then press ENTER/YES or CURSOR→ on the remote.

The minute indication flashes.

7 Press – or + (I◄◄ or ►►I) on the remote repeatedly to set the minute, and then press ENTER/YES on the remote.


If you made a mistake

Press ←CURSOR or CURSOR → on the remote until the indication you wish to change (day, hour, minute) flashes, and then change the setting.

To reset the time Start over from step 1.


SECTION 3 DISASSEMBLY

- This set can be disassembled in the order shown below.
- The dotted square with arrow (☐ ☐ ☐ →) prompts you to move to the next job when all of the works within the dotted square (☐ ☐ ☐) are completed.




Note: Follow the disassembly procedure in the numerical order given.


3-1. BOTTOM PLATE, CASE




3-2. PANEL BOARD




3-3. CD MECHANISM DECK (TN-CCD1001Z), BD (CD) BOARD




3-4. CONNECTOR BOARD




3-5. FRONT BRACKET SECTION, LOADING MOTOR ASSY (M902)




3-6. SW BOARD




3-7. FEED MOTOR ASSY (M903)




3-8. REAR DAMPER BRACKET




3-9. OPTICAL PICK-UP (OPTIMA-720L1E), SCREW GUIDE, FEED SCREW ASSY, etc.




3-10. OPTICAL PICK-UP (OPTIMA-720L1E)




3-11. BASE SECTION



3-12. SPINDLE MOTOR ASSY (M904)






Note for re-installation-1

When installing the rear cover, be careful that the three harnesses coming from

- "2 Connector (CN107)"
- "5 Connector (CN109)",
 "6 Connector (CN110)",
 and the harness coming from the DC fan (M901) must not contact the heat sink (IC902) and the diode (D981) and the heat sink (IC904).

POWER board

diode (D981)




Note for re-installation-2


When installing the rear cover, be careful that the three harnesses coming from
"2 Connector (CN107)",
"5 Connector (CN109)",
"6 Connector (CN110)",

and the harness coming from the D.C. fan (M901) must not be pinched by the rear cover, the UCOM board, power transformer (T900) and tuner pack.


3-14. TUNER PACK, D. C. FAN (M901)




3-15. UCOM BOARD, AMP POWER BOARD




3-16. AUDIO BOARD, POWER BOARD, POWER TRANSFORMER (T900) (1)




3-17. AUDIO BOARD, POWER BOARD, POWER TRANSFORMER (T900) (2)




3-18. MD MECHANISM DECK (MDM-7B4M), MD DIGITAL BOARD




3-19. HOLDER ASSY




3-20. BD (MD) BOARD




3-21. LOADING MOTOR (M703), SPINDLE MOTOR (M701), SLED MOTOR (M702)



3-22. OVER WRITE HEAD



3-23. OP-SUB SECTION



SECTION 4 TEST MODE

[Factory Preset Mode]

* This mode clears all data including preset data stored in the RAM to initial conditions. Excute this mode when returning the set to the customer.

Procedure:

- 1. Press the 1/0 button to turn the power on.
- Press the FUNCTION button to set the CD function. (except the TUNER function)
- Press three buttons VOL +, CD and MD and M
- The message "COLD RESET" blinks and the present contents are reset to the default values.

[Version and Destination Display Mode]

* The version or destination is displayed.

Procedure:


- 1. Press the 1/0 button to turn the power on.
- To enter the test mode, press the three buttons VOL +, and MD simultaneously.
- 3. The model and destination are displayed.
- Press the REC/REC IT/NORMAL and buttons simultaneously.
- Press the <u>REC/REC IT/NORMAL</u> and <u>III</u> buttons simultaneously.
- 7. The version is displayed as "MD V ". " "."
- 8. Press the REC/REC IT/NORMAL and buttons simultaneously, then the mode returns to step 3.
- 9. To exit from this mode, press the 1/0 button to turn the power off.

[FL Tube Test Mode]


* All fluorecent segments and LEDs are tested.

Procedure:

- 1. Press the 1/0 button to turn the power on.
- 2. To enter the test mode, press three buttons VOL +, and TUNING simultaneously.
- 3. All segments and LEDs are turned on.
- Press the REC/REC IT/NORMAL and ►II buttons simultaneously.
- 5. All segments are turned off (All LEDs still lit).
- Press the REC/REC IT/NORMAL and ►II buttons simultaneously.
- 7. Almost half segments are turned on. (PATTERN 1)



- 8. Press the REC/REC IT/NORMAL and buttons simultaneously.
- 9. The segments which are turned on in step 7 are turned off, then remaining segments are turned on. (PATTERN 2)



- 10. Press the REC/REC IT/NORMAL and buttons simultaneously, the mode returns to step 3 and all segments are turned on
- 11. To exit from this mode, press the 1/0 button to turn the power off.

[Key Test Mode]

* Keyboard check.

Procedure:

- 1. Press the 1/0 button to turn the power on.
- 2. To enter the test mode, press three buttons VOL +, and ► TUNING + simultaneously.
- In the key test mode, the fluorecent indicator displays "KEY00".
- 4. Each time a button is pressed, "KEY □ □" value increases. However, once a button is pressed, it is no longer taken into account
- 5. To exit from this mode, press three buttons simultaneously as step 2, or disconnect the power cord.

[Amp Test Mode]

Procedure:

- 1. Press the $1/\bigcirc$ button to turn the power on.
- Press three buttons VOL -, CD and MD simultaneously.
- Press two buttons REC/REC IT/NORMAL and simultaneously.
- 4. The message "7 [TESTMIN]" is displayed for a few seconds.
- Press two buttons REC/REC IT/NORMAL and simultaneously again.
- 6. Each time two buttons are depressed, the display changes as "8 [TESTMID]", "9 [TESTMAX]", and "10 [TESTSUR]".
- Press the VOL + button, the display changes "VOLUME 21" to "VOLUME MAX".
- Press the VOL button, the display changes "VOLUME 21" to "VOLUME MIN".
- 9. To exit from this mode, press the 1/0 button to turn the power off and cold reset is executed.

[CD Test Mode]

* The CD system versions are displayed.

Procedure:


- 1. Press the 1/0 button to turn the power on.
- 2. Press the **FUNCTION** button to set the CD function.
- Press three buttons of VOL + , and CD SYNC HIGH simultaneusly.
- 4. The message "dut CD VER" is displayed.
- 6. Press the ►►I/►► TUNING + button and "CDSYS ###" is displayed.
- 7. Each time the ►►I/►► TUNING + button is depressed, the display changes as "CDMA S", "CDBD O", "CDCD M".
- 8. By depressing the **Idd/dd TUNING** button the versions are displayed in reverse.
- 9. To exit this mode, press the 1/0 button to turn the power off.

[CD Aging Mode]

Procedure:

- 1. Press the 1/0 button to turn the power on.
- Press the FUNCTION button to set the CD function, and insert a disc.
- 3. Press three buttons of VOL -, CD ▲ and ► TUNING + simultaneusly.
- 4. The message "Eject" is displayed, a disc is ejected and inserted again automatically.
- The sequence during the CD aging mode is following as below

CD aging mode sequence:



To exit this mode, press the button to turn the power off.

[CD/MD Aging Mode]

* Aging of CD and MD is performed at the same time.

Procedure:

- 1. Press the 1/0 button to turn the power on.
- 2. Press the FUNCTION button to set the CD function.
- 3. Insert a disc (CD) and a recordable disc (MD).
- 4. Press three buttons of VOL +, ►II and MD ▲ simultaneusly.
- 5. The message "Eject" is displayed and aging started.
- The sequence of CD aging is same as the CD aging mode, however the MD aging is repetition of changing the track after a few seconds recording.
- 7. The number of aging is displayed in hexadecimal. For example, AGING00000011 means the 17th rouine of aging.
- 8. To exit this mode, press the \(\begin{align*} \frac{\bar{\sqrt{O}}}{\top} \) button to turn the power off, or press three buttons of \(\bar{\sqrt{O}L} + \), \(\bar{CD} \) \(\bar{\sqrt{A}} \) and \(\bar{MD} \) \(\bar{\sqrt{A}} \) simultaneously and cold reset is executed.

MD SECITON

Note 1: About "R"

As this unit has only a few buttons, some operations require the use of remote commander (RM-SC5BEN/provided with unit: 1-476-649-21) buttons. These operations are indicated as "R" in this manual.

 $\label{eq:menu} Example: \underline{\text{MENU/NO}} \text{ "R"} ... \text{Press the } \underline{\text{MENU/NO}} \text{ button of the remote commander.}$

Note 2: Incorrect operations may be performed if the MD test mode is not entered properly.

In this case, press the LO button to turn the power off, and retry to enter the MD test mode.

1. PRECAUTIONS FOR USE OF TEST MODE

 As operations related to loading will be performed regardless of the test mode operations being performed, be sure to check that the disc is stopped before setting and removing it.

Even if the MD \(\begin{align*} \) button is pressed while the disc is rotating during continuous playback, continuous recording, etc., the disc will not stop rotating.

Therefore, it will be ejected while rotating.

Be sure to press the MD button after pressing the MENU/NO "R" button and the rotation of disc is stopped.

1-1. Recording laser emission mode and operating buttons

- Continuous recording mode (CREC 1MODE)
- Laser power check mode (LDPWR CHECK)
- Laser power adjustment mode (LDPWR ADJUST)
- Comparison with initial Iop value written in nonvolatile memory (Iop Compare)
- Write current Iop value in read nonvolatile memory using microprocessor (Iop NV Save)
- Traverse (MO) check (EF MO CHECK)
- Traverse (MO) adjustment (EF MO ADJUST)
- When pressing the REC/REC IT button.

2. SETTING THE TEST MODE

The following is the method of entering the test mode.

Procedure: 1. Press the $\boxed{I/\circlearrowleft}$ button to turn the power on.

- 2. Press the FUNCTION button to set the MD function.
- 3. Press three buttons of VOL , , and CD SYNC HIGH (MD) simulta neously. When the test mode is set, "[Check]" will be displayed. Pressing the H R" or HR" button between the following three groups; ··· ← [Check] ← [Service] ← [Develop] ← ···.

Note: Do not use the test mode in the [Develop] group.

If used, the unit may not operate normally.

If the [Develop] group is set accidentally, press the

MENU/NO "R" button immediately to exit the [Develop] group.

3. RELEASING THE TEST MODE

Procedure 1: Press the REPEAT "R" button to display "Initialize", then release the MD test mode.

Procedure 2: Press two button of VOL - and MD ▲ to display "Intialize", then release the MD test mode.

4. BASIC OPERATIONS OF THE TEST MODE

All operations are performed using the [44 "R"], [ENTER/YES "R"] and [MENU/NO "R"]. The functions of these buttons are as follows.

Function name	Function
ldd "R", lbl "R" buttons	Changes parameters and modes
ENTER/YES "R" button	Proceeds onto the next step. Finalizes input
MENU/NO "R" button	Returns to previous step. Stops operations

5. SELECTING THE TEST MODE

There are 26 types of test modes as shown below. The groups can be switched by pressing the *\(\begin{align*} \pm \mathbb{R}''\) button. After selecting the group to be used, press the \(\begin{align*} \begin{align*} \pm \mathbb{R}''\) button. After setting a certain group, pressing the \(\begin{align*} \pm \mathbb{R}''\) or \(\begin{align*} \begin{align*} \mathbb{R}''\) button switches modes shown below.

Refer to "Group" in the table for details can be selected.

All items used for servicing can be treated using group [Service]. So be carefully not to enter other groups by mistake.

Note: Do not use the test mode in the [Develop] group.

If used, the unit may not operate normally.

If the [Develop] group is set accidentally, press the MENU/NO "R" button immediately to exit the [Develop] group.

		5		Group		
Display	No.	Details	Mark	Check	Service	
AUTO CHECK	C01	Automatic self-diagnosis			0	
Err Display	C02	Error history display, clear			0	
TEMP ADJUST	C03	Temperature compensation offset adjustment			0	
LDPWR ADJUST	C04	Laser power adjustment			0	
Iop Write	C05	Iop data writing				
Iop NV Save	C06	Writes current Iop value in read nonvolatile memory using microprocessor			0	
EF MO ADJUST	C07	Traverse (MO) adjustment			0	
EF CD ADJUST	C08	Traverse (CD) adjustment				
FBIAS ADJUST	C09	Focus bias adjustment			0	
AG Set (MO)	C10	Auto gain output level adjustment (MO)			0	
AG Set (CD)	C11	Auto gain output level adjustment (CD)				
TEMP CHECK	C12	Temperature compensation offset check		0	0	
LDPWR CHECK	C13	Laser power check		0	0	
EF MO CHECK	C14	Traverse (MO) check		0	0	
EF CD CHECK	C15	Traverse (CD) check		0	0	
FBIAS CHECK	C16	Focus bias check		0	0	
ScurveCHECK	C17	S-curve check	×	0		
VERIFYMODE	C18	Nonvolatile memory check	×	0		
DETRK CHECK	C19	Detrack check	×	0		
0920 CHECK	C25	Most circumference check	×	0		
Iop Read	C26	Iop data display		0	0	
Iop Compare	C27	Comparison with initial Iop value written in nonvolatile memory		0	0	
ADJ CLEAR	C28	Initialization of nonvolatile memory for adjustment values			0	
INFORMATION	C31	Display of microprocessor version, etc.		0		
CPLAY1MODE	C34	Continuous playback mode		0		
CREC 1MODE	C35	Continuous recording mode		0		

- For details of each adjustment mode, refer to "5. Electrical Adjustments". For details of "Err Display", refer to "Self-Diagnosis Function" on page 2.
- If a different mode has been selected by mistake, press the MENU/NO "R" button to release that mode.
- Modes with (×) in the Mark column are not used for servicing and therefore are not described in detail. If these modes are set accidentally, press the MENU/NO "R" button to release the mode immediately.

5-1. Operating the Continuous Playback Mode

1. Entering the continuous playback mode

- (1) Set the disc in the unit. (Whichever recordable discs or discs for playback only are available)
- (2) Press the **R** "R" or **M** button to display "CPLAY IMODE" (C34).
- (3) Press the ENTER/YES "R" button to change the display to "CPLAY1MID".
- (4) When access completes, the display changes to " $C = \square \square \square \square$

Note: The numbers "0" displayed show you error rates and ADER.

2. Changing the parts to be played back

(1) Press the ENTER/YES "R" button during continuous playback to change the display as below.

When pressed another time, the parts to be played back can be moved

(2) When access completes, the display changes to "C = 0.000" AD = 000".

Note: The numbers "" displayed show you error rates and ADER.

3. Ending the continuous playback mode

- (1) Press the MENU/NO "R" button. The display will change to "CPLAY1MODE" (C34).
- Press the MD \(\begin{array}{c} \begin{

Note: The playback start addresses for IN, MID, and OUT are as follows

> IN : 40h cluster MID : 300h cluster OUT: 700h cluster

5-2. Operating the Continuous Recording Mode (Use only when performing self-recording/palyback check)

1. Entering the continuous recording mode

- Set a recordable disc in the unit.
- Press the **◄◄** "R" or **▶▶** "R" button to display "CREC 1MODE" (C35).
- (3) Press the ENTER/YES "R" button to change the display to "CREC 1MID".
- When access completes, the display changes to "CREC 1(" BBB)" and " REC " is displayed.

Note: The numbers "i" displayed shows you the recording position addresses.

2. Changing the parts to be recorded

When the ENTER/YES "R" button is pressed during continuous recording, the display changes as below.

When pressed another time, the parts to be recorded can be changed. " REC " goes off.

When access completes, the display changes to "CREC 1(" Note: The numbers "0" displayed shows you the recording posi-

tion addresses.

3. Ending the continuous recording mode

- Press the MENU/NO "R" button. The display changes to "CREC 1MODE" (C35) and " REC " goes off.
- Press the MD **\Delta** button and take out the disc.

Note 1: The recording start addresses for IN, MID, and OUT are as follows.

IN: 40h cluster MID: 300h cluster OUT: 700h cluster

Note 2: The MENU/NO "R" button can be used to stop recording anytime.

Note 3: Do not perform continuous recording for long periods of time above 5 minutes.

Note 4: During continuous recording, be careful not to apply vibration.

6. FUNCTIONS OF OTHER BUTTONS

Function	Contents
▶II	Sets continuous playback when this is pressed in the STOP state. When this is pressed during continuous playback, playback position moves.
	Stops continuous playback and continuous recording
▶▶ "R"	The sled moves to the outer circumference only when this is pressed
◄ "R"	The sled moves to the inner circumference only when this is pressed
■ + ▶→/▶→ TUNING +	Switches the spindle servo mode (CLV $S \longleftrightarrow CLV A$)
VOL - + CD ▲	Switches the displayed contents each time the button is pressed
MD ▲	Ejects the disc
REPEAT "R"	Releases the test mode

7. AUTOMATIC SELF-DIAGNOSIS FUNCTION

This test mode performs CREC and CPLAY automatically for mainly checking the characteristics of the optical pick-up. To perform this test mode, the laser power must first be checked.

Perform AUTO CHECK after the laser power check and Iop Compare.

Procedure:

- 1. Press the [are "R"] or button to display "AUTO CHECK" (C01).
- If a disc is in the mechanical deck, it will be ejected forcibly.
 "DISC IN" will be displayed in this case. Load a test disc (MDW-74/GA-1) which can be recorded.
- 4. If a disc is loaded at step 3, the check will start automatically.
- 5. When "XX CHECK" is displayed, the item corresponding to XX will be performed.

 When "060 CHECK" completes, the disc loaded at step 3 will be ejected. "DISC IN" will be displayed. Load the check disc (TDYS-1).
- 6. When the disc is loaded in step 5, the check will automatically be resumed from "07 CHECK".
- 7. After completing to test item 12 ("oC CHECK"), check OK or NG will be displayed. If all items are OK, "CHK ALL OK" will be displayed. If any item is NG, it will be displayed as "NG:xxxx".

When "CHK ALL OK" is displayed, it means that the optical pick-up is normal. Check the operations of other parts (spindle motor, sled motor, etc.).

When displayed as "NG:xxxx", it means that the optical pick-up is faulty. In this case, replace the optical pick-up.

8. INFORMATION

Display the software version.

Procedure:

- 1. Press the ** "R" or ** button to display "INFORMATION" (C31).
- 2. Press the ENTER/YES "R" button.
- 3. The software version will be displayed.
- 4. Press the MENU/NO "R" button to end this mode.

IOP DATA RECORDING AND DISPLAY WHEN OPTI-CAL PICK-UP AND NON-VOLATILE MEMORY (IC195 OF BD (MD) BOARD) ARE REPLACED

The IOP value labeled on the optical pick-up can be recorded in the non-volatile memory. By recording the value, it will eliminate the need to look at the value on the label of the optical pick-up. When replacing the optical pick-up or non-volatile memory (IC195 of BD (MD) board), record the IOP value on the optical pick-up according to the following procedure.

Record Procedure:

- 1. Press the 1/0 button to turn the power on.
- 2. Press the **FUNCTION** button to set the MD function.
- Press three buttons of VOL -, and CD SYNC HIGH, simultaneously to enter the MD test mode and display "ICheck!".
- Press the (R") or (R") button to display "[Service]".
- Press the ENTER/YES "R" button to display "AUTO CHECK", and press the ►► "R" button to display "Iop Write".
- 6. Press the ENTER/YES "R" button.
- 7. The display becomes "Ref=@@@.@" (@ is an arbitrary number) and the numbers which can be changed will blink.
- 8. Input the IOP value written on the optical pick-up.

To select the number: Press the

To select the digit : Press two buttons of VOL - and CD simultaneously.

- 9. When the ENTER/YES "R" button is pressed, the display becomes "Measu=@@@.@" (@ is an arbitrary number).
- 10. As the adjustment results are recorded for the step 9 value. Leave it as it is and press the [ENTER/YES "R"] button.
- 11. "Complete!" will be displayed momentarily. The value will be recorded in the non-volatile memory and the display will become "Iop Write".
- 12. Press the REPEAT "R" button, or press two buttons of VOL and MD ▲ simultaneously. to complete. "Initialize" will be displayed and release the MD test mode.

Display Precedure:

- 1. Press the $\boxed{I/\bigcirc}$ button to turn the power on.
- 2. Press the **FUNCTION** button to set the MD function.
- 3. Press three buttons of VOL , , and CD SYNC HIGH simultaneously to enter the MD test mode and display "[Check]".
- 5. Press the ENTER/YES "R" button to display "AUTO CHECK", and press the ►► "R" button to display "Iop Read".
- 6. Press the ENTER/YES "R" button.
- "@@.@/##.#" is displayed and the recorded contents are displayed.
 - @@.@ : Indicates the Iop value labeled on the pick-up.
 - ##.# : Indicates the Iop value after adjustment.
- 8. Press the REPEAT "R" button to complete. "Initialize" will be displayed and release the MD test mode.

WHEN MEMORY NG IS DISPLAYED

If the nonvolatile memory data is abnormal, "E001 MEMORY NG" will be displayed so that the MD deck does not continue operations. In this case, set the test mode promptly and perform the following procedure.

Procedure:

- 1. Enter the MD test mode.
- Normally a message for selecting the test mode will be displayed. However if the nonvolatile memory is abnormal, the following will be displayed "INIT EEP?".
- 3. Press the and MD buttons simultaneously.
- 4. Press the **◄◄** "R" or **▶▶** "R" button to display "MDM-7B4M".
- 5. Press the ENTER/YES "R" button. If the nonvolatile memory is successfully overwritten, the normal MD test mode will be set and a message to select the MD test mode will be displayed.

CHECKS PRIOR TO PARTS REPLACEMENT AND ADJUSTMENTS IN MD

Before performing repairs, perform the following checks to determine the faulty locations up to a certain extent. Details of the procedures are described in "5 Electrical Adjustments".

	Criteria for Determination (Unsatisfactory if specified value is not satisfied)	Measure if unsatisfactory
Laser power check (6-2 : See page 37)	0.9 mW power Specified value : figure1 7.0 mW power Specified value : figure2	Clean the optical pick-up Adjust again Replace the optical pick-up
	Iop (at 7.0mW) • Labeled on the optical pick-up Iop value ± 10mA	Replace the optical pick-up
Auto check (6-4 : See page 38)	Unsatisfactory if displayed as "NG: XXXX" (X is an arbitrary number)	Replace the optical pick-up
Temperature compensation offset check (6-1 : See page 37)	Unsatisfactory if displayed as "T=@@ (##) [NG]" (@@, ## are both arbitrary numbers)	 Check for disconnection of the circuits around D101 (BD (MD) board) Check the signals around IC101, IC151, CN102, CN103 (BD (MD) board)

Note:

The criteria for determination above is intended merely to determine if satisfactory or not, and does not serve as the specified value for adjustments

When performing adjustments, use the specified values for adjustments.

Figure1:

SPECIFIED VALUE	KMS-260B	0.85 to 0.91 mW
OI EOII IED VALUE	KMS-260E	0.90 to 0.96 mW

Figure2:

SPECIFIED VALUE	KMS-260B	6.8 to 7.2 mW
OI LOII ILD VALUE	KMS-260E	7.0 to 7.5 mW

RETRY CAUSE DISPLAY MODE IN MD

- In this test mode, the causes for retry of the unit during recording can be displayed on the fluorescent indicator tube. During playback, the "track mode" for obtaining track information will be set.
 - This is useful for locating the faulty part of the unit.
- The following will be displayed:

During recording and stop: Retry cause, number of retries, and number of retry errors.

During playback : Information such as type of disc played, part played, copyright.

These are displayed in hexadecimal.

Precedure:

- 1. Load a recordable disc whose contents can be erased into the unit.
- 2. Press the MENU/NO "R" button. When "Edit Menu" is displayed on the fluorescent indicator tube, press the "R" or F" button to display "All Erase?".
- 3. Press the **ENTER/YES** "R" button.
- 4. When "All Erase??" is displayed on the fluorescent indicator tube.
- 5. Press the **ENTER/YES "R"** button to display "Complete!".
- 6. Press the REC/REC IT button to start recording. Then press the ►II button and start recording. If recording cannot be performed, press the FUNCTION button and set a different function.
- 7. Press three buttons of VOL -, I and CD SYNC HIGH simultaneously to enter the retry cause display mode.
- 8. To check the "track mode", press the button to start playback.
- 9. To release this mode, press the 🔀 button to turn the power off. When "TOC" goes off, disconnect the power plug from the outlet.

If the test mode cannot be released, refer to "Factory Preset" on page 24.

Fig. 1 Reading the Test Mode Display (During recording and stop)

RTs@@c##e**
fluorescent indicator tube

@@: Cause of retry## : Number of retries** : Number of retry errors

Fig. 2 Reading the Test Mode Display (During playback)

@@###** \$\$] fluorescent indicator tube

@@: Parts No. (name of area named on TOC)

: Cluster ** : Sector

\$\$: Track mode (Track information such as copyright information of each part)

Reading the Retry Cause Display

	H	lighe	r Bit	s	Lower Bits						
Hexadecimal	8	4	2	1	8	4	2	1	Hexadecimal	Cause of Retry	Occurring conditions
Bit	b7	b6	b5	b4	b3	b2	b1	b0]		
Binary	0	0	0	0	0	0	0	1	01	shock	When track jump (shock) is detected
	0	0	0	0	0	0	1	0	02	ader5	When ADER was counted more than five times
	"	0	0		"	0	1	0	02 aders		continuously
	0	0	0	0	0	1	0	0	04	Discontinuous address	When ADIP address is not continuous
	0	0	0	0	1	0	0	0	08	DIN unlock	When DIN unlock is detected
	0	0	0	1	0	0	0	0	10	FCS incorrect	When not in focus
	0	0	1	0	0	0	0	0	20	IVR rec erraor	When ABCD signal level exceeds the specified range
	0	1	0	0	0	0	0	0	40	CLV unlock	When CLV is unlocked
	1	0	0	0	0	0	0	0	80	Access fault	When access operation is not performed normally

Reading the Display:

Convert the hexadecimal display into binary display. If more than two causes, they will be added.

Example

When 42 is displayed:

Higher bit: $4 = 0100 \rightarrow b6$ Lower bit: $2 = 0010 \rightarrow b1$

In this case, the retry cause is combined of "CLV unlock" and "ader5".

When A2 is displayed:

Higher bit: $A = 1010 \rightarrow b7 + b5$ Lower bit: $2 = 0010 \rightarrow b1$

The retry cause in this case is combined of "Access fault", "IVR rec error", and "ader5".

Reading the Retry Cause Display

	I	High	er Bi	t	L	owe	r Bit	s		D. L. H		
Hexadecimal	8	4	2	1	8	4	2	1	Hexadecimal	Details		
Bit	b7	b6	b5	b4	b3	b2	b1	b0]	When 0	When 1	
Binary	0	0	0	0	0	0	0	1	01	Emphasis OFF	Emphasis ON	
	0	0	0	0	0	0	1	0	02	Monaural	Stereo	
	0	0	0	0	0	1	0	0	04	This is 2-bit display. Normally 01.		
	0	0	0	0	1	0	0	0	08	01:Normal audio. Others:Invalid		
	0	0	0	1	0	0	0	0	10	Audio (Normal)	Invalid	
	0	0	1	0	0	0	0	0	20	Original Digital copy		
	0	1	0	0	0	0	0	0	40	Copyright No copyright		
	1	0	0	0	0	0	0	0	80	Write prohibited	Write allowed	

Reading the Display:

Convert the hexadecimal display into binary display. If more than two causes, they will be added.

Example When 84 is displayed:

Higher bit: $8 = 1000 \rightarrow b7$ Lower bit: $4 = 0100 \rightarrow b2$

In this case, as b2 and b7 are 1 and others are 0, it can be determined that the retry cause is combined of "Emphasis OFF", "Monaural", "Original", "Copyright", and "Write allowed".

Example When 07 is displayed:

Higher bit: $0 = 0000 \rightarrow All \ 0$ Lower bit: $7 = 0111 \rightarrow b0 + b1 + b2$

In this case, as b0, b1, and b2 are 1 and others are 0, it can be determined that the retry cause is combined of "Emphasis ON", "Stereo", "Original", "Copyright", and "Write prohibited".

Hexadecimal → Binary Conversion Table

Hexadecimal	Binary	Hexadecimal	Binary
0	0000	8	1000
1	0001	9	1001
2	0010	A	1010
3	0011	В	1011
4	0100	С	1100
5	0101	D	1101
6	0110	Е	1110
7	0111	F	1111

SECTION 5 ELECTRICAL ADJUSTMENTS


CD SECTION

Note 1:


- CD Block is basically designed to operate without adjustment. Therefore, check each item in order given.
- 2. Use YEDS-18 disc (3-702-101-01) unless otherwise indicated.
- 3. Use an oscilloscope with more than $10M\Omega$ impedance.
- 4. Clean the object lens by an applicator with neutral detergent when the signal level is low than specified value with the following checks.

Note 2:

As the laser diode in the optical pick-up (OPTIMA-720L1E) is easily damaged by static electricity, solder the laser tap of the flexible board when handling it. Before disconnecting the connector, solder first. Before connecting the connector, be careful not to remove the solder. Also take adequate measures to prevent damage by static electricity. Handle the flexible board with care as it breaks easily.




RF Level Check Connection:



Procedure:

- Connect an oscilloscope to test point TP (RFAC) and TP (DVC 1.65V) on the BD (CD) board.
- 2. Turn the power on.
- 3. Put the disc (YEDS-18) in to playback the number five track.
- Confirm that oscilloscope waveform is clear and check RF signal level is correct or not.


Note: A clear RF signal waveform means that the shape "◊" can be clearly distinguished at the center of the waveform.



Checking Location: BD (CD) board

Checking Location:

- BD (CD) BOARD -



MD SECTION

Note 1: About "R"

As this unit has only a few buttons, some operations require the use of remote commander (RM-SC5BEN/provided with unit: 1-476-649-11) buttons. These operations are indicated as "R" in this manual.

Example: MENU/NO "R" ... Press the MENU/NO button of the remote commander.


Note 2: Incorrect operations may be performed if the MD test mode is not entered properly.

In this case, press the 10 button to turn the power off, and retry to enter the MD test mode.


1. PARTS REPLACEMENT AND ADJUSTMENT

If malfunctions caused by optical pick-up such as sound skipping are suspected, follow the following check.

Check before replacement



Adjustment flow




2. PRECAUTIONS FOR CHECKING LASER DIODE EMISSION

To check the emission of the laser diode during adjustments, never view directly from the top as this may lose your eye-sight.

3. PRECAUTIONS FOR USE OF OPTICAL PICK-UP (KMS-260B/260E)

As the laser diode in the optical pick-up is easily damaged by static electricity, solder the laser tap of the flexible board when handling it

Before disconnecting the connector, solder first. Before connecting the connector, be careful not to remove the solder. Also take adequate measures to prevent damage by static electricity. Handle the flexible board with care as it breaks easily.



Optical pick-up flexible board

4. PRECAUTIONS FOR ADJUSTMENTS

- When replacing the following parts, perform the adjustments and checks with
 on the order shown in the following table.
- Set the MD test mode when performing adjustments.
 After completing the adjustments, exit the MD test mode.

 Perform the adjustments and checks in "Group Service" of the MD test mode.
- 3. Perform the adjustments to be needed in the order shown.
- 4. Use the following tools and measuring devices.
 - Check Disc (TDYS-1) (Part No.: 4-963-646-01)
 - Test Disk (MDW-74/GA-1) (Part No.: 4-229-747-01)
 - Laser power meter LPM-8001 (Part No.: J-2501-046-A) or MD Laser power meter 8010S (Part No.: J-2501-145-A)*1
 - Oscilloscope (Measure after performing CAL of prove.)
 - · Digital voltmeter
 - Thermometer
 - Jig for checking BD (MD) board waveform (Part No. : J-2501-196-A)
- When observing several signals on the oscilloscope, etc., make sure that VC and ground do not connect inside the oscilloscope.
 - (VC and ground will become short-circuited.)
- 6. Using the above jig enables the waveform to be checked without the need to solder.
 - (Refer to Servicing Notes on page 6.)
- 7. As the disc used will affect the adjustment results, make sure that no dusts nor fingerprints are attached to it.

*1 Laser power meter

When performing laser power checks and adjustment (electrical adjustment), use of the new MD laser power meter 8010S (Part No. J-2501-145-A) instead of the conventional laser power meter is convenient.

It sharply reduces the time and trouble to set the laser power meter sensor onto the objective lens of optical pick-up.

	Parts to be replaced									
Adjustment	Optical Pick-up	IC101	IC102	IC151	IC190	IC195	D101			
7. Initial setting of adjustment value	0	×	X	X	×	0	×			
8. Recording of Iop information	0	×	X	×	×	0	×			
9. Temperature compensation offset adjustment	×	0	×	×	×	0	0			
10. Laser power adjustment	0	X	X	X	0	0	×			
11. Iop NV Save	0	X	0	X	0	0	×			
12. Traverse adjustment	0	0	X	0	×	0	×			
13. Focus bias adjustment	0	0	X	0	×	0	×			
16. Auto gain control output level adjustment	0	0	×	0	×	0	×			
6-4. AUTO CHECK	0	0	×	0	0	0	×			

5. USING THE CONTINUOUSLY RECORDED DISC

- * This disc is used in focus bias adjustment and error rate check. The following describes how to create a continuous recording disc.
- 1. Insert a disc (blank disc) commercially available.
- 2. Press the ◄ "R" or ▶► "R" button and display "CREC 1MODE"
- 3. Press the ENTER/YES "R" button again to display "CREC 1 MID".
 - Display "CREC 1(0300)" and start to recording.
- 4. Complete recording within 5 minutes.
- 5. Press the MENU/NO "R" button and stop recording.
- 6. Press the MD \(\bigstar button and remove the disc.

The above has been how to create a continuous recorded data for the focus bias adjustment and error rate check.

Note: Be careful not to apply vibration during continuous recording.

6. CHECKS PRIOR TO REPAIRS

These checks are performed before replacing parts according to "approximate specifications" to determine the faulty locations. For details, refer to "Checks Prior to Parts Replacement and Adjustments in MD" (see page 30).

6-1. Temperature Compensation Offset Check

When performing adjustments, set the internal temperature and room temperature to 22 to 28°C.

Procedure:

- 1. Press the ◄◄ "R" or ►► "B" button to display "TEMP CHECK" (C12).
- 2. Press the ENTER/YES "R" button.
- 3. "T=@@(##) [OK]" should be displayed. If "T=@@ (##) [NG]" is displayed, it means that the results are bad. (@@ indicates the current value set, and ## indicates the value written in the non-volatile memory.)

6-2. Laser Power Check


Before starting adjustment;

The laser power adjustment value changes depending upon the types of the optical pick-up (KMS-260B or KMS-260E).

Check the type of the optical pick-up before starting adjustment. (See the illustrations "The method of identifying the optical pick-up" on page 41)

Before checking, check the Iop value of the optical pick-up. (Refer to 8. Recording and Displaying the Iop Information (see page 40))

Connection:



Procedure:

- 1. Set the laser power meter on the objective lens of the optical pick-up. (When it cannot be set properly, press the ◄ "R" button or ▶ "R" button to move the optical pick-up.)

 Connect the digital volt meter to CN105 pin ① (I+3V) and CN105 pin ② (IOP).
- 3. Press the ENTER/YES "R" button once and display "LD 0.9mW\$ U". Check that the reading of the laser power meter becomes specified value.

SPECIFIED VALUE	KMS-260B	0.85 to 0.91 mW
	KMS-260E	0.90 to 0.96 mW


4. Press the ENTER/YES "R" button once more and display "LD 7.0mW\$ 000. Check that the reading the laser power meter and digital volt meter satisfy the specified value.

Specified Value:

Laser power meter reading:

ſ	KMS-260B	7.0 to 0.2 mW
Γ	KMS-260E	7.25 to 0.25 mW

Digital voltmeter reading : Optical pick-up displayed value \pm 10%



Press the MENU/NO "R" button and display "LDPWR CHECK" (C13) and stop the laser emission.
 (The MENU/NO "R" button is effective at all times to stop the laser emission.)

Note: After step 4, each time the ENTER/YES "R" button is pressed, the display will be switched to "LD 0.7W\$ 00" and "LD 6.2mW\$ 00" "LD WP ホセイ\$ 00". Nothing needs to be performed here.

Checking Location: BD (MD) board (see page 44)

6-3. lop Compare

The current Iop value at laser power 7.0 mW output and reference Iop value (set at shipment) written in the nonvolatile memory are compared, and the rate of increase/decrease will be displayed in percentage.

Note: Perform this function with the optical pick-up set at room temperature.

Procedure:

- Press the ◄ "R" or ► "B" button to display "Iop Compare" (C27).
- 2. Press the **ENTER/YES** "R" button and start measurements.
- When measurements complete, the display changes to "± xx% yy".
 - xx is the percentage of increase/decrease, and OK or NG is displayed at yy to indicate whether the percentage of increase/decrease is within the allowable range.
- 4. Press the MENU/NO "R" button to end.

6-4. Auto Check

This test mode performs CREC and CPLAY automatically for mainly checking the characteristics of the optical pick-up. To perform this test mode, the laser power must first be checked. Perform Auto Check after the laser power check and Iop compare.

Procedure:

- Press the ◄ "R" or ▶► "R" button to display "AUTO CHECK" (C01).
- 2. Press the ENTER/YES "R" button. If "LDPWR " " " is displayed, it means that the laser power check has not been performed. In this case, perform the laser power check and Iop Compare, and then repeat from enter the MD test mode.
- If a disc is in the mechanical deck, it will be ejected forcibly.
 "DISC IN" will be displayed in this case. Load a test disc (MDW-74/GA-1) which can be recorded.
- 4. If a disc is loaded at step 3, the check will start automatically.
- 5. When "XX CHECK" is displayed, the item corresponding to XX will be performed.
 When "06 CHECK" completes, the disc loaded at step 3 will be ejected. "DISC IN" will be displayed. Load the check disc
- (TDYS-1).

 6. When the disc is loaded in the step 5, the check will automatically
- be resumed from "07 CHECK".

 7. After completing to test item 12 ("oC CHECK"), check OK or NG will be displayed. If all items are OK, "CHK ALL OK" will be displayed as "NG:xxxx".

When "CHK ALL OK" is displayed, it means that the optical pickup is normal. Check the operations of other parts (spindle motor, sled motor, etc.).

When displayed as "NG:xxxx", it means that the optical pick-up is faulty. In this case, replace the optical pick-up.

6-5. Other Checks

All the following checks are performed by the Auto Check mode. They therefore need not be performed in normal operation.

6-6. Traverse Check

6-7. Focus Bias Check

6-8. C PLAY Check

6-9. Self-Recording/Playback Check

6-6 Traverse Check


Note 1: Data will be erased during MO reading if a recorded disc is used in this adjustment.

Note 2: If the traverse waveform is not clear, connect the oscilloscope as shown in the following figure so that it can be seen more clearly.


oscilloscope (DC range)

BD (MD) board

330 kΩ



Connection:




Procedure:

- Connect an oscilloscope to CN105 pin (TE) and CN105 pin (VC) on the BD (MD) board.
- 2. Load a disc (any available on the market). (Refer to Note 1)
- Press the ►► "R" button to move the optical pick-up outside the pit.
- 4. Press the ◄ "R" or ► "B" button to display "EF MO CHECK"(C14).
- Press the ENTER/YES "R" button to display "EFB = 0 0 MO-R". (Laser power READ power/Focus servo ON/tracking servo OFF/spindle (S) servo ON)
- 6. Observe the waveform of the oscilloscope, and check that the specified value is satisfied. Do not press the ◄ "R" or ► "R" button.

(Read power traverse checking)

Traverse Waveform




Specified value : Below 10% offset value

Offset value (%) =
$$\frac{|A - B|}{2(A + B)} \times 100$$

- 7. Press the ENTER/YES "R" button to display "EFB = 0.00 MO-W".
- 8. Observe the waveform of the oscilloscope, and check that the specified value is satisfied. Do not press the ◄ "R" or ▶ "R" button. (Write power traverse checking)

Traverse Waveform




Specified value: Below 10% offset value

Offset value (%) = $\frac{|A - B|}{2(A + B)} \times 100$

- 9. Press the ENTER/YES "R" button to display "EFB = 0 0 MO-P".
 - Then, the optical pick-up moves to the pit area automatically and servo is imposed.
- 10. Observe the waveform of the oscilloscope, and check that the specified value is satisfied. Do not press the ◄ "R" or ► "R" button.

Traverse Waveform



Specified value: Below 10% offset value

Offset value (%) = $\frac{|A - B|}{2(A + B)} \times 100$

11. Press the ENTER/YES "R" button to display "EF MO CHECK" (C14).

The disc stops rotating automatically.

- 12. Press the MD \(\bigstar button and take out the disc.
- 13. Load the check disc (TDYS-1).
- 14. Press the 【◀◀ "R" or 【▶▶ "R" button and display "EF CD CHECK" (C15).
- 15. Press the ENTER/YES "R" button to display "EFB = 0 0 CD". Servo is imposed automatically.
- 16. Observe the waveform of the oscilloscope, and check that the specified value is satisfied. Do not press the ★★ "R" or ★★ "R" button.

Traverse Waveform



Specified value : Below 10% offset value

Offset value (%) = $\frac{|A - B|}{2(A + B)} \times 100$

- 17. Press the ENTER/YES "R" button to display "EF CD CHECK" (C15).
- 18. Press the MD button and take out the check disc (TDYS-1).

Checking Location: BD (MD) board (see page 44)

6-7. Focus Bias Check

Change the focus bias and check the focus tolerance amount.

Procedure:

- 1. Load the test disc (MDW-74/GA-1).
- Press the ("R") or ("R") button to display "CPLAY 1MODE" (C34).
- 3. Press the ENTER/YES "R" button to display "CPLAY 1MID".
- 4. Press the MENU/NO "R" button when "C = 0000 AD = 00" is displayed.
- Press the (A "R") or (B "R") button to display "FBIAS CHECK" (C16).

- 6. Press the ENTER/YES "R" button to display "0000/00c = 00".
 - The first four digits indicate the C1 error rate, the two digits after [/] indicate ADER, and the 2 digits after [c =] indicate the focus bias value.
 - Check that the C1 error is below 20 and ADER is below 2.
- 7. Press the ENTER/YES "R" button to display "UUUU U b = UU".
 - Check that the C1 error is about 100 and ADER is below 2.
- 8. Press the ENTER/YES "R" button to display "UUUU/U U a =
 - Check that the C1 error is about 100 and ADER is below 2.
- Press the MENU/NO "R" button, then press the MD button and take out the test disc.

6-8. C PLAY Check

MO Error Rate Check

Procedure:

- 1. Load the test disc (MDW-74/GA-1).
- Press the ("R") or F" button to display "CPLAY 1MODE" (C34).
- 3. Press the ENTER/YES "R" button to display "CPLAY 1MID".
- 4. The display changes to " $C = \emptyset \emptyset \emptyset \emptyset AD = \emptyset \emptyset$ ".
- 5. If the C1 error rate is below 20, check that ADER is 00.
- Press the MENU/NO "R" button to stop playback, then press the MD
 button and take out the test disc.

CD Error Rate Check

Procedure:

- 1. Load the check disc (TDYS-1).
- Press the ("R") or ("PLAY 1MODE" (C34).
- 3. Press the ENTER/YES "R" button to display "CPLAY 1MID".
- 4. The display changes to " $C = \emptyset \emptyset \emptyset \emptyset AD = \emptyset \emptyset$ ".
- 5. Check that the C1 error rate is below 20.
- Press the MENU/NO "R" button to stop playback, then press the MD button and take out the check disc.

6-9. Self-Recording/playback Check

Prepare a continuous recording disc using the unit to be repaired and check the error rate.

Procedure:

- 1. Load a recordable disc (blank disc).
- 3. Press the ENTER/YES "R" button to display "CREC 1MID".
- When recording starts, "REC" and display "CREC 1 @@@@" (@@@@ is the address).
- About 1 minute later, press the MENU/NO "R" button to stop continuous recording.
- Press the (Rⁿ) or (Rⁿ) button to display "CPLAY 1 MODE" (C34).
- Press the ENTER/YES "R" button to display "CPLAY 1 MID".
- 8. " $C = \mathbb{U} \mathbb{U} \mathbb{U} AD = \mathbb{U} \mathbb{U}$ " will be displayed.
- Check that the C1 error becomes below 20 and the AD error below 2.
- 10. Press the MENU/NO "R" button to stop playback, then press the MD ♠ button and take out the disc.

7. INITIAL SETTING OF ADJUSTMENT VALUE

Note:

Mode which sets the adjustment results recorded in the non-volatile memory to the initial setting value. However the results of the temperature compensation offset adjustment will not change to the initial setting value.

If initial setting is performed, perform all adjustments again excluding the temperature compensation offset adjustment.

For details of the initial setting, refer to "4. Precautions for Adjustments" (See page 36) and execute the initial setting before the adjustment as required.

Procedure:

- Press the (R") or (R") button to display "ADJ CLEAR" (C28).
- Press the ENTER/YES "R" button. "Complete!" will be displayed momentarily and initial setting will be executed, after which "ADJ CLEAR" (C28) will be displayed.

8. RECORDING AND DISPLAYING THE IOP INFORMATION

The IOP data can be recorded in the non-volatile memory. The IOP value on the optical pick-up label and the IOP value after the adjustment will be recorded. Recording these data eliminates the need to read the label on the optical pick-up.

Recording Procedure:

- 1. Press the ◄◄ "R" or ▶▶ "R" button to display "Iop Write" (C05), and press the ENTER/YES "R" button.
- 2. The display becomes "Ref=@@@.@" (@ is an arbitrary number) and the numbers which can be changed will blink.
- 3. Input the IOP value on the optical pick-up label.

 To select the number: Press the ◄ "R" or ►► "R" button.

 To select the digit: Press two buttons of VOL and CD ▲ simultaneously.
- 4. When the ENTER/YES "R" button is pressed, the display becomes "Measu=@@@.@" (@ is an arbitrary number).
- 5. As the adjustment results are recorded for the step 4 value. Leave it as it is and press the ENTER/YES "R" button.
- "Complete!" will be displayed momentarily. The value will be recorded in the non-volatile memory and the display will become "Iop Write" (C05).

Display Procedure:

- Press the (R") or Press the (R") button to display "Iop Read" (C26) and press the (ENTER/YES "R") button.
- "@@.@/##.#" is displayed and the recorded contents are displayed.
 - @@.@ indicates the IOP value on the optical pick-up label. ##.# indicates the IOP value after adjustment
- To end, press the MENU/NO "R" button to display "Iop Read" (C26).

9. TEMPERATURE COMPENSATION OFFSET ADJUSTMENT

Save the temperature data at that time in the non-volatile memory as $25\,^{\circ}\mathrm{C}$ reference data.

Note:

- 1. Usually, do not perform this adjustment.
- 2. Perform this adjustment in an ambient temperature of 22 °C to 28 °C. Perform it immediately after the power is turned on when the internal temperature of the unit is the same as the ambient temperature of 22 °C to 28 °C.
- 3. When D101 has been replaced, perform this adjustment after the temperature of this part has become the ambient temperature.

Procedure:

- 1. Press the ◄ "R" or ► button to display "TEMP ADJUST" (C03).
- Press the ENTER/YES "R" button to select the "TEMP ADJUST" mode.
- "TEMP = □ □ [OK]" and the current temperature data will be displayed.
- 4. To save the data, press the ENTER/YES "R" button.
 When not saving the data, press the MENU/NO "R" button.
- 5. When the ENTER/YES "R" button is pressed, "TEMP = UU SAVE" will be displayed and turned back to "TEMP ADJUST" (C03) display then. When the MENU/NO "R" button is pressed, "TEMP ADJUST" (C03) will be displayed immediately.

Specified Value:

The "TEMP = 0 0" should be within "E0 - EF", "F0 - FF", "00 - 0F", "10 - 1F" and "20 - 2F".

10.LASER POWER ADJUSTMENT

Before starting adjustment;

The laser power adjustment value changes depending upon the types of the optical pick-up (KMS-260B or KMS-260E).

Check the type of the optical pick-up before starting adjustment. (See the illustrations "The method of identifying the optical pick-up on page 41.)

Check the IOP value of the optical pick-up before adjustments. (Refer to 8. Recording and Displaying the Iop Information)

Procedure:

- Press the ("R") or ("R") button to display "LDPWR ADJUST" (C04).
 - (Laser power : For adjustment)
- 3. Press the ENTER/YES "R" button once to display "LD 0.9 mW
- Press the **In" or ** or "F" button until the laser power meter reading matches with the specified value as described in the following table.

CDECIFIED VALUE	KMS-260B	0.85 to 0.91 mW
SPECIFIED VALUE	KMS-260E	0.90 to 0.96 mW

Press the ENTER/YES "R" button after setting the range knob of the laser power meter, and save the adjustment results. ("LD SAVE \$ 00" will be displayed for a moment)

5. Then "LD 7.0 mW \$ 00" will be displayed.

6. Press the *\(\begin{align*} \text{"R"} \) or *\(\begin{align*} \text{"R"} \) button so that the reading of the laser power meter becomes the specified value, press the *\(\begin{align*} \text{ENTER/YES "R"} \) button to save it.

SPECIFIED VALUE	KMS-260B	6.9 to 7.1 mW
	KMS-260E	7.2 to 7.3 mW

Note: Do not perform the emission with 8.4 mW more than 15 seconds continuously.

- Then, press the (R") or I'R" button to display "LDPWR CHECK" (C13).
- 8. Press the ENTER/YES "R" button once to display "LD 0.9mW\$ 0 0". Check that the reading of the laser power meter matches with the specified value as described in the following table.

SPECIFIED VALUE	KMS-260B	0.85 to 0.91 mW
	KMS-260E	0.90 to 0.96 mW

9. Press the ENTER/YES "R" button once more to display "LD 8.4mW\$ "". Check that the reading the laser power meter and digital voltmeter satisfy the specified value.

Note down the digital voltmeter reading value.


Specified Value:

Laser power meter reading:

ODEOUEIED VALUE	KMS-260B	7.0 to 0.2 mW
SPECIFIED VALUE	KMS-260E	7.25 to 0.25 mW

Digital voltmeter reading: Value on the optical pick-up label ±10%

(Optical pick-up label)



IOP = 57.6 mA in this case $IOP \text{ (mA)} = \text{Digital voltmeter reading (mV)/1 (Ω)}$

- 10. Press the MENU/NO "R" button to display "LDPWR CHECK" (C13) and stop the laser emission.
 - (The MENU/NO "R" button is effective at all times to stop the laser emission)
- 11. Press the [◄◄ "R"] or ▶▶ "R"] button to display "Iop Write" (C05).
- 12. Press the <code>ENTER/YES "R"</code> button. When the display becomes "Ref=@@@.@" (@ is an arbitrary number), press the <code>ENTER/YES "R"</code> button to display "Measu=@@@.@" (@ is an arbitrary number).
- 13. The numbers which can be changed will blink. Input the Iop value noted down at step 9.


To select the number: Press the "R" or "R" button.

To select the digit :Press two buttons of VOL - and CD \(\text{CD} \) simultaneously.

14. When the ENTER/YES "R" button is pressed, "Complete!" will be displayed momentarily. The value will be recorded in the nonvolatile memory and the display will become "Iop Write" (C05).

Note: After step 9, each time the ENTER/YES "R" button is pressed, the display will be switched to "LD 0.7mW\$ [] []", "LD 6.2mW\$ [] []" and "LD WP [] [] []" Nothing needs to be performed here.

The method of identifying the optical pick-up (KMS-260B/260E)



11.lop NV SAVE

Write the reference values in the nonvolatile memory to perform "Iop compare". As this involves rewriting the reference values, do not perform this procedure except when adjusting the laser power during replacement of the optical pick-up and when replacing the IC102. Otherwise the optical pick-up check may deteriorate.

Note: Perform this function with the optical pick-up set at room temperature.

Procedure:

- Press the (C06).
 Press the (R") or FR" button to display "Iop NV Save"
- 2. Press the ENTER/YES "R" button and display "Iop [stop]".
- 3. After the display changes to "Iop =xxsave?", press the ENTER/YES "R" button.
- 4. After "Complete!" is displayed momentarily, the display changes to "Iop 7.0 mW".
- After the display changes to "Iop=yysave?", press the ENTER/YES "R" button.
- When "Complete!" is displayed, it means that Iop NV saving has been completed.

12. TRAVERSE ADJUSTMENT

Note 1: Data will be erased during MO reading if a recorded disc is used in this adjustment.

Note 2: If the traverse waveform is not clear, connect the oscilloscope as shown in the following figure so that it can be seen more clearly.


Oscilloscope
(DC range)

BD (MD) board

CN105 pin (3) (TE)

CN105 pin (6) (VC)

Connection:




Procedure:

- Connect an oscilloscope to CN105 pin (4) (TE) and CN105 pin
 (VC) on the BD (MD) board.
- 2. Load a disc (any available on the market). (Refer to Note 1)
- 3. Press the **R" button to move the optical pick-up outside the pit.
- 4. Press the ◄ "R" or ► "R" button to display "EF MO ADJUST" (C07).
- Press the ENTER/YES "R" button to display "EFB = 0 0 MO-R". (Laser power READ power/Focus servo ON/tracking servo OFF/spindle (S) servo ON)
- 6. Press the ◄ "R" or ► "R" button so that the waveform of the oscilloscope becomes the specified value.

(When the [♣♣ "R"] or [▶♠ "R"] button is pressed, the □ □ of "EFB=□□" changes and the waveform changes) In this adjustment, waveform varies at intervals of approx. 2%. Adjust the waveform so that the specified value is satisfied as much as possible. (Read power traverse adjustment)

Traverse Waveform




Specification A = B

- 7. Press the ENTER/YES "R" button and save the result of adjustment to the non-volatile memory ("EFB = 0 0 SAVE" will be displayed for a moment. Then "EFB = 0 0 MO-W" will be displayed).
- 8. Press the **IT* or **D** "R" button so that the waveform of the oscilloscope becomes the specified value.

(When the ◄ "R" or ► "ER" button is pressed, the □□ of "EFB= □□" changes and the waveform changes) In this adjustment, waveform varies at intervals of approx. 2%. Adjust the waveform so that the specified value is satisfied as much as possible. (Write power traverse adjustment)

Traverse Waveform



Specification A = B


- 9. Press the ENTER/YES "R" button, and save the adjustment results in the non-volatile memory. ("EFB = 0 0 SAVE" will be displayed for a moment)
- 10. "EFB = □ □ MO-P" will be displayed.

The optical pick-up moves to the pit area automatically and servo is imposed.

11. Press the ◄◄ "R" or ▶▶ "R" button until the waveform of the oscilloscope moves closer to the specified value.

In this adjustment, waveform varies at intervals of approx. 2%. Adjust the waveform so that the specified value is satisfied as much as possible.

Traverse Waveform




Specification A = B

- 12. Press the ENTER/YES "R" button, and save the adjustment results in the non-volatile memory. ("EFB = 0 SAVE" will be displayed for a moment)
 - Next "EF MO ADJUST" (C07) is displayed. The disc stops rotating automatically.
- 13. Press the MD \(\bigstar button and take out the disc.
- 14. Load the check disc (TDYS-1).
- 15. Press the ◄ "R" or ► "R" button to display "EF CD ADJUST" (C08).
- 16. Press the ENTER/YES "R" button to display "EFB = 00 CD". Servo is imposed automatically.
- 17. Press the *\(\mathbb{H}\) "R" button so that the waveform of the oscilloscope moves closer to the specified value.

 In this adjustment, waveform varies at intervals of approx. 2%. Adjust the waveform so that the specified value is satisfied as much as possible.

Traverse Waveform



Specification A = B

18. Press the ENTER/YES "R" button, display "EFB = UUSAVE" for a moment and save the adjustment results in the non-volatile memory.

Next "EF CD ADJUST" (C08) will be displayed.

19. Press the MD ♠ button and take out the check disc.

Adjustment Location: BD (MD) board (see page 44)

13. FOCUS BIAS ADJUSTMENT

Procedure:


- 1. Load the continuously-recorded disc. (Refer to "5. USING THE CONTINUOUSLY RECORDED DISC" (See page 37))
- Press the ("R") or P button to display "CPLAY 1 MODE" (C34).
- 3. Press the ENTER/YES "R" button to display "CPLAY 1MID".
- 4. Press the MENU/NO "R" button when "C = 0 0 0 0 = 0 0" is displayed.
- Press the ◄ "R" or ►► "R" button to display "FBIAS ADJUST" (C09).
- 6. Press the ENTER/YES "R" button to display "UUUU a = UUU T"

The first four digits indicate the C1 error rate, the two digits after "/" indicate ADER, and the 2 digits after "a =" indicate the focus bias value.

- 7. Press the T" button and find the focus bias value at which the C1 error rate becomes about 220 (refer to Note 2).
- 8. Press the ENTER/YES "R" button to display "UUUU/UUb = UUT".
- Press the [◄◄ "R"] button and find the focus bias value at which the C1 error rate becomes about 220.
- 10. Press the ENTER/YES "R" button to display "0000/00 c = 00 T".
- 11. Check that the C1 error rate is below 20 and ADER is 00. Then press the ENTER/YES "R" button.
- 12. If the "(\Box \Box)" in " \Box \Box \Box \Box \Box \Box (\Box \Box)" is above 20, press the ENTER/YES "R" button.

If below 20, press the MENU/NO "R" button and repeat the adjustment from step 2.

- 13. Press thet MD \(\bigstar button and take out the disc.
- **Note 1:** The relation between the C1 error and focus bias is as shown in the following figure. Find points A and B in the following figure using the above adjustment. The focal point position C is automatically calculated from points A and B.
- **Note 2:** As the C1 error rate changes, perform the adjustment using the average value.



14. ERROR RATE CHECK

14-1. CD Error Rate Check

Procedure:

- 1. Load the check disc (TDYS-1).
- Press the (R") or F" button and display "CPLAY 1 MODE" (C34).
- Press the ENTER/YES "R" button and display "CPLAY 1 MID".
- 4. The display changes to " $C = \emptyset \emptyset \emptyset \emptyset AD = \emptyset \emptyset$ ".
- 5. Check that the C1 error rate is below 20.
- 6. Press the MENU/NO "R" button to stop playback, then press the MD ♠ button and take out the check disc.

14-2. MO Error Rate Check

Procedure:

- Load the continuously-recorded disc. (Refer to "5. USING THE CONTINUOUSLY RECORDED DISC" (See page 37))
- Press the ("R") or F button to display "CPLAY 1 MODE" (C34).
- 3. Press the ENTER/YES "R" button to display "CPLAY 1MID".
- 4. The display changes to "C1 = 0.000 AD = 0.00".
- 5. If the C1 error rate is below 20, check that ADER is 00.
- 6. Press the MENU/NO "R" button to stop playback, then press the MD ♠ button and take out the disc.

15. FOCUS BIAS CHECK

Change the focus bias and check the focus tolerance amount.

Procedure:

- Load the continuously-recorded disc. (Refer to "5. USING THE CONTINUOUSLY RECORDED DISC" (See page 37))
- Press the ("R") or F button to display "CPLAY 1 MODE" (C34).
- Press the ENTER/YES "R" button twice to display "CPLAY 1 MID".
- Press the MENU/NO "R" button when "C1 = □ □ □ □ AD = □
 □ " is displayed.
- 5. Press the [44 "R"] or [54] button to display "FBIAS CHECK" (C16).
- 6. Press the ENTER/YES "R" button to display "UUU c =

The first four digits indicate the C1 error rate, the two digits after "/" indicate ADER, and the 2 digits after "c =" indicate the focus bias value.

Check that the C1 error is below 20 and ADER is below 2.

- 7. Press the ENTER/YES "R" button and display "UUUU b = UU".
 - Check that the C1 error is about 100 and ADER is below 2.
- 8. Press the ENTER/YES "R" button and display "UUUU a = UU".
 - Check that the C1 error is about 100 and ADER is below 2
- 9. Press the MENU/NO "R" button, then press the MD ▲ button and take out the disc.

Note: If the C1 error and ADER are above other than the specified value at points a (step 8. in the above) or b (step 7. in the above), the focus bias adjustment may not have been carried out properly. Adjust from the beginning again.

16. AUTO GAIN CONTROL OUTPUT LEVEL ADJUSTMENT

Be sure to perform this adjustment when the optical pick-up is replaced.

If the adjustment results becomes "Adjust NG!", the optical pick-up may be faulty or the servo system circuits may be abnormal.

16-1. CD Auto Gain Control Output Level Adjustment

Procedure:

- 1. Load the check disc (TDYS-1).
- 2. Press the **Add "R"** or **DD DD "R"** button to display "AG Set (CD)" (C11).
- 3. When the ENTER/YES "R" button is pressed, the adjustment will be performed automatically. "Complete!" will then be displayed momentarily when the value is recorded in the non-volatile memory, after which the display changes to "AG Set (CD)" (C11).
- 4. Press the MD ♠ button and take out the check disc.

16-2. MO Auto Gain Control Output Level Adjustment

Procedure:


- 1. Load the test disc (MDW-74/GA-1).
- 2. Press the ** "R" or ** button to display "AG Set (MO)" (C10).
- 3. When the ENTER/YES "R" button is pressed, the adjustment will be performed automatically. "Complete!" will then be displayed momentarily when the value is recorded in the non-volatile memory, after which the display changes to "AG Set (MO)" (C10).

Adjustment and checking Loacation:

- BD (MD) BOARD (Component Side) -

D101 CN101

- BD (MD) BOARD (Conductor Side) -



Note: It is useful to use the jig for checking the waveform. (Refer to Servicing Notes on page 6)

SECTION 6 DIAGRAMS

6-1. NOTE FOR PRINTED WIRING BOARDS AND SCHEMATIC DIAGRAMS (In addition to this, the necessary note is printed in each block)

Note on Printed Wiring Boards:


- • : parts extracted from the component side.
- O : Through hole.
- : parts extracted from the conductor side.
- : Pattern from the side which enables seeing

Caution:

Pattern face side: Parts on the pattern face side seen from (Conductor B) the pattern face are indicated. Parts face side: Parts on the parts face side seen from (Component A) the parts face are indicated.

(The other layers' patterns are not indicated.)

· Indication of transistor.



Abbreviation

AUS : Australian model HK : Hong Kong model KR : Korean model

Note on Schematic Diagram:

- All capacitors are in μF unless otherwise noted. pF: μμF 50 WV or less are not indicated except for electrolytics and tantalums.
- All resistors are in Ω and $^{1}\!/_{\!4}\,W$ or less unless otherwise specified.
- fusible resistor.
- _____ : panel designation.
- : B+ Line.

• === : B- Line.

Note: The components identified by mark \triangle or dotted line with mark \triangle are critical for safety. Replace only with part number specified.

- Voltages are taken with a VOM (Input impedance 10 $M\Omega$). Voltage variations may be noted due to normal production tolerances.
- · Waveforms are taken with a oscilloscope. Voltage variations may be noted due to normal production tolerances.
- · Circled numbers refer to waveforms.

· Signal path.

 \Rightarrow : FM


: CD (ANALOG) : CD (DIGITAL)

: CD (DIGITAL DESCRIPTION : PB (MD) : REC (MD)

: DIGITAL ÍN (OPTICAL)


: PB (TAPE) : REC (TAPE)


• Waveforms






· Circuit Boards Location







45




6-3. BLOCK DIAGRAM - MD SERVO SECTION -





6-4. BLOCK DIAGRAM - MAIN SECTION -





6-6. SCHEMATIC DIAGRAM – CD SECTION – • See page 45 for Wavefoms. • See page 64 for IC Pin Function Description.





Semiconductor Location Side A

Side A		
Ref. No.	Location	
D101	A-1	
Q101	B-1	
Q131	B-1	
Q132	B-1	
Q133	B-1	
Q134	B-1	

Semiconductor Location Side B


Ref. No.	Location
D181	D-3
D183	D-3
IC101 IC102 IC141 IC151 IC153 IC181 IC190 IC195	A-3 B-3 C-1 C-2 C-3 D-3 D-1
Q121 Q122 Q181 Q182	B-3 B-3 C-3 D-3


(22)


1-677-920-

51

6-8. SCHEMATIC DIAGRAM – BD (MD) BOARD (1/2) – • See page 45 for Wavefoms. • See page 65 for IC Block Diagrams. • See page 68 for IC Pin Function Description.








• Semiconductor Location

-ocation		
Ref. No.	Location	
0211	A-3	
C201 C211 C701 C861 C871	B-1 B-2 D-2 D-5 D-5	
0201 0202 0211 0861 0871 0872	D-7 C-7 A-2 D-5 D-3 C-3	




IC222 D221 C-9 A-1 D222 B-9 IC501 D-6 D232 D-1 IC941 D-5 B-9 D513 D910 D-3 Q202 D-4 [UCOM BOARÐ] B-3 B-3 C-3 C-3 D923 Q211 D924 Q212 005 D925 D-4 Q221 B-9 D926 D-4 Q222 C-9 D927 D-4 Q223 C-9 0 **IC221** D-4 Q224 B-9 D941 DIGITAL OPTICAL INPUT D942 Q232 D-2 0 D943 D-5 Q911 B-4 0 B-4 0 Q912 C-3 0 2 IC212 Q941 D-4 0 0 0 H AUÐ 10 BOARÐ CN101 (Page 58) (PO) 0 CN207 PC LINK 0 FB213050 FB214050 0 L TO PANEL BOARÐ CN601 JW270 JW271 JW272 SPEAKERS (Page 60) JW273 ⊚ R 0 % 00 0 N 00 0 0 0 12 (12) -681-376-3 5 7 8 9 6 CN852 (Page 62)

• Semiconductor Location

Ref. No. | Location | Ref. No.


Location







• Semiconductor Location


Ref. No.	Location	Ref. No.	Location
D101	B-6	Q101	B-6
D111	D-5	Q102	B-6
D301	C-4	Q103	A-7
D103	B-6	Q151	C-6
D343	B-5	Q311	C-1
D393	B-5	Q331	B-3
		Q361	B-3
IC301	B-2	Q381	B-3
IC302	B-4		















(11)

Q971 Q991


E-3






6-20. IC BLOCK DIAGRAMS


IC301 M62428AFP600C (AUDIO BOARD)




IC102 BA5982FP-E2 (BD (CD) BOARD)




IC101 CXD3068Q (BD (CD) BOARD)




IC103 CXA2581N-T4 (BD (CD) BOARD)




IC1102 BA6956AN (BD (CD) BOARD)
IC871 BA6956AN (MD DIGITAL BOARD)




IC201 μDA1360TS (MD DIGITAL BOARD)




IC141 BH6519FS-E2 (BD (MD) BOARD)



IC211 μDA1350AH (MD DIGITAL BOARD)



IC861 M62016L (MD DIGITAL BOARD)



DIG11 DIGITAL OUTPUT 64 DIG12 61 DIG15 DIGO CIRCUIT RES (13) INDICATION CS (14) SERIAL CONTROLLER CLK (15) **RECEIVE** CIRCUIT DATA (16) INDICATION CONTROL CODE SELECT OUTPUT P1 (17) **PORT** RESISTOR (2BIT) P0 (18) Vcc1 (19) CODE/COMMAND CONTROL CLOCK XOUT (20) **GENERATOR** XIN (21) **CIRCUIT** CIRCUIT Vss (22) RAM WRITE CODE WRITE (35BIT x 16) (35BIT x 16) DECODER DECODER INDICATION CODE RESISTOR (8BIT x 16) 60 VCC2

IC601 M66004M8FP-200D (PANEL BOARD)


IC212 BA8274F-E2 (UCOM BOARD)

SEGMENT OUTPUT CIRCUIT

SEG35 23

SEG27 31 VP 32 59 SEG0

33 SEG26



6-21. IC PIN FUNCTION DESCRIPTION

• IC101 CXA2523AR (RF AMP, FOCUS/TRACKING ERROR AMP) (BD (MD) BOARD)

Pin No.	Pin Name	I/O	Description
1	I	I	I-V converted RF signal I input from the optical pick-up block detector
2	J	I	I-V converted RF signal J input from the optical pick-up block detector
3	VC	0	Middle point voltage (+1.65V) generation output terminal
4 to 9	A to F	I	Signal input from the optical pick-up detector
10	PD	I	Light amount monitor input from the optical pick-up block laser diode
11	APC	_	Laser amplifier output terminal to the automatic power control circuit
12	APCREF	I O	Reference voltage input for setting laser power from the CXD2662R (IC151) Ground terminal
13	GND		
14	TEMPI	I	Connected to the temperature sensor
15	TEMPR	I	Output terminal for a temperature sensor reference voltage
16	SWDT	I	Writing serial data input from the CXD2662R (IC151)
17	SCLK	I	Serial data transfer clock signal input from the CXD2662R (IC151)
18	XLAT	I	Serial data latch pulse signal input from the CXD2662R (IC151)
19	XSTBY	О	Standby signal input terminal "L": standby (fixed at "H" in this set)
20	F0CNT	I	Center frequency control voltage input terminal of internal circuit (BPF22, BPF3T, EQ) input
			from the CXD2662R (IC151)
21	VREF	0	Reference voltage output terminal Not used (open)
22	EQADJ	I	Center frequency setting terminal for the internal circuit (EQ)
23	3TADJ	I	Center frequency setting terminal for the internal circuit (BPF3T)
24	VCC	_	Power supply terminal (+3.3V)
25	WBLADJ	I	Center frequency setting terminal for the internal circuit (BPF22)
26	TE	О	Tracking error signal output to the CXD2662R (IC151)
27	CSLED	I	Connected to the external capacitor for low-pass filter of the sled error signal
28	SE	О	Sled error signal output to the CXD2662R (IC151)
29	ADFM	О	FM signal output of the ADIP
30	ADIN	I	Receives a ADIP FM signal in AC coupling
31	ADAGC	I	Connected to the external capacitor for ADIP AGC
32	ADFG	0	ADIP duplex signal (22.05 kHz ± 1 kHz) output to the CXD2662R (IC151)
33	AUX	0	Auxiliary signal (I3 signal/temperature signal) output to the CXD2662R (IC151)
34	FE	0	Focus error signal output to the CXD2662R (IC151)
35	ABCD	0	Light amount signal (ABCD) output to the CXD2662R (IC151)
36	BOTM	0	Light amount signal (RF/ABCD) bottom hold output to the CXD2662R (IC151)
37	PEAK	О	Light amount signal (RF/ABCD) peak hold output to the CXD2662R (IC151)
38	RF	О	Playback EFM RF signal output to the CXD2662R (IC151)
39	RFAGC	I	Connected to the external capacitor for RF auto gain control circuit
40	AGCI	I	Receives a RF signal in AC coupling
41	COMPO	О	User comparator output terminal Not used (open)
42	COMPP	I	User comparator input terminal Not used (fixed at "L")
43	ADDC	I	Connected to the external capacitor for cutting the low band of the ADIP amplifier
44	OPO	О	User operational amplifier output terminal Not used (open)
45	OPN	I	User operational amplifier inversion input terminal Not used (fixed at "L")
46	RFO	О	RF signal output terminal
47	MORFI	I	Receives a MO RF signal in AC coupling
48	MORFO	О	MO RF signal output terminal
	-	ı	

• IC151 CXD2662R (DIGITAL SIGNAL PROCESSOR, EFM/ACIRC ENCODER/DECODER, SHOCK PROOF MEMORY CONTROLLER, ATRAC ENCODER/DECODER) (BD (MD) BOARD)

	Dia Mara		
Pin No.	Pin Name	I/O	Description
1	MNT0 (FOK)	О	Focus OK signal output terminal "H" is output when focus is on ("L": NG) Not used (open)
2	MNT1 (SHCK)	О	Track jump detection signal output to the MD mechanism controller (IC1001)
3	MNT2 (XBUSY)	О	Busy monitor signal output to the MD mechanism controller (IC1001)
4	MNT3 (SLOC)	0	Spindle servo lock status monitor signal output to the MD mechanism controller (IC1001) (open)
5	SWDT	I	Writing serial data signal input from the MD mechanism controller (IC1001)
6	SCLK	I(S)	Serial data transfer clock signal input from the MD mechanism controller (IC1001)
7	XLAT	I(S)	Serial data latch pulse signal input from the MD mechanism controller (IC1001)
8	SRDT	O (3)	Reading serial data signal output to the MD mechanism controller (IC1001)
9	SENS	O (3)	Internal status (SENSE) output to the MD mechanism controller (IC1001)
10	XRST	I(S)	Reset signal input from the MD mechanism controller (IC1001) "L": reset
1.1	COCV		Subcode Q sync (SCOR) output to the MD mechanism controller (IC1001)
11	SQSY	О	"L" is output every 13.3 msec Almost all, "H" is output
1.0	5007		Digital In U-bit CD format subcode Q sync (SCOR) output to the MD mechanism controller
12	DQSY	О	(IC1001) "L" is output every 13.3 msec Almost all, "H" is output
			Laser power selection signal input from the MD mechanism controller (IC1001)
13	RECP	I	"L": playback mode, "H": recording mode
14	XINT	0	Interrupt status output to the MD mechanism controller (IC1001)
15	TX	0	Magnetic head on/off signal output to the over write head drive (IC181)
16	OSCI	I	System clock signal (90.3168 MHz) input terminal
17	OSCO	0	System clock signal (512Fs=90.3168 MHz) output terminal Not used (open)
1,	OSCO		Input terminal for the system clock frequency setting
18	XTSL	I	"L": 45.1584 MHz, "H": 90.3168 MHz (fixed at "H" in this set)
19	DIN0	I	Digital audio signal input terminal when recording mode Not used
20	DIN1	I	Digital audio signal input terminal when recording mode Not used
21			
	DOUT	0	Digital audio signal output terminal when playback mode
22	DATI	I	Recording data input from the A/D converter (IC1005)
23	LRCKI	I	L/R sampling clock signal (44.1 kHz) input from the D/A converter (IC1006), A/D converter
2.4	TAD CITA	-	(IC1005)
24	XBCKI	I	Bit clock signal (2.8224 MHz) input from the D/A converter (IC1006), A/D converter (IC1005)
25	ADDT	I	Recording data input terminal Not used (fixed at "L")
26	DADT	О	Playback data output terminal Not used (open)
27	LRCK	0	L/R sampling clock signal (44.1 kHz) output terminal Not used (open)
28	XBCK	0	Bit clock signal (2.8224 MHz) output terminal Not used (open)
29	FS256	О	Clock signal (11.2896 MHz) output terminal Not used (open)
30	DVDD		Power supply terminal (+3.3V) (digital system)
31 to 34	A03 to A00	О	Address signal output to the D-RAM (IC152)
35	A10	О	Address signal output to the D-RAM (IC152) (open)
36 to 40	A04 to A08	О	Address signal output to the D-RAM (IC152)
41	A11	О	Address signal output to the external D-RAM Not used (open)
42	DVSS		Ground terminal (digital system)
43	XOE	О	Output enable signal output to the D-RAM (IC152) "L" active
44	XCAS	0	Column address strobe signal output to the D-RAM (IC152) "L" active
45	A09	О	Address signal output to the D-RAM (IC152)
46	XRAS	О	Row address strobe signal output to the D-RAM (IC152) "L" active
47	XWE	0	Write enable signal output to the D-RAM (IC152) "L" active
			for analog input O(3) for 3 state output, and O(A) for analog output in the column I/O

 $^{*\} I\ (S)\ stands\ for\ schmitt\ input,\ I\ (A)\ for\ analog\ input,\ O\ (3)\ for\ 3-state\ output,\ and\ O\ (A)\ for\ analog\ output\ in\ the\ column\ I/O.$

Pin No.	Pin Name	I/O	Description
48	D1	I/O	
49	D0	I/O	Two way data bus with the D. P.A.M. (IC152)
50	D2	I/O	Two-way data bus with the D-RAM (IC152)
51	D3	I/O	
52	MVCI	I(S)	Digital in PLL oscillation input from the external VCO Not used (fixed at "L")
53	ASYO	О	Playback EFM full-swing output terminal
54	ASYI	I(A)	Playback EFM asymmetry comparator voltage input terminal
55	AVDD	_	Power supply terminal (+3.3V) (analog system)
56	BIAS	I(A)	Playback EFM asymmetry circuit constant current input terminal
57	RFI	I(A)	Playback EFM RF signal input from the CXA2523AR (IC101)
58	AVSS	_	Ground terminal (analog system)
59	PCO	O (3)	Phase comparison output for master clock of the recording/playback EFM master PLL
60	FILI	I(A)	Filter input for master clock of the recording/playback master PLL
61	FILO	O (A)	Filter output for master clock of the recording/playback master PLL
62	CLTV	I (A)	Internal VCO control voltage input of the recording/playback master PLL
63	PEAK	I(A)	Light amount signal (RF/ABCD) peak hold input from the CXA2523AR (IC101)
64	BOTM	I (A)	Light amount signal (RF/ABCD) bottom hold input from the CXA2523AR (IC101)
65	ABCD	I (A)	Light amount signal (ABCD) input from the CXA2523AR (IC101)
66	FE	I (A)	Focus error signal input from the CXA2523AR (IC101)
67	AUX1	I (A)	Auxiliary signal (I3 signal/temperature signal) input from the CXA2523AR (IC101)
68	VC	I (A)	Middle point voltage (+1.65V) input from the CXA2523AR (IC101)
69	ADIO	O (A)	Monitor output of the A/D converter input signal Not used (open)
70	AVDD		Power supply terminal (+3.3V) (analog system)
71	ADRT	I (A)	A/D converter operational range upper limit voltage input terminal (fixed at "H" in this set)
72	ADRB	I (A)	A/D converter operational range lower limit voltage input terminal (fixed at "L" in this set)
73	AVSS		Ground terminal (analog system)
74	SE	I (A)	Sled error signal input from the CXA2523AR (IC101)
75	TE	I (A)	Tracking error signal input from the CXA2523AR (IC101)
76	DCHG	I (A)	Connected to the +3.3V power supply
77	TEST4	I	nput terminal for the test Not used (fixed at "H")
78	ADFG	I(S)	ADIP duplex FM signal (22.05 kHz ± 1 kHz) input from the CXA2523AR (IC101)
79	F0CNT	0	Filter f0 control signal output to the CXA2523AR (IC101)
80	XLRF	0	Serial data latch pulse signal output to the CXA2523AR (IC101)
81	CKRF	0	Serial data transfer clock signal output to the CXA2523AR (IC101)
82	DTRF	0	Writing serial data output to the CXA2523AR (IC101)
83	APCREF	0	Control signal output to the reference voltage generator circuit for the laser automatic power control
84	TEST0	0	Input terminal for the test Not used (open)
85	TRDR	0	Tracking servo drive PWM signal (–) output to the BH6511FS (IC141)
86	TFDR	0	Tracking servo drive PWM signal (+) output to the BH6511FS (IC141)
87	DVDD		Power supply terminal (+3.3V) (digital system)
88	FFDR	0	Focus servo drive PWM signal (+) output to the BH6511FS (IC141)
89	FRDR	0	Focus servo drive PWM signal (-) output to the BH6511FS (IC141)
90	FS4	0	Clock signal (176.4 kHz) output terminal (X'tal system) Not used (open)
91	SRDR	0	Sled servo drive PWM signal (–) output to the BH6511FS (IC141)
92	SFDR	0	Sled servo drive PWM signal (+) output to the BH6511FS (IC141)
93	SPRD	0	Spindle servo drive PWM signal (-) output to the BH6511FS (IC141)
73	SI KD		Spinule serve univer with signal (=) output to the Driostif's (IC141)

^{*} I (S) stands for schmitt input, I (A) for analog input, O (3) for 3-state output, and O (A) for analog output in the column I/O.

Pin No.	Pin Name	I/O	Description
94	SPFD	0	Spindle servo drive PWM signal (+) output to the BH6511FS (IC141)
95	FGIN	I(S)	Input terminal for the test (fixed at "L")
96	TEST1	I	
97	TEST2	I	
98	TEST3	I	
99	DVSS	_	Ground terminal (digital system)
100	EFMO	0	EFM signal output terminal when recording mode

^{*} I (S) stands for schmitt input, I (A) for analog input, O (3) for 3-state output, and O (A) for analog output in the column I/O.

• IC701 M30803MG-A03FP MASTER CONTROLLER (MD DIGITAL BOARD)

Pin No.	Pin Name	1/0	TER CONTROLLER (MD DIGITAL BOARD) Description
1	(FLDT)		Not used
2	(FLCK)		Not used
3	(LEVEL-L)		Not used
4	(LEVEL-R)		Not used
5 to 7	(EE VEE-IC)		Not used
8	BYTE		Data bus changed signal input (Connected to ground)
9	CNVSS		Processor mode selection terminal
10	XIN-T	I	Not used
11	+	I	Not used
12	XOUT-T S-RST		
13	<u> </u>	I	System reset input Main shock system (10MHz)
	XOUT		Main clock output (10MHz)
14	VSS	I	Ground
15	XIN	О	Main clock input (10MHz)
16	VCC	_	Power supply
17	NMI	I	Fixed at H (Pull-up)
18	DQSY		Digital in sync signal input (Record system)
19	P-DOWN	I	Power down detection signal input (L:Power down)
20	SQSY	I	ADIP (MO) sync signal or subcode Q (PIT) sync signal input from the CXD2662R
	-		(Playback system)
21	(KB-CLK)	I	Not used
22	(KB-DATA)	I	Not used
23	I2C-BUSY	_	I2C cable connect check signal output
24	(A1-OUT)	_	Not used
25	XINT	О	Interrupt status signal input from the CXD2662R
26	(BEEP)		Not used
27	(XELT)	I	Not used
28	(I2C-POWER)	—	Not used
29	I2C-CLK	_	I2C serial clock input/output
30	I2C-DAT	_	I2C serial data input/output
31	SWDT	I/O	Writing data signal output to the serial bus
32	SRDT	I/O	Reading data signal input from the serial bus
33	SCLK	О	Clock signal output to the serial bus
34	(KB-CLK-CTL)	I	Not used
35	(CLIP-TX0)	О	Not used
36	(CLIP-RX0)		Not used
37	(CLIP-CLK0)	_	Not used
38	(MUTE)	_	Not used
39	(ADA-RESET)	—	Not used
40	(ADA-LATCH)	_	Not used
41	EPM	_	Not used (Pull-down)
42	(CLIP-SEL)	_	Not used
43	_	_	Not used
44	PROTECT	I	Recording protection tab detection signal input from the protection detection switch (H:Protect)
45	EEP-CLK	О	Clock signal output to the EEP-ROM
46	CE	I	Fixed at H (Pull-up)
47	EEP-WP	0	Write protect signal output to the EEP ROM (L:Write enable)
	1		· · · · · · · · · · · · · · · · · · ·
48	XBUSY(MNT2)	I	Busy signal input from the CXD2662R

Pin No.	Pin Name	I/O	Description
50	XLATCH	О	Lacth signal output to the DSP IC
51	PLAY-SW	I	Detection signal input from the playback position detection switch (L:PLAY)
52	D-RESET	О	Digital reset signal output to the CXD2662R and the motor driver (L:Reset)
53	REC—SW	I	Detection signal input from the recording position detection switch (L:REC)
54	WRPWR	О	Write power ON/OFF signal output (L:OFF, H:ON)
55	LIMIT—IN	I	Detection signal input from the limit switch (L:Sled limit-in, H:Sled limit-out)
56	MOD	О	Modulation signal output to the laser diode (L:OFF, H:ON)
57	LDON	О	Laser ON/OFF control signal output (H:Laser ON)
58	SENS	I	SENS signal input from the CXD2662R
59	SHOCK(MNT1)	I	Track jump signal input from the CXD2662R
60	EEP—DATA	I/O	Data signal input/output terminal with the EEP-ROM
		_	Disc reflection rate detection input from the reflect detection switch
61	REFLECT	I	(H:Disc with low reflection rate)
62	VCC	_	Power supply (+3.3V)
63	_	_	Not used
64	VSS	_	Ground
65	LOAD—LO	0	Loading motor voltage control signal output (L:High voltage, H:Low voltage)
66	LOAD—OUT	О	Loading motor control signal output (H:Out)
67	LOAD—IN	0	Loading motor control signal output (H:In)
68	(MODEL0)		Not used
69	(MODEL1)		Not used
70	MODEL2	I	Model setting input terminal
71	MODEL3	I	Model setting input terminal
72	SPDIF—CUT	О	Power control signal output for the PLL power supply of the D/A converter
73 to 75	_	_	Not used
76	DAC—MUTE	0	Muting signal output to the D/A converter
77	LINE—MUTE	_	Not used
78	DA—RESET	О	Reset signal output to the D/A converter (L:Active)
79	SLICER—SEL	0	IEC958 input select signal output to the D/A converter
80	SPDIF—LOCK	I	LOCK signal input from the D/A converter
81	OPTSEL	О	Optical input selection signal output
82	ADPDWN	О	Power control signal output to the A/D converter
83 to 84	_		Not used
85	TP1	_	Not used
86	TP2		Not used
87	TP3		Not used
88	TP4		Not used
89	IOP	I	Optical pick-up voltage (current) detect signal input
90 to 95	_		Not used
96	AVSS		Ground (Analog)
97	<u> </u>	_	Not used
98	VREF	I	Reference voltage input terminal
99	AVCC		Power supply (Analog)
100			Not used

HCD-C5

• IC501 µPD703032AYGF-M01-3BA MASTER CONTROL (UCOM BOARD)

			BDA WASTER CONTROL (UCOW BOARD)
Pin No.	Pin Name	I/O	Description
1	FL-DATA	О	FL tube data signal output
2	FL-CLK	О	FL tube clock signal output
3	SDA	I/O	IIC data signal input or output
4	FL-CE	0	FL tube enable signal output
5	SCL	I/O	IIC clock signal input or output
6	FL-RST	О	FL tube reset signal output
7	CXD-DATA	О	Data signal output to DSP
8	CXD-CLK	О	Clock signal output to DSP
9	EVDD		Power supply for I/O port
10	EVSS		Ground for I/O port
11	CXD-XLT	О	Latch signal output to DSP
12	PWM1	О	PWM1 signal output
13	LDON	О	Laser power control signal output
14	SENSE	I	CD SENSE signal input
15	SUBQ	I	CD SUBQ signal input
16	CHECK	О	Not used (open)
17	SCLK	О	CD SUBQ clock signal output
18	CTRL1	О	CTRL1 (setting double speed) signal output
19	PWM2	О	PWM2 signal output
20	PWM3	О	PWM3 signal output
21	VPP	_	Not used
22	SP-MUTE	О	Not used (open)
23	1-4	О	Not used (open)
24	DMUTE	О	Muting signal output to DAC
25	AMUTE	О	Not used (open)
26	LODNEG	О	Loading motor control signal output
27	LODPOS	О	Loading motor control signal output
28	BDPWR	О	CD power control signal output
29	BDRST	О	CD reset signal output
30	SW1	I	Loading switch signal input
31	SW2	I	Loading switch signal input
32	SW3(ENC-A)	I	Loading switch signal input
33	SW4(ENC-B)	I	Loading switch signal input
34	RESET	I	Systen reset input
35	XT1	I	Sub clock input
36	XT2	_	Sub clock output
37	REGC	_	Terminal for regulator clock
38	X2	_	Main system clock output
39	X1	I	Main system clock input
40	VSS	_	Ground
41	VDD	_	Power supply
42	CLKOUT	0	Clock output (open)
43	PLL-CLK	0	Tuner clock signal output
44	PLL-DO(μCOM-ST)	0	Tuner data signal output
45	PLL-DI(ST-µCOM)	I	Tuner data signal input
46	PLL-CE	0	Tuner chip enable signal output
47	ST-MUTE	0	Tuner muting signal output
48	STEREO	I	Stereo tuning signal input
49	TUNED	I	TUNED detect signal input
		I	RDS data signal input
50	RDS-DATA	1	KD3 data signai input

Pin No.	Pin Name	I/O	Description
51	PROTECT	I	Not used (pull-up)
52	PRE-MUTE	0	Pre-amplifier muting signal output
53	PWR-MUTE	0	Not used (open)
	REC-MUTE		7. * - 7
54		0	REC output muting signal output
55	HP-MUTE	0	Not used (open)
56	SPK-RELAY	0	Speaker relay control signal output
57	HELP	I/O	IIC busy signal input or output
58	BVDD		Power supply for bus interface
59	BVSS	_	Ground for bus interface
60	KBD-CHK	I	PC LINK inserted detect signal input
61	KBD-DATA	I	Key board data input (pull-up)
62	VOL-CE	О	Volume latch signal output to the sound processor
63	VOL-CLK	0	Volume clock signal output to the sound processor
64	VOL-DATA	О	Volume data signal output to the sound processor
65	LED	0	LED control signal output
66	FAN-ON	О	Not used (open)
67	HP-IN	I	Headphone detect signal input (pull-down)
68	IO-RST	0	Not used (open)
69	PWR-RELAY	0	Power relay control signal output
70	MD-PWR	О	MD power control signal output
71	FL-ON	О	Not used (open)
72	ON/STANDBY	О	STANDBY LED control signal output
73	DIMMER	О	Not used (open)
74	AVDD	_	Analog power supply
75	AVSS	_	Analog ground
76	AVREF	_	Analog reference voltage
77	KEY1	I	Key input signal from function switch
78	KEY2	I	Key input signal from function switch
79	KEY3	I	Key input signal from function switch
80	ADJ	I	Adjust mode input (pull-up)
81	DEST1	I	Destination setting input
82	DEST2	I	Destination setting input
83	DEST3	I	Destination setting input
84	DEST4	I	Destination setting input
85	MODEL1	I	Model setting input
86	MODEL2	I	Model setting input
87	DEVICE1	I	Device setting input
88	DEVICE2	I	Device setting input
89	KBD-CLKO	0	Keyboard clock output (pull-up)
90	KBD-CLKI	I	Keyboard clock input (pull-up)
91	AC-CUT	I	AC off detect signal input
92	PCPON	I	PC power detect signal input for PC LINK
93	KEY-RM	I	Remote control receiver or power key detect signal input
94	SIRCS	I	Remote control receiver data signal input
95	SCOR	I	CD Q-data request signal input
96	RDS-CLK	I	RDS clock signal input
97	IO-DI	1	Not used (open)
98	IO-DI IO-DO	_	Not used (open)
98	IO-DO IO-CLK		
			Not used (open)
100	IO-CE		Not used (open)

SECTION 7 EXPLODED VIEWS

NOTE:


- -XX, -X mean standardized parts, so they may have some differences from the original one.
- Items marked "*" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- The mechanical parts with no reference number in the exploded views are not supplied.

 Hardware (# mark) list and accessories and packing materials are given in the last of this parts list.

Abbreviation


AUS : Australian model HK : Hong Kong model KR : Korean model The components identified by mark \triangle or dotted line with mark \triangle are critical for safety. Replace only with part number specified.

7-1. OVERALL SECTION



Ref. No.	Part No.	Description	<u>Remarks</u>	Ref. No.	Part No.	<u>Description</u>	<u>Remarks</u>
1	1-757-791-11	WIRE (FLAT TYPE) (16 CORE)		7	7-685-903-21	SCREW +PTPWH 3X8 (TYPE2)	
2	4-233-859-01	CASE		8	1-681-712-11	HP BOARD	
3	4-886-865-01	CUSHION (A)		9	4-233-862-11	COVER, REAR (AEP,UK,KR)	
4	A-4476-934-A	BD BOARD, COMPLETE		9	4-233-862-21	COVER, REAR (AUS,HK)	
5	4-235-553-01	SPACER (A)		10	1-681-381-11	JACK BOARD	
6	1-773-289-11	WIRE (FLAT TYPE) (29 CORE)		* 11	4-930-336-71	FOOT (FELT)	


7-2. FRONT PANEL SECTION



Ref. No.	Part No.	<u>Description</u>	<u>Remarks</u>	Ref. No.	Part No.	<u>Description</u>	<u>Remarks</u>
51	X-4953-691-1	PANEL ASSY (B), FRONT		55	4-233-840-01	PANEL, FRONT	
52	4-942-636-01	EMBLEM (NO.3.5), SONY		56	A-4476-936-A	PANEL BOARD, COMPLETE	
53	4-233-846-01	ESCUTCHEON (MD)		57	4-228-323-01	SPRING (MD)	
54	4-233-847-01	ESCUTCHEON (CD)		58	4-228-335-11	LID (MD)	


HCD-C5 Ver 1.1 2001.09

7-3. CHASSIS SECTION-1




Ref. No.	Part No.	<u>Description</u>	<u>Remarks</u>	Ref. No.	Part No.	<u>Description</u>	<u>Remarks</u>
101	A-4476-947-A	UCOM BOARD, COMPLETE (AEP,UK)		107	A-4727-414-A	POWER BOARD, COMPLETE (HK,KF	1)
101	A-4727-413-A	UCOM BOARD, COMPLETE (AUS, HK.	KR)	108	1-773-110-11	WIRE (FLAT TYPE) (19 CORE)	,
102	1-681-380-11	AMP POWER BOARD	,	109	A-4476-938-A	AUDIO BOARD, COMPLETE (AUS, HI	(,KR)
103	3-703-244-00	BUSHING (2104), CORD		109	A-4476-949-A	AUDIO BOARD, COMPLETE (AEP,UK)
104 △	1-696-847-11	CORD, POWER (AUS)		110	3-701-748-00	CLAMP	
△ 104	1-769-079-21	CORD, POWER (KR)		111	4-812-134-31	RIVET (DIA. 3.5), NYLON	
△104	1-777-071-21	CORD, POWER (AEP,UK,HK)		112	4-234-235-01	INSULATED PLATE (POWER)	
105	1-769-943-11	WIRE (FLAT TYPE) (11CORE) (AUS, H	K.KR)	113	4-937-971-01	CUSHION	
105	1-773-007-11	WIRE (FLAT TYPE) (15 CORE) (AEP,UI	()	114	4-237-035-01	INSULATED PLATE (POWER) 2	
106	1-693-529-11	TUNER PACK (FM/AM) (AEP,UK)	,	M901	1-698-997-11	FAN, D.C.	
106	1-693-531-11	TUNER PACK (FM/AM) (AUS,HK)		 ∆ T900	1-437-239-11	TRANSFORMER, POWER (AEP,UK,A	US)
106	1-693-536-11	TUNER PACK (FM/AM) (KR)		 ∆ T900	1-437-241-11	TRANSFORMER, POWER (HK,KR)	
107	A-4476-948-A	POWER BOARD, COMPLETE (AEP,UK,	AUS)				

7-4. CHASSIS SECTION-2




Ref. No.	Part No.	<u>Description</u>	<u>Remarks</u>	Ref. No.	Part No.	<u>Description</u>	<u>Remarks</u>
				155	A-4725-732-A	MD DIGITAL BOARD, COMPLETE	
151	4-231-555-01	INSULATOR		156	1-757-079-11	WIRE (FLAT TYPE) (17 CORE)	
152	4-228-643-21	SCREW (+BVTTWH M3), STEP		157	1-757-080-11	WIRE (FLAT TYPE) (27 CORE)	
154	1-773-138-11	WIRE (FLAT TYPE) (19 CORE)		158	4-231-113-01	SCREW (1.7X3), BTN	

7-5. CD MECHANISM DECK SECTION (TN-CCD1001Z)




Ref. No.	Part No.	Description	<u>Remarks</u>	Ref. No.	Part No.	<u>Description</u>	<u>Remarks</u>
401	4-236-062-01	PIN, DAMPER		406	1-682-100-11	CONNECTOR BOARD	
402	4-236-087-01	SPRING (FZ), HANG UP		407	4-236-105-01	HOLDER, FPC	
403	4-236-114-01	BELT, LOADING		408	1-682-101-11	PICK-UP FLEXIBLE BOARD	
404	4-236-088-01	SPRING (R), HANG UP		409	1-815-750-11	CONNECTOR	
405	4-236-101-01	DAMPER (J)		M902	X-4954-023-1	MOTOR ASSY, LOADING	

7-6. CD MECHANISM DECK SECTI – FRONT BRACKET SECTION (TN-CCD1001Z)




Ref. No.	Part No.	<u>Description</u>	<u>Remarks</u>	Ref. No.	Part No.	<u>Description</u>	<u>Remarks</u>
451	4-236-112-01	SPRING (R), LOADING PULLEY		457	4-236-118-01	WASHER (117)	
452	4-236-115-01	BRACKET (J), FRONT		458	4-236-116-01	WASHER (113)	
453	4-236-111-01	SPRING (L), LOADING PULLEY		459	4-236-110-01	ROLLER, LOADING	
454	4-236-106-01	BRACKET, GEAR MOUNT		460	X-4954-024-1	SHAFT ASSY, LOADING ROLLER	
455	4-236-108-01	GEAR (3), LOADING		461	4-236-117-01	WASHER, WAVE	
456	4-236-107-01	GEAR (2), LOADING		462	4-236-109-01	GEAR (5), LOADING	

7-7. CD MECHANISM DECK SECTION – BASE SECTION (TN-CCD1001Z)




Ref. No.	Part No.	Description	<u>Remarks</u>	Ref. No.	Part No.	Description	<u>Remarks</u>
501	X-4954-022-1	SCREW ASSY, FEED		512	4-236-102-01	SPRING (L), CLIP ARM	
502	4-236-104-01	SPRING, PULLEY GUIDE		513	4-236-098-01	STOPPER, 8CM	
 ∆ 503	1-758-631-11	OPTICAL PICK-UP BLOCK (OPTIMA-7	'20L1E)	514	4-236-096-01	SPRING, CLIP ARM	
504	4-236-092-01	GUIDE, PULLEY		515	4-236-103-01	GUIDE, SCREW	
505	4-236-094-01	PULLEY (M)		516	4-236-090-01	BASE, FM	
506	4-236-095-01	SPRING, DETENT		517	4-236-091-01	BRACKET, FD GEAR	
507	4-236-101-01	DAMPER (J)		518	4-236-093-01	SPRING, THRUST	
508	X-4954-025-1	BASE ASSY, TT		519	4-236-089-01	GEAR, PULLEY	
509	4-236-097-01	CLAMP		S5	1-786-212-11	SWITCH (DETECTION) (LIMIT IN)	
510	4-236-100-01	PLATE, CLAMP		M903	X-4954-020-1	MOTOR ASSY, FEED	
511	4-236-099-01	RETAINER, 8CM STOPPER		M904	X-4954-021-1	MOTOR ASSY, SPINDLE	

7-8. CD MECHANISM DECK SECTION – CHASSIS SECTION (TN-CCD1001Z)




Ref. No.	Part No.	<u>Description</u>	<u>Remarks</u>	Ref. No.	Part No.	<u>Description</u> <u>Remarks</u>
551	4-236-085-01	ARM, SLIDE		564	4-236-081-01	HOLDER (L)
552	4-236-086-01	SPRING, SLIDE ARM		565	4-236-079-01	ARM (L), HOLDER
553	4-236-073-01	ARM (R), S		566	4-236-077-01	SPRING, TRIGGER
554	4-236-074-01	SPRING, S ARM		567	4-236-076-01	TRIGGER (Z)
555	4-236-064-01	HOLDER, S ARM		568	4-236-078-01	ARM, TRIĞĞER
556	4-236-063-01	HOLDER, UPPER		569	4-236-075-01	LEVER, TRIGGER
557	4-236-113-01	ACTUATOR, SWITCH		S1	1-786-214-11	SWITCH (DETECTION)
558	1-682-099-11	SW BOARD				(Disc IN/8cm Disc detect)
559	4-236-065-01	ARM (L), S		S2	1-786-213-11	SWITCH (DETECTION)
560	4-236-080-01	ARM (R), HOLDER				(12cm Disc/12cm Disc Eject End detect)
				S3	1-786-213-11	SWITCH (DETECTION)
561	4-236-082-01	HOLDER (R)				(Disc Existence, Chucking, Releasing detect)
562	4-236-084-01	SPRING, LOADING GEAR		S4	1-786-214-11	SWITCH (DETECTION) (8cm Disc Eject detect)
563	4-236-083-01	GEAR (6), LOADING				

7-9. MD MECHANISM DECK SECTION-1 (MDM-7B4M)



Ref. No.	Part No.	Description	<u>Remarks</u>	Ref. No.	Part No.	Description	<u>Remarks</u>
* 701	4-996-267-01	BASE (BU-D)		713	4-226-995-01	SLIDER (EJ)	
702	4-231-319-01	SCREW (2X6) CZN, +B (P) TRI		714	4-227-013-01	SPRING (EJ), TENSION	
703	4-226-994-01	GUIDE (L)		715	4-226-996-01	LIMITTER (EJ)	
704	A-4735-075-A	HOLDER ASSY		716	4-226-997-04	SLIDER	
705	X-4952-665-1	SPRING (SHT) ASSY, LEAF		717	4-226-998-01	LEVER (CHG)	
706	4-227-002-01	GEAR, PULLEY		718	4-227-007-01	GEAR (SB)	
707	3-372-761-01	SCREW (M1.7), TAPPING		719	4-227-006-01	GEAR (SA)	
708	4-2270-250-1	BELT (LOADING)		720	4-226-999-01	LEVER (HEAD)	
710	4-229-533-01	SPRING (STOPPER), TORSION		721	A-4680-638-B	PLATE (HOLDER) ASSY, RETAINER	
711	4-227-012-01	SPRING (HOLDER), TENSION					

7-10. MD MECHANISM DECK SECTION-2 - (MDM-7B4M)



Ref. No.	Part No.	Description	<u>Remarks</u>	Ref. No.	Part No.	<u>Description</u> <u>Re</u>	<u>emarks</u>
751	4-231-319-01	SCREW (2X6) CZN, +B (P) TRI		763	4-226-992-01	BASE, SL	
752	3-372-761-01	SCREW (M1.7), TAPPING		764	4-227-023-01	SPRING (SPINDLE), TORSION	
753	4-227-008-01	GEAR (SC)		765	4-227-004-01	GEAR (LC)	
754	4-227-009-01	GEAR (SD)		766	4-227-005-01	GEAR (LD)	
755	4-226-989-01	CHASSIS		767	4-226-990-01	BASE (BU-A)	
756	4-232-270-01	SCREW (1.7X3.5), +PWH		768	A-4726-344-A	BD (MD) BOARD, COMPLETE	
757	4-226-993-01	RACK		HR901	1-500-670-11	HEAD, OVER WRITE	
758	4-227-014-01	SPRING (RACK), COMPRESSION		M701	A-4672-898-A	MOTOR ASSY, SPINDLE	
759	1-678-514-11	FLEXIBLE BOARD		M702	A-4735-076-A	MOTOR ASSY, SLED	
 1 1 1 1 1 1 1 1 1 	A-4672-541-A	MINI DISK OPTICAL PICK-UP (KMS-2	60B)	M703	A-4735-074-A	MOTOR ASSY, LOADING	
761	4 000 EED 01	SCREW (+P 1.7X6)		S102	1 771 057 11	SWITCH, PUSH (2 KEY) (REFLECT→PRO	TECT\
		,		3102	1-771-937-11	SWITCH, FUSH (2 KET) (NEFLECT→FNU	IEUI)
762	4-996-265-01	SHAFI, MAIN		The	omponente ide	ntified by mark $ riangle$ or dotted	
						critical for safety.	
				lille w	illi illaik 🗥 ale	Citical for Salety.	

Replace only with part number specified.



AUDIO

SECTION 8 ELECTRICAL PARTS LIST

NOTE:

- Due to standardization, replacements in the parts list may be different from the parts specified in the diagrams or the components used on the set.
- -XX, -X mean standardized parts, so they may have some difference from the original one.
- Items marked "*" are not stocked since they are seldom required for routine service.
 Some delay should be anticipated when ordering these items.
- CAPACITORS: uF: μF

RESISTORS

All resistors are in ohms. METAL: metal-film resistor

METAL OXIDE: Metal Oxide-film resistor

F: nonflammable
• COILS

uH: μH

SEMICONDUCTORS

In each case, u: μ , for example: uA...: μ A..., uPA..., μ PA..., uPB..., μ PC...,

 $uPD...,\,\mu PD...$

• Abbreviation

AUS : Australian model
HK : Hong Kong model
KR : Korean model

When indicating parts by reference number, please include the board name.

Ref. No.	Part No.	Description			Remarks	Ref.	No	Part No.	Description			Remarks
1101. 140.	1-681-380-11	•	ARD		<u>rtomarko</u>		310	1-124-261-00	•	10uF	20%	50V
		******	***			l		1-124-261-00		10uF	20%	50V
		< CAPACITOR >						1-136-165-00 1-124-464-11		0.1uF 0.22uF	5.00% 20%	50V 50V
		COAFACITORS						1-137-365-11		0.22ui 0.0015uF		50V
C851	1-136-165-00		0.1uF	5.00%								
C852 C853	1-136-165-00 1-128-549-11		0.1uF 3300uF	5.00% 20.00%		ı		1-124-261-00 1-136-165-00		10uF 0.1uF	20% 5.00%	50V 50V
C854	1-128-549-11		3300uF	20.00%		ı		1-136-165-00		0.1uF	5.00%	50V
		0011150705						1-124-261-00		10uF	20%	50V
		< CONNECTOR >				l C	322	1-124-261-00	ELECT	10uF	20%	50V
CN851		PLUG, CONNECT				l		1-124-261-00		10uF	20%	50V
CN852	1-779-939-11	CONNECTOR, BO	ARD TO BO	ARD 7P		l		1-128-057-11		330uF	20.00%	
		< DIODE >						1-137-367-11 1-162-960-11	CERAMIC CHIP	0.0033uF 220PF	5.00% 10%	50V 50V
						ı		1-124-257-00		2.2uF	20%	50V
D851	8-719-028-23	DIODE D3SBA20	0-4101			ر,	332	1-119-772-11	EI ECT	47uF	20%	25V
		< FUSE >				ı		1-119-772-11		47uF	20%	25V 25V
. ===.		== 00				ı			CERAMIC CHIP	100PF	5%	50V
 ∆ F851 ∆ F852		FUSE, GLASS TU FUSE, GLASS TU						1-119-772-11 1-124-257-00		47uF 2.2uF	20.00% 20%	35V 50V
<u> </u>	1 000 11 11	1002, 02/100 10	DE (DIII. 0)	1 1712/200	•		000	1 121 207 00		2.241	2070	001
		< FUSE HOLDER	>			ı		1-124-465-00 1-124-257-00		0.47uF 2.2uF	20% 20%	50V 50V
FH851	1-533-293-11	FUSE HOLDER				l			CERAMIC CHIP	100PF	20 % 5%	50V 50V
FH852		FUSE HOLDER						1-124-257-00		2.2uF	20%	50V
FH853 FH854		FUSE HOLDER FUSE HOLDER				C	354	1-162-965-11	CERAMIC CHIP	0.0015uF	10%	50V
111004	1 300 230 11	TOOL HOLDER				C	355	1-124-257-00	ELECT	2.2uF	20%	50V
		< RESISTOR >				l		1-124-261-00		10uF	20%	50V
R851	1-260-107-11	CARRON	4.7K	5%	1/2W	ı		1-124-261-00 1-124-261-00		10uF 10uF	20% 20%	50V 50V
		*******						1-136-165-00		0.1uF	5.00%	50V
	A 4476 029 A	AUDIO BOARD, C	OMDLETE (VIIG FIN I	(D)	ر,	363	1-124-464-11	EI EOT	0.22uF	20%	50V
		AUDIO BOARD, C			Nn)	ı		1-124-404-11		0.22ur 0.0015uF		50V 50V
		******	******	. ,		ı	365	1-124-261-00		10uF	20%	50V
		< CAPACITOR >						1-136-165-00 1-136-165-00		0.1uF 0.1uF	5.00% 5.00%	50V 50V
C102		CERAMIC CHIP					381	1-124-257-00		2.2uF	20%	50V
C111	1-124-227-00	ELEGI	10uF	20%	10V (AEP,UK)	ı	382 383	1-119-772-11 1-119-772-11		47uF 47uF	20% 20%	25V 25V
C121		CERAMIC CHIP	0.1		25V	ı	384	1-162-927-11	CERAMIC CHIP	100PF	5%	50V
C152 C301	1-162-962-11 1-124-257-00	CERAMIC CHIP	470PF 2.2uF	10% 20%	50V 50V				< CONNECTOR >			
0301	1-124-231-00	LLLOT	2.2ui	20 /0	30 V				COUNTEDIONS			
C302		CERAMIC CHIP	100PF	5%	50V		N101	1-784-780-11	, -			
C303 C304	1-124-257-00 1-162-965-11	CERAMIC CHIP	2.2uF 0.0015uF	20% 10%	50V 50V	l			PIN, CONNECTOR CONNECTOR, BOA		ARD 5P	
C305	1-124-257-00	ELECT	2.2uF	20%	50V	CI	N104	1-568-830-11	CONNECTOR, FFC	11P (AUS,	HK,KR)	
C309	1-124-261-00	ELECT	10uF	20%	50V	CI	N104	1-784-776-11	CONNECTOR, FFC	15P (AEP,U	JK)	

AUDIO

BD (CD)

											,
Ref. No.	Part No.	Description			Remarks	Ref. No.	Part No.	Description			<u>Remarks</u>
CN105	1-564-506-11	PLUG, CONNECT	OR 3P		Homano	R321	1-216-839-11	•	33K	5%	1/16W
* CN106	1-568-934-11	PIN, CONNECTOR				R322	1-216-857-11		1M	5%	1/16W
* CN108	1-568-943-11	PIN, CONNECTOR				R323	1-216-821-11		1K	5%	1/16W
. 011100	1 000 0 10 11	i iii, ooiiiiLoroi	. 01			R324	1-216-821-11		1K	5%	1/16W
		< DIODE >				R325	1-216-821-11		1K	5%	1/16W
		(51052)				11020	1 210 021 11	MEDICE OTTO		0,0	1, 1011
D101	8-719-200-82	DIODE 11ES2-TA	A1B			R326	1-216-831-11	METAL CHIP	6.8K	5%	1/16W
D103	8-719-988-61					R327	1-249-433-11		22K	5%	1/4W
D111	8-719-923-34	DIODE MTZJ-T-		P,UK)		R331	1-216-821-11	METAL CHIP	1K	5%	1/16W
D301	8-719-988-61	DIODE 1SS355T		. ,		R332	1-216-833-11	METAL CHIP	10K	5%	1/16W
D343	8-719-988-61	DIODE 1SS355T	E-17			R333	1-216-833-11	METAL CHIP	10K	5%	1/16W
D393	8-719-988-61	DIODE 1SS355T	E-17			R334	1-216-821-11		1K	5%	1/16W
						R335	1-216-835-11		15K	5%	1/16W
		< TERMINAL >				R336	1-216-833-11		10K	5%	1/16W
EDT100	4 507 774 04	TED1411141 BOAR		_		R338	1-216-845-11		100K	5%	1/16W
EP1102	1-53/-//1-21	TERMINAL BOAR	D, GROUNI	ט		△ R339	1-249-405-11	CARBON	100	5%	1/4WF
		. 10 .				D040	1 010 045 11	METAL CLUD	1001/	E0/	4 /4 CM/
		< IC >				R340 R341	1-216-845-11 1-216-845-11		100K 100K	5% 5%	1/16W 1/16W
10201	8-759-494-40	IC M62428AFP6	2000			R343			100K 100K	5% 5%	1/16W
IC301							1-216-845-11 1-247-903-00				
IC302	8-739-107-88	IC NJM4565D (A	AEP,UK)			R344 R352			1M	5% 5%	1/4W 1/16W
		< CONDUCTOR >				N332	1-216-821-11	WE TAL CHIP	1K	370	1/1000
		< CONDUCTOR >				R353	1-216-845-11	METAL CHID	100K	5%	1/16W
JR303	1-216-864-11	METAL CHIP	0	5%	1/16W	R354	1-216-821-11		1K	5%	1/16W
JR304	1-216-864-11	METAL CHIP	0	5%	1/16W	R359	1-216-845-11		100K	5%	1/16W
JR305		METAL CHIP	0	5%	1/16W	R362	1-216-829-11		4.7K	5%	1/16W
JR306			0	5%	1/16W	R363	1-218-296-11		75K	5% 5%	1/16W
011000	1 210 004 11	WEIAL OITH	U	3 /0	1/1000	11000	1 210 230 11	TIEO OTTI	7010	3 /0	1/1000
		< TRANSISTOR >				R364	1-216-839-11	MFTAL CHIP	33K	5%	1/16W
		(110,000,010,17)				R365	1-216-857-11		1M	5%	1/16W
Q101	8-729-120-28	TRANSISTOR	2SC1623-	T1-I 5I 6	3	R366	1-249-441-11		100K	5%	1/4W
Q102		TRANSISTOR	UN2111-7		•	R367	1-216-837-11		22K	5%	1/16W
Q103	8-729-120-28		2SC3052F		F	R381	1-216-821-11		1K	5%	1/16W
Q151		TRANSISTOR	2SC1623-			11001	. 2.0 02	WEINE OIM		0 70	1, 1011
Q311	8-729-120-28		2SC1623-			R382	1-216-833-11	METAL CHIP	10K	5%	1/16W
						R383	1-216-833-11	-	10K	5%	1/16W
Q331	8-729-046-97	TRANSISTOR	2SD1938	F)-T(TX).SO	R384	1-216-821-11		1K	5%	1/16W
Q361	8-729-120-28		2SC1623-			R385	1-216-835-11		15K	5%	1/16W
Q381	8-729-046-97		2SD1938			R386	1-216-833-11		10K	5%	1/16W
				. , .	,						
		< RESISTOR >				R388	1-216-845-11	METAL CHIP	100K	5%	1/16W
						R393	1-216-845-11	METAL CHIP	100K	5%	1/16W
R102	1-216-821-11	METAL CHIP	1K	5%	1/16W	******	*****	*****	******	******	*****
R103	1-216-833-11	METAL CHIP	10K	5%	1/16W						
R104	1-216-821-11	METAL CHIP	1K	5%	1/16W		A-4476-934-A	BD (CD) BOARD	, complete		
R105	1-216-845-11	METAL CHIP	100K	5%	1/16W			******	*******	•	
R111	1-247-819-11	CARBON	330	5%	1/4W						
					(AEP,UK)		7-685-852-04	SCREW +BVTT 2	(S)		
D440	1 010 000 11	METAL OLUD	4 71/	F0/	4/4/01/1			OADAOITOD			
R112	1-216-829-11	METAL CHIP	4.7K	5%	1/16W			< CAPACITOR >			
R152	1-216-821-11		1K	5%	1/16W	04.04	4 404 045 44	OEDANNO OUID	470DE	F 000/	501/
R153	1-216-833-11	METAL CHIP	10K	5%	1/16W	C101		CERAMIC CHIP	470PF	5.00%	
R154	1-216-821-11	METAL CHIP	1K	5%	1/16W	C102		CERAMIC CHIP	0.1uF	10.00%	
R155	1-216-845-11	METAL CHIP	100K	5%	1/16W	C103		CERAMIC CHIP	470PF	5.00%	50V
Dooo	1 010 001 11	METAL OLUB	417	F0/	4 4 0 4 4	C104		CERAMIC CHIP	0.0033uF	10%	50V
R302	1-216-821-11	METAL CHIP	1K	5%	1/16W	C107	1-162-921-11	CERAMIC CHIP	33PF	5%	50V
R303	1-216-845-11	METAL CHIP	100K	5%	1/16W	0400	1 104 000 11	OEDAMIO OLUB	0.4		101/
R304	1-216-821-11	METAL CHIP	1K	5%	1/16W	C108		CERAMIC CHIP	0.1uF		16V
R309	1-216-845-11	METAL CHIP	100K	5%	1/16W	C109		CERAMIC CHIP	0.1uF	10.000/	16V
R312	1-216-829-11	METAL CHIP	4.7K	5%	1/16W	C110		CERAMIC CHIP	0.1uF	10.00%	
poto	1 010 000 11	DEC CHID	751/	E0/	1/1C\M	C111	1-124-589-11		47uF	20%	16V
R313	1-218-296-11	RES-CHIP	75K	5%	1/16W	C112	1-124-589-11	CLEVI	47uF	20%	16V
R314	1-216-839-11		33K	5%	1/16W						
R315	1-216-857-11	METAL CHIP	1M 100K	5%	1/16W						
R316 R317	1-249-441-11 1-216-837-11		100K 22K	5% 5%	1/4W 1/16W						
11017	1-210-03/-11	IVIL IAL UNIF	ZZIN	J /0	1/1000	I					

HCD-C5

BD (CD)

Ref. No.	Part No.	Description			Remarks	Ref. No.	Part No.	Description			Remarks
C113	1-124-584-00	ELECT	100uF	20%	10V			< DIODE >			
C114	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V			< DIODE >			
C115	1-124-589-11	ELECT	47uF	20%	16V	D101	8-719-056-77	DIODE UDZ-TE-1	7-3.9B		
C117	1-164-360-11	CERAMIC CHIP	0.1uF		16V						
C118	1-115-156-11	CERAMIC CHIP	1uF		10V			< FERRITE BEAD :	>		
C119	1-115-156-11	CERAMIC CHIP	1uF		10V	FB101	1-500-445-21	FERRITE	0uH		
C120		ELECT	47uF	20.00%							
C154	1-164-360-11	CERAMIC CHIP	0.1uF		16V			< IC >			
C159	1-162-968-11	CERAMIC CHIP	0.0047uF	10%	50V						
C161	1-164-360-11	CERAMIC CHIP	0.1uF		16V	IC101		IC CXD3068Q			
C162	1-162-974-11	CERAMIC CHIP	0.01uF		50V	IC102 IC103		IC BA5982FP-E2 IC CXA2581N-T4			
C164	1-102-374-11		220uF	20.00%		IC1103		IC BA6956AN	·		
C180		CERAMIC CHIP	100PF	5%	50V	101102	0 700 000 00	TO BROODERIN			
C181	1-162-927-11	CERAMIC CHIP	100PF	5%	50V			< CONDUCTOR >			
C182	1-162-927-11	CERAMIC CHIP	100PF	5%	50V						
						JR201	1-216-864-11	METAL CHIP	0	5%	1/16W
C183	1-162-927-11	CERAMIC CHIP	100PF	5%	50V			TRANSISTOR			
C184 C185	1-162-969-11 1-162-969-11	CERAMIC CHIP CERAMIC CHIP	0.0068uF 0.0068uF	10% 10%	25V 25V			< TRANSISTOR >			
C185	1-102-909-11	ELECT	0.0068uF 220uF	20.00%		Q101	8-729-049-31	TRANSISTOR	2SB710A-F	RTY	
C187		CERAMIC CHIP	0.1uF	20.00 /0	16V	Q102	8-729-015-74		UN5111-T		
0107	1 101 000 11	OLITAWINO OTTO	o. rui		101	Q103	8-729-920-85		2SD1664-1		
C188	1-162-974-11	CERAMIC CHIP	0.01uF		50V						
C191		CERAMIC CHIP	0.047uF	10.00%				< RESISTOR >			
C192		CERAMIC CHIP	0.047uF	10.00%							
C193		CERAMIC CHIP	0.047uF	10.00%		R102	1-216-835-11		15K	5%	1/16W
C194	1-165-176-11	CERAMIC CHIP	0.047uF	10.00%	16V	R103	1-216-845-11		100K	5%	1/16W
C201	1-126-934-11	ELECT	220uF	20.00%	10\/	R104 R105	1-216-835-11 1-216-821-11		15K 1K	5% 5%	1/16W 1/16W
C201		CERAMIC CHIP	0.1uF	20.00 /6	16V	R109	1-216-846-11	METAL CHIP	120K	5%	1/16W
C203		CERAMIC CHIP	10PF	0.5PF	50V	11100	1 210 010 11	WEINE OITH	12010	0 70	17 1000
C204	1-162-915-11	CERAMIC CHIP	10PF	0.5PF	50V	R111	1-216-846-11	METAL CHIP	120K	5%	1/16W
C205	1-164-360-11	CERAMIC CHIP	0.1uF		16V	R113	1-216-827-11	METAL CHIP	3.3K	5%	1/16W
						R114	1-216-845-11	METAL CHIP	100K	5%	1/16W
C206	1-162-927-11	CERAMIC CHIP	100PF	5%	50V	R115	1-216-841-11	METAL CHIP	47K	5%	1/16W
C209	1-162-927-11	CERAMIC CHIP	100PF	5%	50V	R116	1-216-841-11	METAL CHIP	47K	5%	1/16W
C211 C212	1-107-826-11 1-162-965-11	CERAMIC CHIP CERAMIC CHIP	0.1uF 0.0015uF	10.00% 10%	50V	R117	1-216-847-11	METAL CHIP	150K	5%	1/16W
C213			0.0013uF	10%	50V	R118	1-216-835-11	METAL CHIP	156K	5%	1/16W
0210	1 102 007 11	OLI II III III O	0.000001	1070	001	R120	1-216-849-11	METAL CHIP	220K	5%	1/16W
C215	1-117-863-11	CERAMIC CHIP	0.47uF	10.00%	6.3V	R122	1-216-845-11		100K	5%	1/16W
C216		CERAMIC CHIP	0.01uF	10%	25V	R123	1-216-797-11	METAL CHIP	10	5%	1/16W
C221		CERAMIC CHIP	0.1uF		16V						
C222		CERAMIC CHIP	0.1uF		16V	R124	1-216-798-11		12	5%	1/16W
C224	1-164-360-11	CERAMIC CHIP	0.1uF		16V	R125 R126	1-216-834-11 1-216-834-11		12K 12K	5% 5%	1/16W 1/16W
C227	1-164-360-11	CERAMIC CHIP	0.1uF		16V	R158	1-216-833-11		12K 10K	5%	1/16W
C228		CERAMIC CHIP	1uF		10V	R159	1-216-841-11		47K	5%	1/16W
C229		CERAMIC CHIP	0.1uF		16V						
C230	1-126-382-11	ELECT	100uF	20.00%		R162	1-216-847-11	METAL CHIP	150K	5%	1/16W
C231	1-126-934-11	ELECT	220uF	20.00%	10V	R180	1-216-845-11		100K	5%	1/16W
0004		0504440 01110	0.04 5		5017	R181	1-216-846-11		120K	5%	1/16W
C234		CERAMIC CHIP	0.01uF		50V	R182	1-216-843-11		68K	5%	1/16W
C235 C236		CERAMIC CHIP CERAMIC CHIP	0.01uF 0.47uF	10.00%	50V	R183	1-216-843-11	WETAL CHIP	68K	5%	1/16W
C236		CERAMIC CHIP	0.47uF 0.47uF	10.00%		R184	1-216-849-11	METAL CHIP	220K	5%	1/16W
C240		CERAMIC CHIP	0.001uF	10%	50V	R185	1-216-849-11		220K	5%	1/16W
				-		R186	1-216-843-11		68K	5%	1/16W
C1109		CERAMIC CHIP	0.1uF		16V	R187	1-216-843-11	METAL CHIP	68K	5%	1/16W
C1110	1-126-934-11		220uF	20.00%		R188	1-216-849-11	METAL CHIP	220K	5%	1/16W
C1111	1-162-974-11	CERAMIC CHIP	0.01uF		50V	D400	4 040 040 41	METAL OLUB	00014	F0'	4 /4 0\4
		COMMECTOR				R189	1-216-849-11		220K	5% 5%	1/16W
		< CONNECTOR >				R190 R191	1-216-837-11 1-216-837-11		22K 22K	5% 5%	1/16W 1/16W
CN101	1-784-751-11	CONNECTOR, FFC	29P			R192	1-216-837-11		22K 22K	5%	1/16W
		CONNECTOR, BO		ARD 26P		R193	1-216-837-11		22K	5%	1/16W
		•									

BD (CD)

BD (MD)

R196	-	Ref. No.	Part No.	Description			Remarks	Ref. No.	Part No.	Description			Remarks
R199	1			•	001/	F0/				•	47.5		
R198												10.000/	
R190													
R202													
R202													
R203		11201	1-210-039-11	WEIAL CHIF	JUK	J /0	1/1000	0113	1-102-900-11	OLIMAINIO OITIF	0.002201	10 /0	J0 V
R203		R202	1-216-833-11	METAL CHIP	10K	5%	1/16W	C116	1-164-227-11	CERAMIC CHIP	0.022uF	10%	25V
R204 -1218-827-11 METAL CHIP S.3K 5% 1/16W C119 1-165-176-11 CERAMIC CHIP 0.0476 10.00% 16V R206 -1218-833-11 METAL CHIP 10K 5% 1/16W C120 1-164-156-11 CERAMIC CHIP 0.10F 25V C121 -1218-833-11 METAL CHIP 0.05% 1/16W C120 1-164-156-11 CERAMIC CHIP 0.10F C25V C121 -1218-833-11 METAL CHIP 0.05% 1/16W C125 -1117-720-11 CERAMIC CHIP 0.10F C25V C125 -1117-720-11 C125												10%	
R207 1-216-633-11 METAL CHIP 10K 5% 1/16W C12D 1-164-156-11 CERAMIC CHIP 0.1 uF 25V 25V R212 1-216-631-11 METAL CHIP 0 5% 1/16W C12E 1-117-720-11 CERAMIC CHIP 0.1 uF 25V R215 1-216-631-11 METAL CHIP 20 5% 1/16W C13E 1-164-156-11 CERAMIC CHIP 0.1 uF 25V R217 1-216-633-11 METAL CHIP 20 5% 1/16W C13E 1-164-156-11 CERAMIC CHIP 0.1 uF 25V R217 1-216-632-11 METAL CHIP 10V 5% 1/16W C13E 1-164-156-11 CERAMIC CHIP 0.1 uF 25V R217 1-216-632-11 METAL CHIP 10V 5% 1/16W C13E 1-164-156-11 CERAMIC CHIP 0.1 uF 25V C1			1-216-827-11	METAL CHIP	3.3K	5%	1/16W	C118	1-165-176-11	CERAMIC CHIP	0.047uF	10.00%	16V
R207		R205	1-216-821-11	METAL CHIP	1K	5%	1/16W	C119	1-165-176-11	CERAMIC CHIP	0.047uF	10.00%	16V
R212 1-216-838-11 METAL CHIP 220 5% 1716W C125 1-116-720-11 CERAMIC CHIP 0.10F 25V R216 1-216-838-11 METAL CHIP 220 5% 1716W C131 1-117-720-11 CERAMIC CHIP 0.10F 25V R216 1-216-839-11 METAL CHIP 10K 5% 1716W C131 1-117-720-11 CERAMIC CHIP 0.10F 25V R219 1-216-839-11 METAL CHIP 10K 5% 1716W C132 1-164-156-11 CERAMIC CHIP 0.10F 25V R219 1-216-839-11 METAL CHIP 10K 5% 1716W C141 1-126-206-11 ELECT CHIP 10Ug 20% 6.3V R220 1-216-839-11 METAL CHIP 10K 5% 1716W C142 1-164-156-11 CERAMIC CHIP 0.10F 25V R221 1-216-831-11 METAL CHIP 20 5% 1716W C143 1-164-156-11 CERAMIC CHIP 0.10F 25V R221 1-216-831-11 METAL CHIP 10W 5% 1716W C143 1-164-156-11 CERAMIC CHIP 0.10F 25V R226 1-216-831-11 METAL CHIP 20 5% 1716W C143 1-164-156-11 CERAMIC CHIP 0.10F 25V R228 1-216-831-11 METAL CHIP 20 5% 1716W C143 1-164-156-11 CERAMIC CHIP 0.10F 25V R228 1-216-832-11 METAL CHIP 20 5% 1716W C153 1-164-156-11 CERAMIC CHIP 0.10F 25V R230 1-216-832-11 METAL CHIP 22K 5% 1716W C153 1-164-156-11 CERAMIC CHIP 0.10F 25V R230 1-216-837-11 METAL CHIP 22K 5% 1716W C153 1-164-156-11 CERAMIC CHIP 0.10F 25V R330 1-216-837-11 METAL CHIP 22K 5% 1716W C153 1-164-156-11 CERAMIC CHIP 0.10F 25V R330 1-216-837-11 METAL CHIP 22K 5% 1716W C153 1-164-156-11 CERAMIC CHIP 0.10F 25V R330 1-216-837-11 METAL CHIP 22K 5% 1716W C153 1-164-156-11 CERAMIC CHIP 0.10F 25V R330 1-216-837-11 METAL CHIP 22K 5% 1716W C154 1-162-206-11 ELECT CHIP 0.10F 25V R330 1-216-837-11 METAL CHIP 22K 5% 1716W C156 1-164-156-11 CERAMIC CHIP 0.10F 25V C163 1-216-837-11 METAL CHIP 22K 5% 1716W C156 1-164-156-11 CERAMIC CHIP 0.10F 25V C163 1-216-837-11 METAL CHIP 22K 5% 1716W C156 1-164-156-11 CERAMIC CHIP 0.10F 25V C163 1-216-837-11 METAL CHIP 22K 5% 1716W C156 1-164-156-11 CERAMIC CHIP 0.10F 25V C163 1-216-837-11 METAL CHIP 22K 5% 1716W C156 1-164-156-11 CERAMIC CHIP 0.10F 25V C163 1-216-837-11 METAL CHIP 22K 5% 1716W C156 1-164-156-11 CERAMIC CHIP 0.10F 25V C163 1-216-837-11 METAL CHIP 22K 5% 1716W C165 1-164-156-11 CERAMIC CHIP 0.10F 25V C163 1-126-837-11 METAL CHIP 22W 5% 5% 1716W C165 1-164-15		R206	1-216-833-11	METAL CHIP	10K	5%	1/16W	C120	1-164-156-11	CERAMIC CHIP	0.1uF		25V
R212 1-216-838-11 METAL CHIP 220 5% 1716W C125 1-116-720-11 CERAMIC CHIP 0.10F 25V R216 1-216-838-11 METAL CHIP 220 5% 1716W C131 1-117-720-11 CERAMIC CHIP 0.10F 25V R216 1-216-839-11 METAL CHIP 10K 5% 1716W C131 1-117-720-11 CERAMIC CHIP 0.10F 25V R219 1-216-839-11 METAL CHIP 10K 5% 1716W C132 1-164-156-11 CERAMIC CHIP 0.10F 25V R219 1-216-839-11 METAL CHIP 10K 5% 1716W C141 1-126-206-11 ELECT CHIP 10Ug 20% 6.3V R220 1-216-839-11 METAL CHIP 10K 5% 1716W C142 1-164-156-11 CERAMIC CHIP 0.10F 25V R221 1-216-831-11 METAL CHIP 20 5% 1716W C143 1-164-156-11 CERAMIC CHIP 0.10F 25V R221 1-216-831-11 METAL CHIP 10W 5% 1716W C143 1-164-156-11 CERAMIC CHIP 0.10F 25V R226 1-216-831-11 METAL CHIP 20 5% 1716W C143 1-164-156-11 CERAMIC CHIP 0.10F 25V R228 1-216-831-11 METAL CHIP 20 5% 1716W C143 1-164-156-11 CERAMIC CHIP 0.10F 25V R228 1-216-832-11 METAL CHIP 20 5% 1716W C153 1-164-156-11 CERAMIC CHIP 0.10F 25V R230 1-216-832-11 METAL CHIP 22K 5% 1716W C153 1-164-156-11 CERAMIC CHIP 0.10F 25V R230 1-216-837-11 METAL CHIP 22K 5% 1716W C153 1-164-156-11 CERAMIC CHIP 0.10F 25V R330 1-216-837-11 METAL CHIP 22K 5% 1716W C153 1-164-156-11 CERAMIC CHIP 0.10F 25V R330 1-216-837-11 METAL CHIP 22K 5% 1716W C153 1-164-156-11 CERAMIC CHIP 0.10F 25V R330 1-216-837-11 METAL CHIP 22K 5% 1716W C153 1-164-156-11 CERAMIC CHIP 0.10F 25V R330 1-216-837-11 METAL CHIP 22K 5% 1716W C154 1-162-206-11 ELECT CHIP 0.10F 25V R330 1-216-837-11 METAL CHIP 22K 5% 1716W C156 1-164-156-11 CERAMIC CHIP 0.10F 25V C163 1-216-837-11 METAL CHIP 22K 5% 1716W C156 1-164-156-11 CERAMIC CHIP 0.10F 25V C163 1-216-837-11 METAL CHIP 22K 5% 1716W C156 1-164-156-11 CERAMIC CHIP 0.10F 25V C163 1-216-837-11 METAL CHIP 22K 5% 1716W C156 1-164-156-11 CERAMIC CHIP 0.10F 25V C163 1-216-837-11 METAL CHIP 22K 5% 1716W C156 1-164-156-11 CERAMIC CHIP 0.10F 25V C163 1-216-837-11 METAL CHIP 22K 5% 1716W C156 1-164-156-11 CERAMIC CHIP 0.10F 25V C163 1-216-837-11 METAL CHIP 22K 5% 1716W C165 1-164-156-11 CERAMIC CHIP 0.10F 25V C163 1-126-837-11 METAL CHIP 22W 5% 5% 1716W C165 1-164-15													
R216 1-216-88-11 METAL CHIP													
R216 1-216-831-11 METAL CHIP													
R218													
R218 1-216-821-11 METAL CHIP 1K 5% 1/16W C133 1-164-156-11 CERAMIC CHIP 0.1 UF 25V R219 1-216-833-11 METAL CHIP 0 5% 1/16W C141 1-128-206-11 ELECT CHIP 0.1 UF 25V R226 1-216-831-11 METAL CHIP 100 5% 1/16W C143 1-164-156-11 CERAMIC CHIP 0.1 UF 25V R226 1-216-831-11 METAL CHIP 100 5% 1/16W C143 1-164-156-11 CERAMIC CHIP 0.1 UF 25V R226 1-216-839-11 METAL CHIP 100 5% 1/16W C144 1-162-970-11 CERAMIC CHIP 0.1 UF 25V R228 1-216-831-11 METAL CHIP 100 5% 1/16W C152 1-164-156-11 CERAMIC CHIP 0.1 UF 25V R228 1-216-831-11 METAL CHIP 2.2 K 5% 1/16W C152 1-164-156-11 CERAMIC CHIP 0.1 UF 25V R230 1-216-837-11 METAL CHIP 2.2 K 5% 1/16W C153 1-164-156-11 CERAMIC CHIP 0.1 UF 25V R231 1-216-825-11 METAL CHIP 2.2 K 5% 1/16W C153 1-164-156-11 CERAMIC CHIP 0.1 UF 25V R231 1-216-825-11 METAL CHIP 2.2 K 5% 1/16W C153 1-164-156-11 CERAMIC CHIP 0.1 UF 25V R331 1-216-837-11 METAL CHIP 2.2 K 5% 1/16W C154 1-126-206-11 ELECT CHIP 0.1 UF 25V R331 1-216-837-11 METAL CHIP 2.2 K 5% 1/16W C155 1-164-156-11 CERAMIC CHIP 0.1 UF 25V R331 1-216-837-11 METAL CHIP 2.2 K 5% 1/16W C156 1-164-156-11 CERAMIC CHIP 0.1 UF 25V R331 1-216-837-11 METAL CHIP 2.2 K 5% 1/16W C156 1-164-156-11 CERAMIC CHIP 0.1 UF 25V R331 1-216-837-11 METAL CHIP 2.2 K 5% 1/16W C156 1-164-156-11 CERAMIC CHIP 0.1 UF 25V R331 1-216-837-11 METAL CHIP 2.2 K 5% 1/16W C159 1-164-156-11 CERAMIC CHIP 0.1 UF 25V R331 1-216-837-11 METAL CHIP 2.2 K 5% 1/16W C159 1-162-907-11 CERAMIC CHIP 0.1 UF 25V C169 1-164-156-11 CERAMIC CHIP 0.0 UF 25V C169 1-164-156-													
R219		nZ17	1-210-029-11	WEIAL UNIP	4./ N	370	1/1000	6132	1-104-130-11	CENAIVIIC CHIP	U.TUF		237
R219		R218	1-216-821-11	METAL CHIP	1K	5%	1/16W	C133	1-164-156-11	CERAMIC CHIP	0.1uF		25V
R220												20%	
R226												2070	
R226 1-216-809-11 METAL CHIP 100 5% 1/16W C144 1-162-970-11 CERAMIC CHIP 0.01uF 25V													
R227												10%	
R228 1-216-835-11 METAL CHIP 470K 5% 1/16W C151 1-117-370-11 CERAMIC CHIP 10UF 25V C152 1-164-156-11 CERAMIC CHIP 0.1 uF 25V C152 1-164-156-11 CERAMIC CHIP 0.1 uF 25V C154 1-216-825-11 METAL CHIP 2.2 K 5% 1/16W C153 1-164-156-11 CERAMIC CHIP 0.1 uF 25V C154 1-216-820-11 ELECT CHIP 0.1 uF 25V C154 1-216-825-11 METAL CHIP 2.2 K 5% 1/16W C155 1-164-156-11 CERAMIC CHIP 0.1 uF 25V C154 1-216-837-11 METAL CHIP 22K 5% 1/16W C157 1-164-156-11 CERAMIC CHIP 0.1 uF 25V C154 1-216-837-11 METAL CHIP 22K 5% 1/16W C157 1-164-156-11 CERAMIC CHIP 0.1 uF 25V C154 1-216-837-11 METAL CHIP 22K 5% 1/16W C157 1-164-156-11 CERAMIC CHIP 0.1 uF 25V C158 1-162-937-11 CERAMIC CHIP 0.0 uF 5% 50V C158 1-162-937-11 CERAMIC CHIP 0.0 uF 5% 50V C164 1-162-937-11 CERAMIC CHIP 0.0 uF 5% 50V C165 1-162-968-11 CERAMIC CHIP 0.0 uF 5% 50V C165 1-162-968-11 CERAMIC CHIP 0.0 uF 0.0 u													
R229 1-216-825-11 METAL CHIP 2.2K 5% 1/16W C152 1-164-156-11 CERAMIC CHIP 0.1uF 25V C154 1-216-825-11 METAL CHIP 2.2K 5% 1/16W C154 1-126-206-11 ELECT CHIP 100uF 25V C154 1-216-825-11 METAL CHIP 2.2K 5% 1/16W C155 1-164-156-11 CERAMIC CHIP 100uF 25V C154 1-216-827-11 METAL CHIP 22K 5% 1/16W C156 1-164-156-11 CERAMIC CHIP 0.1uF 25V C154 1-216-837-11 METAL CHIP 22K 5% 1/16W C156 1-164-156-11 CERAMIC CHIP 0.1uF 25V C157 1-164-156-11 CERAMIC CHIP 0.00F 5% 50V C157 1-162-907-11 CERAMIC CHIP 0.00F 5% 50V C158 1-162-927-11 CERAMIC CHIP 0.00F 5% 50V C159 1-162-927-11 CERAMIC CHIP 0.00F 5% 50V C159 1-162-937-11 CERAMIC CHIP 0.00F 5% 50V C160 1-162-937-11 CERAMIC CHIP 0.00F 5% 50V C162 1-162-937-11 CERAMIC CHIP 0.00F 5% 50V C162 1-162-937-11 CERAMIC CHIP 0.00F 5% 50V C162 1-162-937-11 CERAMIC CHIP 0.00F 5% 50V C164 1-162-937-11 CERAMIC CHIP 0.00F 5% 50V C164 1-162-937-11 CERAMIC CHIP 0.00F 5% 50V C165 1-162-938-11 CERA					100K	5%		C145	1-164-156-11	CERAMIC CHIP			25V
R230													
R231 1-216-825-11 METAL CHIP 2.2K 5% 1/16W C155 1-164-156-11 CERAMIC CHIP 0.1uF 25V									1-164-156-11	CERAMIC CHIP			
R302													
R303		R231	1-216-825-11	METAL CHIP	2.2K	5%	1/16W	C154	1-126-206-11	ELECT CHIP	100uF	20%	6.3V
R303		D000	1 010 007 11	METAL OLUB	001/	F0/	4/4/01/4	0455	1 104 150 11	OFDAMIO OLUD	0.4		051/
R304 1-216-837-11 METAL CHIP 22K 5% 1/16W C159 1-162-927-11 CERAMIC CHIP 0.01F 5% 50V C159 1-162-927-11 CERAMIC CHIP 0.007F 10% 25V C161 1-162-907-11 CERAMIC CHIP 0.01F 10% 25V C162 1-162-907-11 CERAMIC CHIP 0.01F 10% 25V C163 1-125-891-11 CERAMIC CHIP 0.047F 100.00% 10V C164 1-162-927-11 CERAMIC CHIP 0.047F 100.00% 10V C167 1-162-968-11 CERAMIC CHIP 0.047F 10% 50V C168 1-125-891-11 CERAMIC CHIP 0.015F 100.00% 10V C167 1-164-156-11 CERAMIC CHIP 0.015F 100.00% 25V C169 1-164-156-11 CERAMIC CHIP 0.015F 100.00% 25V C169 1-164-156-11 CERAMIC CHIP 0.015F 10V C169													
R305 1-216-837-11 METAL CHIP 22K 5% 1/16W C159 1-162-927-11 CERAMIC CHIP 100PF 5% 50V C161 1-162-927-11 CERAMIC CHIP 100PF 5% 50V C161 1-162-927-11 CERAMIC CHIP 0.01uF 10% 25V C162 1-162-970-11 CERAMIC CHIP 0.01uF 10% 25V C163 1-125-891-11 CERAMIC CHIP 0.47uF 10.00% 10V C163 1-125-891-11 CERAMIC CHIP 0.47uF 10.00% 10V C164 1-162-927-11 CERAMIC CHIP 0.47uF 10.00% 10V C165 1-162-968-11 CERAMIC CHIP 0.47uF 10.00% 10V C166 1-125-891-11 CERAMIC CHIP 0.47uF 10.00% 10V C166 1-125-891-11 CERAMIC CHIP 0.47uF 10.00% 10V C166 1-125-891-11 CERAMIC CHIP 0.47uF 10.00% 25V C169 1-164-156-11 CERAMIC CHIP 0.1uF 25V C173 1-164-156-11 CERAMIC CHIP 0.1uF 25V C173 1-164-156-11 CERAMIC CHIP 0.1uF 25V C173 1-164-156-11 CERAMIC CHIP 0.1uF 25V C182 1-163-938-00 CERAMIC CHIP 0.1uF 25V C182 1-163-938-00 CERAMIC CHIP 0.1uF 25V C182 1-163-908-11 CERAMIC CHIP 0.1uF 25V C183 1-163-908-01 CERAMIC CHIP 0.1uF 25V C193 1-126-206-11 ELECT CHIP 100uF 25V C193 1-126-206-11 CERAMIC CHIP 0.1uF 25V C194 1-164-227-11 CERAMIC CHIP 0.1uF 25V C195 1-164-156-11 CERAMIC CHIP 0.1uF 25V C195 1-164-677-11 CERAMIC CHIP 0.008uF 10% 25V C195 1-164-156-11 CERAMIC CHIP 0.1uF 25V C195 1-164-677-11 CERAMIC CHIP 0.008uF 10% 25V C195 1-164-156-11 CERAMIC CHIP 0.1uF 25V C195 1-164-677-11 CERAMIC C													
R1133 1-216-813-11 METAL CHIP 220 5% 1/16W C159 1-162-927-11 CERAMIC CHIP 100PF 5% 50V R1134 1-216-821-11 METAL CHIP 1K 5% 1/16W C160 1-162-927-11 CERAMIC CHIP 0.01uF 10% 25V												5%	
R1134 1-216-821-11 METAL CHIP 1K 5% 1/16W C160 1-162-927-11 CERAMIC CHIP 100PF 5% 50V C161 1-162-970-11 CERAMIC CHIP 0.01uF 10% 25V C162 1-162-970-11 CERAMIC CHIP 0.01uF 10% 25V C162 1-162-970-11 CERAMIC CHIP 0.01uF 10% 25V C163 1-125-891-11 CERAMIC CHIP 0.07uF 10.00% 10V C164 1-162-970-11 CERAMIC CHIP 0.07uF 10.00% 10V C164 1-162-970-11 CERAMIC CHIP 0.007uF 10% 50V C165 1-162-981-11 CERAMIC CHIP 0.07uF 10.00% 10V C166 1-125-891-11 CERAMIC CHIP 0.07uF 10.00% 10V C167 1-164-156-11 CERAMIC CHIP 0.01uF 25V C173 1-164-156-11 CERAMIC CHIP 0.01uF 25V C173 1-164-156-11 CERAMIC CHIP 0.01uF 25V C184 1-125-206-11 CERAMIC CHIP 0.01uF 25V C184 1-126-206-11 CERAMIC CHIP 0.01uF 25V C185 1-318-72-11 CERAMIC CHIP 0.01uF 25V C192 1-164-156-11 CERAMIC CHIP 0.01uF 25V C192 1-164-156-11 CERAMIC CHIP 0.01uF 25V C192 1-164-156-11 CERAMIC CHIP 0.01uF 25V C194 1-162-206-11 CERAMIC CHIP 0.01uF 25V C194 1-162-206-11 CERAMIC CHIP 0.1uF 25V C194 1-164-25-11 CERAMIC CHIP 0.1uF 25V C195 1-164-25-11 CERAMIC CHIP 0.01uF 25V C195 1-164-156-11 CERAMIC CHIP 0.1uF 25V C195 1-164-156-11													
C161		111100	1-210-013-11	WEIAL OITH	220	J /0	1/1000	0100	1-102-321-11	OLITAWIO OTIII	10011	J /0	30 V
RN201 1-233-576-11 RES, CHIP NETWORK 100 C164 1-162-977-11 CERAMIC CHIP 0.47uF 10.00% 10V		R1134	1-216-821-11	METAL CHIP	1K	5%	1/16W	C160	1-162-927-11	CERAMIC CHIP	100PF	5%	50V
RN201 1-233-576-11 RES, CHIP NETWORK 100 RN202 1-233-576-11 RES, CHIP NETWORK 100								C161	1-162-970-11	CERAMIC CHIP	0.01uF	10%	
RN201				< NETWORK >				C162	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
RN202 1-233-576-11 RES, CHIP NETWORK 100 C165 1-162-968-11 CERAMIC CHIP 0.0047uF 10.00% 10V C167 1-164-245-11 CERAMIC CHIP 0.015uF 10.00% 25V C169 1-164-156-11 CERAMIC CHIP 0.015uF 0.015uF 25V C173 1-164-156-11 CERAMIC CHIP 0.10F 25V C173 1-164-156-11 CERAMIC CHIP 0.01F 25V C174 1-162-970-11 CERAMIC CHIP 0.01F 10V C181 1-126-206-11 ELECT CHIP 10UF 25V C183 1-164-156-11 CERAMIC CHIP 0.1UF 25V C183 1-164-156-11 CERAMIC CHIP 0.01F 25V C185 1-131-872-11 CERAMIC CHIP 0.00F 10W 630V C192 1-164-156-11 CERAMIC CHIP 0.00F 20% 6.3V C193 1-126-206-11 ELECT CHIP 100UF 25V C195 1-164-156-11 CERAMIC CHIP 0.1UF 25V C195 1-164-156-11 CERAMIC CHIP 0.0068uF 10% 25V C196 1-164-156-11 CERAMIC CHIP 0.0068uF 10% 25V C196 1-164-156-11 CERAMIC CHIP 0.0068uF 10													
C165				,				C164	1-162-927-11	CERAMIC CHIP	100PF	5%	50V
C166 1-125-891-11 CERAMIC CHIP 0.47uF 10.00% 10V 10.00% 25V 10.00% 25		RN202	1-233-576-11	RES, CHIP NETWO	ORK 100								
RV101 1-238-602-11 RES, ADJ, CARBON 47K C169 1-164-156-11 CERAMIC CHIP 0.1uF 25V													
RV101 1-238-602-11 RES, ADJ, CARBON 47K C169 1-164-156-11 CERAMIC CHIP 0.1uF 25V				< VARIABLE RESI	STUR >								
C173		D\/101	1 220 602 11	DEC ADI CADDO	N 471/							10.00%	
X201		NVIUI	1-230-002-11	neo, ADJ, GANDO	IN 47 IX								
X201 1-579-834-11 VIBRATOR, CRYSTAL 33.8688MHz ***********************************				< VIBRATOR >				0170	1 104 100 11	OLITAWIO OTIII	o. rui		201
X201 1-579-834-11 VIBRATOR, CRYSTAL 33.8688MHz C180 1-117-370-11 CERAMIC CHIP 10uf 10V								C174	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
A-4726-344-A BD (MD) BOARD, COMPLETE **********************************		X201	1-579-834-11	VIBRATOR, CRYS	TAL 33.8688	3MHz		C180	1-117-370-11	CERAMIC CHIP	10uF		10V
A-4726-344-A BD (MD) BOARD, COMPLETE ******************************* C183 1-164-156-11 CERAMIC CHIP 0.1uF 25V C184 1-117-970-11 ELECT CHIP 22uF 20.00% 10V C185 1-131-872-11 CERAMIC CHIP 1000F 10% 630V C191 1-126-206-11 ELECT CHIP 100uF 20% 6.3V C102 1-135-259-11 TANTAL. CHIP 10uF 20.00% 6.3V C103 1-162-970-11 CERAMIC CHIP 0.01uF 10% 25V C104 1-164-227-11 CERAMIC CHIP 0.02uF 10% 25V C105 1-115-416-11 CERAMIC CHIP 0.01uF 5.00% 25V C106 1-162-970-11 CERAMIC CHIP 0.01uF 10% 25V C107 1-162-970-11 CERAMIC CHIP 0.01uF 10% 25V C108 1-162-970-11 CERAMIC CHIP 0.01uF 10% 25V C109 1-164-677-11 CERAMIC CHIP 0.03uF 10% 25V C109 1-164-156-11 CERAMIC CHIP 0.1uF 25V C190 1-164-156-11 CERAMIC CHIP 0.1uF 25V	*	******	******	******	*****	*****	*****	C181	1-126-206-11	ELECT CHIP	100uF	20%	6.3V
**************************************								C182	1-163-038-00	CERAMIC CHIP	0.1uF		25V
C184 1-117-970-11 ELECT CHIP 22uF 20.00% 10V C185 1-131-872-11 CERAMIC CHIP 1000F 10% 630V C191 1-126-206-11 ELECT CHIP 1000F 20% 6.3V C192 1-164-156-11 CERAMIC CHIP 0.1uF 25V C103 1-162-970-11 CERAMIC CHIP 0.01uF 10% 25V C105 1-115-416-11 CERAMIC CHIP 0.001uF 5.00% 25V C106 1-162-970-11 CERAMIC CHIP 0.01uF 10% 25V C106 1-162-970-11 CERAMIC CHIP 0.01uF 25V C107 1-162-970-11 CERAMIC CHIP 0.0068uF 10% 25V C108 1-164-677-11 CERAMIC CHIP 0.0068uF 10% 25V C109 1-164-677-11 CERAMIC CHIP 0.008uF 10% 25V C109 1-164-156-11 CERAMIC CHIP 0.008uF 10% 25V C109 1-16			A-4726-344-A	, , .				C183	1-164-156-11	CERAMIC CHIP	0.1uF		25V
C185 1-131-872-11 CERAMIC CHIP 1000F 10% 630V C191 1-126-206-11 ELECT CHIP 1000F 20% 6.3V C191 1-126-206-11 ELECT CHIP 1000F 20% 6.3V C192 1-164-156-11 CERAMIC CHIP 0.1uF 25V C193 1-162-970-11 CERAMIC CHIP 0.01uF 10% 25V C193 1-164-27-11 CERAMIC CHIP 0.001uF 10% 25V C195 1-164-156-11 CERAMIC CHIP 0.01uF 25V C195 1-164-156-11 CERAMIC CHIP 0.1uF 25V C196 1-164-156-				*****	*****								
C191 1-126-206-11 ELECT CHIP 100uF 20% 6.3V C192 1-164-156-11 CERAMIC CHIP 0.1uF 25V C193 1-162-970-11 CERAMIC CHIP 0.001uF 10% 25V C194 1-164-27-11 CERAMIC CHIP 0.001uF 5.00% 25V C195 1-164-156-11 CERAMIC CHIP 0.1uF 25V C196 1-164-156-11 CER													
C101 1-135-259-11 TANTAL. CHIP 10uF 20.00% 6.3V C192 1-164-156-11 CERAMIC CHIP 0.1uF 25V C102 1-135-259-11 TANTAL. CHIP 10uF 20.00% 6.3V C103 1-162-970-11 CERAMIC CHIP 0.01uF 10% 25V C104 1-164-227-11 CERAMIC CHIP 0.02uF 10% 25V C105 1-115-416-11 CERAMIC CHIP 0.001uF 5.00% 25V C195 1-164-156-11 CERAMIC CHIP 0.1uF 25V C196 1-162-970-11 CERAMIC CHIP 0.01uF 25V C196 1-164-156-11 CERAMIC CHIP 0.1uF 25V C196 1-162-970-11 CERAMIC CHIP 0.01uF 25V C196 1-164-156-11 CERAMIC CHIP 0.1uF 25V C19				< CAPACITOR >									
C102 1-135-259-11 TANTAL. CHIP 10uF 20.00% 6.3V C103 1-162-970-11 CERAMIC CHIP 0.01uF 10% 25V C104 1-164-227-11 CERAMIC CHIP 0.02uF 10% 25V C105 1-115-416-11 CERAMIC CHIP 0.001uF 5.00% 25V C106 1-162-970-11 CERAMIC CHIP 0.01uF 10% 25V C106 1-162-970-11 CERAMIC CHIP 0.01uF 10% 25V C107 1-162-970-11 CERAMIC CHIP 0.01uF 10% 25V C108 1-162-969-11 CERAMIC CHIP 0.0068uF 10% 25V C109 1-164-677-11 CERAMIC CHIP 0.033uF 10.00% 16V C193 1-126-206-11 ELECT CHIP 100uF 20% 6.3V C194 1-164-156-11 CERAMIC CHIP 0.1uF 25V C195 1-164-156-11 CERAMIC CHIP 0.1uF 25V C196 1-164-156-11 CERAMIC CHIP		C101	1 105 050 11	TANTAL CLUD	10uE	20.000/	6 21/					20%	
C103 1-162-970-11 CERAMIC CHIP 0.01uF 10% 25V C104 1-164-227-11 CERAMIC CHIP 0.022uF 10% 25V C105 1-115-416-11 CERAMIC CHIP 0.001uF 5.00% 25V C106 1-162-970-11 CERAMIC CHIP 0.01uF 10% 25V C106 1-162-970-11 CERAMIC CHIP 0.01uF 10% 25V C107 1-162-970-11 CERAMIC CHIP 0.01uF 10% 25V C108 1-162-969-11 CERAMIC CHIP 0.0068uF 10% 25V C109 1-164-677-11 CERAMIC CHIP 0.033uF 10.00% 16V												20%	
C104 1-164-227-11 CERAMIC CHIP 0.022uF 10% 25V C105 1-115-416-11 CERAMIC CHIP 0.001uF 5.00% 25V C195 1-164-156-11 CERAMIC CHIP 0.1uF 25V C196 1-162-970-11 CERAMIC CHIP 0.01uF 10% 25V C107 1-162-970-11 CERAMIC CHIP 0.01uF 10% 25V C108 1-162-969-11 CERAMIC CHIP 0.0068uF 10% 25V C109 1-164-677-11 CERAMIC CHIP 0.033uF 10.00% 16V								0133	1-120-200-11	LLLUI UNIF	TOUUF	ZU /0	0.01
C105 1-115-416-11 CERAMIC CHIP 0.001uF 5.00% 25V C196 1-164-156-11 CERAMIC CHIP 0.1uF 25V C196 1-162-970-11 CERAMIC CHIP 0.01uF 10% 25V C107 1-162-970-11 CERAMIC CHIP 0.01uF 10% 25V C108 1-162-969-11 CERAMIC CHIP 0.0068uF 10% 25V C109 1-164-677-11 CERAMIC CHIP 0.033uF 10.00% 16V C195 1-164-156-11 CERAMIC CHIP 0.1uF 25V C1401 1-117-720-11 CERAMIC CHIP 4.7uF 10V C109 1-164-677-11 CERAMIC CHIP 0.033uF 10.00% 16V								C194	1-164-156-11	CERAMIC CHIP	0.1uE		25V
C196 1-162-970-11 CERAMIC CHIP 0.01uF 10% 25V C107 1-162-970-11 CERAMIC CHIP 0.01uF 10% 25V C108 1-162-969-11 CERAMIC CHIP 0.0068uF 10% 25V C109 1-164-677-11 CERAMIC CHIP 0.033uF 10.00% 16V													
C106 1-162-970-11 CERAMIC CHIP 0.01uF 10% 25V C1401 1-117-720-11 CERAMIC CHIP 4.7uF 10V C107 1-162-970-11 CERAMIC CHIP 0.01uF 10% 25V C108 1-162-969-11 CERAMIC CHIP 0.0068uF 10% 25V C109 1-164-677-11 CERAMIC CHIP 0.033uF 10.00% 16V		5.00	5 110 11		3.00 iui	2.30/0							
C107 1-162-970-11 CERAMIC CHIP 0.01uF 10% 25V C108 1-162-969-11 CERAMIC CHIP 0.0068uF 10% 25V C109 1-164-677-11 CERAMIC CHIP 0.033uF 10.00% 16V		C106	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V						
C109 1-164-677-11 CERAMIC CHIP 0.033uF 10.00% 16V					0.01uF	10%	25V						
C109 1-164-677-11 CERAMIC CHIP 0.033uF 10.00% 16V		C108	1-162-969-11	CERAMIC CHIP	0.0068uF	10%	25V						
C110 1-163-038-00 CERAMIC CHIP 0.1uF 25V					0.033uF	10.00%	16V						
		C110	1-163-038-00	CERAMIC CHIP	0.1uF		25V						

HCD-C5

BD (MD)

B (N		5		5 .	l B (N	5 . 1	5			
Ref. No.	Part No.	<u>Description</u>		<u>Remarks</u>	Ref. No.	Part No.	Description			<u>Remarks</u>
		< CONNECTOR >			Q133		TRANSISTOR	UN5214-T		
CN101	1-766-833-21	CONNECTOR, FFO	C/EDC (7IE) 21D		Q134 Q181	8-729-402-93 8-729-018-75	TRANSISTOR	UN5214-T 2SJ278M		
CN101	1-784-835-21		(LIF(NON-ZIF))27P		Q182		TRANSISTOR	2SK1764k		
CN103	1-784-869-21		(LIF(NON-ZIF))17P		4.02	0 120 011 00	110.01010101	201117011		
* CN104	1-580-055-21	PIN, CONNECTOR					< RESISTOR >			
CN105	1-784-859-21	CONNECTOR, FFO	C(LIF(NON-ZIF))7P							
					R101	1-216-829-11		4.7K	5%	1/16W
		< DIODE >			R102	1-216-853-11		470K	5%	1/16W
D101	8-719-988-61	DIODE 1SS355T	ΓΕ_17		R103 R104	1-216-863-11 1-216-853-11		3.3M 470K	5% 5%	1/16W 1/16W
D101	8-719-080-81	DIODE FS1J6	L-17		R105	1-216-825-11		2.2K	5%	1/16W
D183	8-719-080-81	DIODE FS1J6				. 2.0 020			• , ,	.,
					R106	1-216-825-11		2.2K	5%	1/16W
		< IC >			R107	1-216-825-11		2.2K	5%	1/16W
10404	0.750.000.05	10 074050045			R108	1-216-833-11		10K	5%	1/16W
IC101 IC102	8-752-080-95 8-759-473-51	IC CXA2523AR IC TLV2361CDB	V		R109 R110	1-216-845-11 1-216-845-11		100K 100K	5% 5%	1/16W 1/16W
IC102	8-759-836-79	IC BH6519FS-E2			NIIU	1-210-045-11	METAL CHIP	TOUR	J /0	1/1000
IC151		IC CXD2662R	-		R111	1-216-833-11	METAL CHIP	10K	5%	1/16W
IC153		IC MSM51V440	0D-10TSK-FS		R112	1-216-829-11		4.7K	5%	1/16W
					R113	1-216-833-11		10K	5%	1/16W
IC181		IC MC74ACT08I	OTR2		R114	1-216-827-11		3.3K	5%	1/16W
IC190	8-759-677-64				R115	1-216-833-11	METAL CHIP	10K	5%	1/16W
IC195	8-759-640-41	IC BR24C08F-E2	2		R116	1-216-839-11	METAL CHIP	33K	5%	1/16W
		< CONDUCTOR >			R117	1-216-837-11		22K	5%	1/16W
		(00115001011)			R118	1-218-855-11		2.2K	0.5%	1/16W
JW201	1-216-295-00	SHORT	0		R119	1-218-863-11		4.7K	0.5%	1/16W
JW202	1-216-295-00		0		R120	1-218-889-11	METAL CHIP	56K	0.5%	1/16W
JW203	1-216-295-00		0							
JW903	1-216-295-00		0		R121	1-218-863-11		4.7K	0.5%	1/16W
JW904	1-216-295-00	SHUKI	U		R122 R123	1-218-855-11 1-216-819-11		2.2K 680	0.5% 5%	1/16W 1/16W
		< CONDUCTOR /	FERRITE BEAD >		R124	1-216-809-11		100	5%	1/16W
		(001150010117	TETTITE BEAB		R125	1-216-815-11		330	5%	1/16W
L101	1-500-245-11	FERRITE	0uH							
L102	1-500-245-11		0uH		R126	1-216-819-11		680	5%	1/16W
L103	1-500-245-11		0uH		R127	1-216-845-11		100K	5%	1/16W
L105	1-414-235-22		0uH		R128	1-219-724-11 1-216-298-00		1	1%	1/4W
L106	1-500-245-11	FERRIIE	0uH		R129 R130	1-216-298-00		2.2 4.7K	5% 5%	1/10W 1/16W
L121	1-500-245-11	FERRITE	0uH		11100	1-210-029-11	WEIAL OIII	7.71	J /0	1/1000
L122	1-500-245-11		0uH		R131	1-216-833-11	METAL CHIP	10K	5%	1/16W
L131	1-500-245-11	FERRITE	0uH		R132	1-216-839-11	METAL CHIP	33K	5%	1/16W
L141	1-216-296-11		0		R133	1-216-821-11		1K	5%	1/16W
L142	1-216-296-11	SHORT	0		R134	1-216-821-11		1K	5%	1/16W
L143	1-216-296-11	CHUDT	0		R135	1-216-821-11	METAL CHIP	1K	5%	1/16W
L143 L144	1-216-296-11		0		R136	1-216-302-00	METAL CHIP	2.7	5%	1/10W
L145	1-216-296-11		0		R138	1-216-833-11		10K	5%	1/16W
L146	1-469-855-21	FERRITE	0uH		R150	1-216-833-11		10K	5%	1/16W
L147	1-469-855-21	FERRITE	0uH		R151	1-216-833-11		10K	5%	1/16W
1.461	4 500 0:= ::	CEDD'TE	0.11		R153	1-216-833-11	METAL CHIP	10K	5%	1/16W
L161 L171	1-500-245-11 1-500-245-11		OuH OuH		Diec	1-216-864-11	METAL CLUD	0	E0/	1/16W
L171 L180	1-300-245-11		OuH		R155 R156	1-216-864-11		0	5% 5%	1/16W
L181	1-469-855-21		0uH		R158	1-216-809-11		100	5%	1/16W
L182	1-500-245-11		0uH		R162	1-216-833-11		10K	5%	1/16W
					R167	1-216-833-11	METAL CHIP	10K	5%	1/16W
L183	1-216-296-11		0						= c:	
L184	1-216-296-11	SHORT	0		R168	1-216-845-11		100K	5%	1/16W
		< TRANSISTOR >			R169 R170	1-216-855-11 1-216-827-11		680K 3.3K	5% 5%	1/16W 1/16W
		< ITANSISTUR >	•		R170	1-216-821-11		3.3K 1K	5% 5%	1/16W
Q101	8-729-403-35	TRANSISTOR	UN5113-TX		R173	1-216-821-11		1K	5%	1/16W
Q121		TRANSISTOR	UN5113-TX					•		. +-*
Q122		TRANSISTOR	2SB798-T1DK		R174	1-216-811-11		150	5%	1/16W
Q131		TRANSISTOR	2SA1576A-T106-Q	R	R177	1-216-805-11		47	5%	1/16W
Q132	8-729-903-10	TRANSISTOR	FMW1-T-148		R179	1-216-295-00		0 471/	E0/	1/1014
					R181 R182	1-216-841-11 1-216-841-11		47K 47K	5% 5%	1/16W 1/16W
					1 11102	1-210-041-11	WIL IAL UITE	711	J /0	1/1000

					_					V	er i.i a	2001.09
			BD	(MD)	COI	NNECT	OR	HF	JACK	ME	DIG	ITAL
Ref. No.	Part No.	Description			Remarks	Ref. No.	Part No.		Description			Remarks
R183	1-216-841-11	METAL CHIP	47K	5%	1/16W	110111101	<u>. a.c.1101</u>		< CONNECTOR >			<u> </u>
R184	1-220-942-11	METAL CHIP	3.3	1%	1/1000				COUNTEDION			
R185	1-220-942-11		3.3	1%	1/4	* CN107	1-568-93	34-11	PIN, CONNECTOR	R 7P		
R195	1-216-833-11		10K	5%	1/16W				· IACK ›			
R196	1-216-833-11	METAL CHIP	10K	5%	1/16W				< JACK >			
R197	1-216-833-11		10K	5%	1/16W	J101	1-793-43		JACK (SMALL TY			
R218	1-216-864-11	METAL CHIP	0	5%	1/16W	J102	1-793-43	39-11	JACK (SMALL TY	PE) (TAPE	IN)	
		< SWITCH >							< RESISTOR >			
S101	1-762-596-21	SWITCH, PUSH (1 KFY) (I II	/IIT-IN)		R101	1-216-84	15-11	METAL CHIP	100K	5%	1/16W
S103		SWITCH, PUSH (, ,	,		R151			METAL CHIP	100K	5%	1/16W
S104		SWITCH, PUSH (*******	******	****	******	******	*****	*****
S105	1-771-955-21	SWITCH, PUSH (1 KEY) (RE	C)			Δ_4725_7	732 <u>-</u> A	MD DIGITAL BOA	BD COMP	LETE	
		< VIBRATOR >					N 4720 7	02 A	******	-		
X171	1-781-569-21	OSCILLATOR, CR	YSTAL 90N	ЛHz					< CAPACITOR >			
		*******			*****							
	1 000 100 11	CONNECTOR ROA	N D D			C200	1-124-58			100uF	20%	10V
	1-082-100-11	CONNECTOR BOA				C201 C202	1-104-15		CERAMIC CHIP	0.1uF 47uF	20%	25V 16V
						C203			CERAMIC CHIP	0.1uF	2070	25V
		< CONNECTOR >				C204	1-124-26	61-00	ELECT	10uF	20%	50V
CN1	1-815-750-11	CONNECTOR				C205	1-164-15	56-11	CERAMIC CHIP	0.1uF		25V
		*******	******	*****	*****	C207	1-164-15		CERAMIC CHIP	0.1uF		25V
	1 001 710 11	UD DOADD				C208	1-164-15		CERAMIC CHIP	0.1uF		25V
	1-681-712-11	HP BUARD ******				C211 C212	1-164-15 1-124-58		CERAMIC CHIP	0.1uF 100uF	20%	25V 10V
						OLIZ	1 121 00	71 00	LLLOT	Toour	2070	101
		< CAPACITOR >				C213			CERAMIC CHIP	0.1uF	000/	25V
C337	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V	C214 C215	1-124-26 1-124-26			10uF 10uF	20% 20%	50V 50V
C338	1-162-294-31		0.001uF	10%	50V	C216			CERAMIC CHIP	0.1uF	2070	25V
C339	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V	C217	1-164-15	6-11	CERAMIC CHIP	0.1uF		25V
		< CONNECTOR >				C218	1-162-96	64-11	CERAMIC CHIP	0.001uF	10%	50V
						C219			CERAMIC CHIP	0.001uF	10%	50V
* CN109 CN110		PIN, CONNECTOR PIN, CONNECTOR				C221 C222	1-164-15 1-124-58		CERAMIC CHIP	0.1uF 47uF	20%	25V 16V
CIVITO	1-300-403-11	r IIV, CONNECTOR	141			C223			CERAMIC CHIP	0.1uF	20 /0	25V
		< JACK >				0704	4 404 50		EL EOT	400 5	000/	4017
J103	1-794-702-11	JACK, HEADPHOI	NE (PHONE	(S)		C701 C702	1-124-58 1-164-15		CERAMIC CHIP	100uF 0.1uF	20%	10V 25V
0100	170170211	071011, TIE7101	112 (1110112	.0)		C703	1-126-24		ELECT	330uF	20.00%	
		< TRANSISTOR >				C704			CERAMIC CHIP	0.001uF	10%	50V
Q341	8-729-046-97	TRANSISTOR	2SD1938	(F)-T(TX)	SO.	C705	1-162-96	64-11	CERAMIC CHIP	0.001uF	10%	50V
Q391		TRANSISTOR	2SD1938			C706			CERAMIC CHIP	0.01uF	10%	25V
		DEGLOTOR				C707			CERAMIC CHIP	0.01uF	10%	25V
		< RESISTOR >				C719 C723			CERAMIC CHIP CERAMIC CHIP	0.1uF 0.1uF		25V 25V
R337	1-249-407-11	CARBON	150	5%	1/4W F	C726			CERAMIC CHIP	0.1uF		25V
R342	1-249-429-11		10K	5%	1/4W							
R387 R392	1-249-407-11 1-216-833-11		150 10K	5% 5%	1/4W F 1/16W	C730 C738			CERAMIC CHIP CERAMIC CHIP	0.001uF 100PF	10% 5%	50V 50V
		WETAL UNIP				C740			CERAMIC CHIP	100PF	5% 5%	50V 50V
						C742	1-162-92	27-11	CERAMIC CHIP	100PF	5%	50V
	1-681-381-11	JACK BOARD *******				C743	1-162-97	70-11	CERAMIC CHIP	0.01uF	10%	25V
		~~~~~~~~				C748	1-162-92	27-11	CERAMIC CHIP	100PF	5%	50V
		< CAPACITOR >				C749	1-162-97	70-11	CERAMIC CHIP	0.01uF	10%	25V
0404	1 160 007 11	CEDAMIC CLUB	10005	E0/	EOV	C751			CERAMIC CHIP	0.01uF	10%	25V
C101 C122		CERAMIC CHIP CERAMIC CHIP	100PF 1000PF	5%	50V 50V	C756 C791			CERAMIC CHIP CERAMIC CHIP	100PF 0.1uF	5%	50V 25V
					AEP,UK,KR)			•		-		
C151	1-162-927-11	CERAMIC CHIP	100PF	5%	50V	I						

MD DIGITAL PANEL

Ref. No.	Part No.	Description			Remarks	Ref. No.	Part No.	Description			Remarks
	·	•	0.4 5						470	<b>5</b> 0/	
C843	1-164-156-11	CERAMIC CHIP	0.1uF		25V	R220	1-216-817-11	METAL CHIP	470	5%	1/16W
C861	1-164-156-11	CERAMIC CHIP	0.1uF	00 000/	25V	R221	1-216-809-11	METAL CHIP	100	5%	1/16W
C862	1-115-869-11	ELECT	0.33uF	20.00%		R222	1-216-825-11		2.2K	5%	1/16W
C863	1-164-156-11	CERAMIC CHIP	0.1uF		25V	R223	1-216-833-11	METAL CHIP	10K	5%	1/16W
C864	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	R701	1-216-817-11	METAL CHIP	470	5%	1/16W
C871	1-124-584-00		100uF	20%	10V	R702	1-216-809-11	METAL CHIP	100	5%	1/16W
C872	1-164-156-11	CERAMIC CHIP	0.1uF		25V	R717	1-216-833-11	METAL CHIP	10K	5%	1/16W
C873	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	R724	1-216-833-11	METAL CHIP	10K	5%	1/16W
						R726	1-216-831-11	METAL CHIP	6.8K	5%	1/16W
		< CONNECTOR >				R727	1-216-829-11	METAL CHIP	4.7K	5%	1/16W
CN201	1-790-669-21	PIN, CONNECTOR	R (PC BOARI	D) 9P		R730	1-216-833-11	METAL CHIP	10K	5%	1/16W
CN701	1-784-741-11	CONNECTOR, FFC		<i>-,</i> 0.		R743	1-216-833-11	METAL CHIP	10K	5%	1/16W
CN702	1-784-384-11	CONNECTOR, FFC				R749	1-216-833-11	METAL CHIP	10K	5%	1/16W
CN703	1-784-376-11	CONNECTOR, FFC				R751	1-216-833-11	METAL CHIP	10K	5%	1/16W
0117 00	1 701 070 11	OOMMEDION, IT	,,,,,,			R752	1-216-833-11	METAL CHIP	10K	5%	1/16W
		< DIODE >									
						R754	1-216-833-11	METAL CHIP	10K	5%	1/16W
D211	8-719-104-34	DIODE 1S2835-	Γ1			R767	1-216-833-11	METAL CHIP	10K	5%	1/16W
						R768	1-216-833-11	METAL CHIP	10K	5%	1/16W
		< FERRITE BEAD	/ CONDUCT	0R >		R786	1-216-833-11	METAL CHIP	10K	5%	1/16W
						R787	1-216-833-11	METAL CHIP	10K	5%	1/16W
FB217	1-469-116-21	FERRITE	0UH								
FB701	1-469-324-21	FERRITE	0UH			R815	1-216-837-11	METAL CHIP	22K	5%	1/16W
FB702	1-469-324-21	FERRITE	0UH			R816	1-216-841-11	METAL CHIP	47K	5%	1/16W
FB703	1-469-324-21	FERRITE	0UH			R824	1-216-809-11	METAL CHIP	100	5%	1/16W
FB704	1-216-864-11	METAL CHIP	0	5%	1/16W	R861	1-216-849-11	METAL CHIP	220K	5%	1/16W
		10				R862	1-216-845-11	METAL CHIP	100K	5%	1/16W
		< IC >				R863	1-216-837-11	METAL CHIP	22K	5%	1/16W
IC201	8-759-675-78	IC UDA1360TS/I	VI1 118			R871	1-216-829-11		4.7K	5%	1/16W
IC211	8-759-675-77	IC UDA1350AH	VI.IIO			R872	1-216-824-11		1.8K	5%	1/16W
IC701	6-800-339-01	IC M30803MG-A	\U3ED			R873	1-216-825-11	METAL CHIP	2.2K	5%	1/16W
IC861	8-759-481-02	IC M62016L	10011			11070	1 210 020 11	WEIAL OIII	L.LIX	<b>3</b> /0	1/ 10 00
IC871		IC BA6956AN						< VIBRATOR >			
		< CONDUCTOR >				X720		VIBRATOR, CERA *********			<b></b>
JR210	1-216-296-11	SHORT	0			*****	****	****	****	****	****
OTILLIO	. 210 200 11	0110111	· ·				A-4476-936-A	PANEL BOARD, C	OMPLETE		
		< COIL >						******			
L701	1-412-533-21	INDUCTOR	47uH				4-233-850-01	HOLDER (FL)			
2701	1 412 300 21						4 200 000 01	,			
		< TRANSISTOR >						< CAPACITOR >			
Q201	8-729-421-22	TRANSISTOR	LINIOO44 T								
Q202		TRANSISTOR	11012211-1	Χ		C603	1-124-247-11	FLECT	10uF	20.00%	35V
			UN2211-T		)R	C603 C623	1-124-247-11 1-162-306-11		10uF 0.01uF	20.00%	
0211	8-729-026-49	TRANSISTOR	2SA1037A	K-T146-C	ΩR	C623	1-162-306-11	CERAMIC	0.01uF	30.00%	16V
Q211 0861	8-729-026-49 8-729-424-08	TRANSISTOR TRANSISTOR	2SA1037A UN2111-T	K-T146-C X	lR	C623 C624	1-162-306-11 1-162-282-31	CERAMIC CERAMIC	0.01uF 100PF	30.00% 10%	16V 50V
Q861	8-729-026-49 8-729-424-08 8-729-120-28	TRANSISTOR TRANSISTOR TRANSISTOR	2SA1037A UN2111-T 2SC1623-T	.K-T146-C X T1-L5L6	lR	C623 C624 C626	1-162-306-11 1-162-282-31 1-162-927-11	CERAMIC CERAMIC CERAMIC CHIP	0.01uF 100PF 100PF	30.00% 10% 5%	16V 50V 50V
Q861 Q871	8-729-026-49 8-729-424-08 8-729-120-28 8-729-421-22	TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR	2SA1037A UN2111-T: 2SC1623-T UN2211-T:	.K-T146-C X T1-L5L6 X	ΩR	C623 C624 C626 C635	1-162-306-11 1-162-282-31 1-162-927-11 1-124-247-11	CERAMIC CERAMIC CERAMIC CHIP ELECT	0.01uF 100PF 100PF 10uF	30.00% 10% 5% 20.00%	16V 50V 50V 35V
Q861	8-729-026-49 8-729-424-08 8-729-120-28	TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR	2SA1037A UN2111-T 2SC1623-T	.K-T146-C X T1-L5L6 X	ΩR	C623 C624 C626 C635	1-162-306-11 1-162-282-31 1-162-927-11 1-124-247-11 1-126-153-11	CERAMIC CERAMIC CHIP ELECT ELECT	0.01uF 100PF 100PF 10uF 22uF	30.00% 10% 5%	16V 50V 50V 35V 6.3V
Q861 Q871	8-729-026-49 8-729-424-08 8-729-120-28 8-729-421-22	TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR	2SA1037A UN2111-T: 2SC1623-T UN2211-T:	.K-T146-C X T1-L5L6 X	ùR	C623 C624 C626 C635 C636 C637	1-162-306-11 1-162-282-31 1-162-927-11 1-124-247-11 1-126-153-11 1-164-156-11	CERAMIC CERAMIC CHIP ELECT ELECT CERAMIC CHIP	0.01uF 100PF 100PF 10uF 22uF 0.1uF	30.00% 10% 5% 20.00% 20%	16V 50V 50V 35V 6.3V 25V
Q861 Q871	8-729-026-49 8-729-424-08 8-729-120-28 8-729-421-22	TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR	2SA1037A UN2111-T: 2SC1623-T UN2211-T:	.K-T146-C X T1-L5L6 X	ùR	C623 C624 C626 C635 C636 C637 C640	1-162-306-11 1-162-282-31 1-162-927-11 1-124-247-11 1-126-153-11 1-164-156-11 1-162-927-11	CERAMIC CERAMIC CHIP ELECT ELECT CERAMIC CHIP CERAMIC CHIP	0.01uF 100PF 100PF 10uF 22uF 0.1uF 100PF	30.00% 10% 5% 20.00% 20%	16V 50V 50V 35V 6.3V 25V 50V
Q861 Q871 Q872	8-729-026-49 8-729-424-08 8-729-120-28 8-729-421-22 8-729-602-36	TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR  < RESISTOR >	2SA1037A UN2111-T: 2SC1623-1 UN2211-T: 2SA1602T	K-T146-C X T1-L5L6 X P-1EF		C623 C624 C626 C635 C636 C637 C640 C641	1-162-306-11 1-162-282-31 1-162-927-11 1-124-247-11 1-126-153-11 1-164-156-11 1-162-927-11 1-162-970-11	CERAMIC CERAMIC CHIP ELECT ELECT CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP	0.01uF 100PF 100PF 10uF 22uF 0.1uF 100PF 0.01uF	30.00% 10% 5% 20.00% 20% 5% 10%	16V 50V 50V 35V 6.3V 25V 50V 25V
Q861 Q871 Q872 R201	8-729-026-49 8-729-424-08 8-729-120-28 8-729-421-22 8-729-602-36	TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR  TRANSISTOR  < RESISTOR >  RES-CHIP	2SA1037A UN2111-T. 2SC1623- UN2211-T. 2SA1602T	K-T146-C X T1-L5L6 X P-1EF	1/16W	C623 C624 C626 C635 C636 C637 C640	1-162-306-11 1-162-282-31 1-162-927-11 1-124-247-11 1-126-153-11 1-164-156-11 1-162-927-11	CERAMIC CERAMIC CHIP ELECT ELECT CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP	0.01uF 100PF 100PF 10uF 22uF 0.1uF 100PF	30.00% 10% 5% 20.00% 20%	16V 50V 50V 35V 6.3V 25V 50V 25V
Q861 Q871 Q872 R201 R202	8-729-026-49 8-729-424-08 8-729-120-28 8-729-421-22 8-729-602-36 1-218-272-11 1-218-272-11	TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR  TRANSISTOR  < RESISTOR >  RES-CHIP RES-CHIP	2SA1037A UN2111-T: 2SC1623- UN2211-T: 2SA1602T 5.1K 5.1K	.K-T146-C X T1-L5L6 X P-1EF 5% 5%	1/16W 1/16W	C623 C624 C626 C635 C636 C637 C640 C641 C642	1-162-306-11 1-162-282-31 1-162-927-11 1-124-247-11 1-126-153-11 1-164-156-11 1-162-927-11 1-162-306-11	CERAMIC CERAMIC CHIP ELECT ELECT CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP	0.01uF 100PF 100PF 10uF 22uF 0.1uF 100PF 0.01uF 0.01uF	30.00% 10% 5% 20.00% 20% 5% 10% 30.00%	16V 50V 50V 35V 6.3V 25V 50V 25V 16V
Q861 Q871 Q872 R201 R202 R211	8-729-026-49 8-729-424-08 8-729-120-28 8-729-421-22 8-729-602-36 1-218-272-11 1-218-272-11 1-216-813-11	TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR  TRANSISTOR  < RESISTOR >  RES-CHIP RES-CHIP METAL CHIP	2SA1037A UN2111-T. 2SC1623- UN2211-T. 2SA1602T 5.1K 5.1K 220	K-T146-C X T1-L5L6 X P-1EF 5% 5% 5%	1/16W 1/16W 1/16W	C623 C624 C626 C635 C635 C636 C637 C640 C641 C642	1-162-306-11 1-162-282-31 1-162-927-11 1-124-247-11 1-126-153-11 1-164-156-11 1-162-970-11 1-162-306-11 1-162-970-11	CERAMIC CERAMIC CHIP ELECT ELECT CERAMIC CHIP	0.01uF 100PF 100PF 10uF 22uF 0.1uF 100PF 0.01uF 0.01uF	30.00% 10% 5% 20.00% 20% 5% 10%	16V 50V 50V 35V 6.3V 25V 50V 25V 16V
Q861 Q871 Q872 R201 R202 R211 R213	8-729-026-49 8-729-424-08 8-729-120-28 8-729-421-22 8-729-602-36 1-218-272-11 1-218-272-11 1-216-813-11 1-216-833-11	TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR  TRANSISTOR  < RESISTOR >  RES-CHIP RES-CHIP METAL CHIP METAL CHIP	2SA1037A UN2111-T. 2SC1623- UN2211-T. 2SA1602T 5.1K 5.1K 220 10K	K-T146-C X T1-L5L6 X P-1EF 5% 5% 5% 5%	1/16W 1/16W 1/16W 1/16W	C623 C624 C626 C635 C635 C636 C637 C640 C641 C642	1-162-306-11 1-162-282-31 1-162-927-11 1-124-247-11 1-126-153-11 1-164-156-11 1-162-970-11 1-162-306-11 1-162-970-11 1-165-319-91	CERAMIC CERAMIC CHIP ELECT ELECT CERAMIC CHIP	0.01uF 100PF 100PF 10uF 22uF 0.1uF 100PF 0.01uF 0.01uF 0.01uF	30.00% 10% 5% 20.00% 20% 5% 10% 30.00%	16V 50V 50V 35V 6.3V 25V 50V 25V 16V
Q861 Q871 Q872 R201 R202 R211	8-729-026-49 8-729-424-08 8-729-120-28 8-729-421-22 8-729-602-36 1-218-272-11 1-218-272-11 1-216-813-11	TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR  TRANSISTOR  < RESISTOR >  RES-CHIP RES-CHIP METAL CHIP	2SA1037A UN2111-T. 2SC1623- UN2211-T. 2SA1602T 5.1K 5.1K 220	K-T146-C X T1-L5L6 X P-1EF 5% 5% 5%	1/16W 1/16W 1/16W	C623 C624 C626 C635 C635 C636 C637 C640 C641 C642	1-162-306-11 1-162-282-31 1-162-927-11 1-124-247-11 1-126-153-11 1-162-927-11 1-162-970-11 1-162-970-11 1-162-970-11 1-165-319-91 1-162-290-31	CERAMIC CERAMIC CHIP ELECT ELECT CERAMIC CHIP CERAMIC	0.01uF 100PF 100PF 10uF 22uF 0.1uF 100PF 0.01uF 0.01uF 0.01uF 470PF	30.00% 10% 5% 20.00% 20% 5% 10% 30.00% 10%	16V 50V 50V 35V 6.3V 25V 50V 25V 16V 25V 50V 50V
Q861 Q871 Q872 R201 R202 R211 R213 R214	8-729-026-49 8-729-424-08 8-729-120-28 8-729-421-22 8-729-602-36 1-218-272-11 1-218-272-11 1-216-813-11 1-216-809-11	TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR  TRANSISTOR  < RESISTOR >  RES-CHIP RES-CHIP METAL CHIP METAL CHIP METAL CHIP METAL CHIP	2SA1037A UN2111-T. 2SC1623- UN2211-T. 2SA1602T 5.1K 5.1K 220 10K	K-T146-C X T1-L5L6 X P-1EF 5% 5% 5% 5% 5%	1/16W 1/16W 1/16W 1/16W 1/16W	C623 C624 C626 C635 C635 C636 C637 C640 C641 C642	1-162-306-11 1-162-282-31 1-162-927-11 1-124-247-11 1-126-153-11 1-162-927-11 1-162-970-11 1-162-970-11 1-165-319-91 1-162-290-31 1-162-286-31	CERAMIC CERAMIC CHIP ELECT ELECT CERAMIC CHIP CERAMIC	0.01uF 100PF 100PF 10uF 22uF 0.1uF 100PF 0.01uF 0.01uF 0.01uF 470PF 220PF	30.00% 10% 5% 20.00% 20% 5% 10% 30.00% 10% 10% 10.00%	16V 50V 50V 35V 6.3V 25V 50V 25V 16V 25V 50V 50V 50V
Q861 Q871 Q872 R201 R202 R211 R213 R214	8-729-026-49 8-729-424-08 8-729-120-28 8-729-421-22 8-729-602-36 1-218-272-11 1-218-272-11 1-216-813-11 1-216-809-11 1-216-833-11	TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR  TRANSISTOR  < RESISTOR >  RES-CHIP RES-CHIP METAL CHIP METAL CHIP METAL CHIP METAL CHIP METAL CHIP	2SA1037A UN2111-T: 2SC1623- UN2211-T: 2SA1602T 5.1K 5.1K 220 10K 100	K-T146-C X T1-L5L6 X P-1EF 5% 5% 5% 5% 5%	1/16W 1/16W 1/16W 1/16W 1/16W	C623 C624 C626 C635 C635 C636 C637 C640 C641 C642 C643 C646 C647	1-162-306-11 1-162-282-31 1-162-927-11 1-124-247-11 1-126-153-11 1-162-927-11 1-162-970-11 1-162-970-11 1-162-970-11 1-165-319-91 1-162-290-31	CERAMIC CERAMIC CHIP ELECT ELECT CERAMIC CHIP CERAMIC	0.01uF 100PF 100PF 10uF 22uF 0.1uF 100PF 0.01uF 0.01uF 0.01uF 470PF	30.00% 10% 5% 20.00% 20% 5% 10% 30.00% 10%	16V 50V 50V 35V 6.3V 25V 50V 25V 16V 25V 50V 50V 50V
Q861 Q871 Q872 R201 R202 R211 R213 R214 R215 R216	8-729-026-49 8-729-424-08 8-729-120-28 8-729-602-36 1-218-272-11 1-218-272-11 1-216-813-11 1-216-809-11 1-216-833-11 1-216-833-11 1-216-833-11	TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR  TRANSISTOR  < RESISTOR >  RES-CHIP RES-CHIP METAL CHIP	2SA1037A UN2111-T: 2SC1623- UN2211-T: 2SA1602T 5.1K 5.1K 220 10K 100	K-T146-C X T1-L5L6 X P-1EF 5% 5% 5% 5% 5% 5%	1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W	C623 C624 C626 C635 C635 C636 C637 C640 C641 C642 C643 C646 C647 C648	1-162-306-11 1-162-282-31 1-162-927-11 1-124-247-11 1-126-153-11 1-162-927-11 1-162-970-11 1-162-306-11 1-162-319-91 1-162-290-31 1-162-286-31 1-162-286-31	CERAMIC CERAMIC CHIP ELECT ELECT CERAMIC CHIP CERAMIC CERAMIC CERAMIC	0.01uF 100PF 100PF 10uF 22uF 0.1uF 100PF 0.01uF 0.01uF 0.01uF 470PF 220PF 220PF	30.00% 10% 5% 20.00% 20% 5% 10% 30.00% 10% 10.00%	16V 50V 50V 35V 6.3V 25V 50V 25V 16V 25V 50V 50V 50V 50V
R201 R202 R211 R213 R214 R215 R216 R217	8-729-026-49 8-729-424-08 8-729-120-28 8-729-602-36 1-218-272-11 1-218-272-11 1-216-813-11 1-216-809-11 1-216-833-11 1-216-833-11 1-216-809-11	TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR  TRANSISTOR  < RESISTOR >  RES-CHIP RES-CHIP METAL CHIP	2SA1037A UN2111-T: 2SC1623- UN2211-T: 2SA1602T 5.1K 5.1K 220 10K 100	K-T146-C X T1-L5L6 X P-1EF 5% 5% 5% 5% 5% 5% 5%	1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W	C623 C624 C626 C635 C635 C636 C637 C640 C641 C642 C643 C646 C647 C648	1-162-306-11 1-162-282-31 1-162-927-11 1-124-247-11 1-126-153-11 1-162-927-11 1-162-970-11 1-162-306-11 1-162-306-11 1-162-290-31 1-162-286-31 1-162-286-31 1-162-286-31	CERAMIC CERAMIC CHIP ELECT ELECT CERAMIC CHIP CERAMIC CERAMIC CERAMIC CERAMIC	0.01uF 100PF 100PF 10uF 22uF 0.1uF 100PF 0.01uF 0.01uF 0.01uF 470PF 220PF 220PF	30.00% 10% 5% 20.00% 20% 5% 10% 30.00% 10% 10.00% 10.00%	16V 50V 50V 35V 6.3V 25V 50V 25V 16V 25V 50V 50V 50V 50V
R201 R202 R211 R213 R214 R215 R216 R217 R218	8-729-026-49 8-729-424-08 8-729-120-28 8-729-602-36 1-218-272-11 1-218-272-11 1-216-813-11 1-216-809-11 1-216-833-11 1-216-833-11 1-216-833-11	TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR  TRANSISTOR  < RESISTOR >  RES-CHIP RES-CHIP METAL CHIP	2SA1037A UN2111-T: 2SC1623- UN2211-T: 2SA1602T 5.1K 5.1K 220 10K 100	K-T146-C X T1-L5L6 X P-1EF 5% 5% 5% 5% 5% 5%	1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W	C623 C624 C626 C635  C636 C637 C640 C641 C642  C643 C646 C647 C648 C649	1-162-306-11 1-162-282-31 1-162-927-11 1-124-247-11 1-126-153-11 1-162-927-11 1-162-970-11 1-162-306-11 1-162-319-91 1-162-290-31 1-162-286-31 1-162-286-31	CERAMIC CERAMIC CHIP ELECT ELECT CERAMIC CHIP CERAMIC CERAMIC CERAMIC CERAMIC	0.01uF 100PF 100PF 10uF 22uF 0.1uF 100PF 0.01uF 0.01uF 0.01uF 470PF 220PF 220PF	30.00% 10% 5% 20.00% 20% 5% 10% 30.00% 10% 10.00%	16V 50V 50V 35V 6.3V 25V 50V 25V 16V 25V 50V 50V 50V 50V
R201 R202 R211 R213 R214 R215 R216 R217	8-729-026-49 8-729-424-08 8-729-120-28 8-729-602-36 1-218-272-11 1-218-272-11 1-216-813-11 1-216-809-11 1-216-833-11 1-216-833-11 1-216-809-11	TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR  TRANSISTOR  < RESISTOR >  RES-CHIP RES-CHIP METAL CHIP	2SA1037A UN2111-T: 2SC1623- UN2211-T: 2SA1602T 5.1K 5.1K 220 10K 100 10K 10K	K-T146-C X T1-L5L6 X P-1EF 5% 5% 5% 5% 5% 5% 5%	1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W	C623 C624 C626 C635  C636 C637 C640 C641 C642  C643 C646 C647 C648 C649  C650	1-162-306-11 1-162-282-31 1-162-927-11 1-124-247-11 1-126-153-11 1-162-927-11 1-162-970-11 1-162-306-11 1-162-306-11 1-162-290-31 1-162-286-31 1-162-286-31 1-162-286-31	CERAMIC CERAMIC CHIP ELECT ELECT CERAMIC CHIP CERAMIC CERAMIC CERAMIC CERAMIC CERAMIC CERAMIC	0.01uF 100PF 100PF 10uF 22uF 0.1uF 100PF 0.01uF 0.01uF 0.01uF 470PF 220PF 220PF	30.00% 10% 5% 20.00% 20% 5% 10% 30.00% 10% 10.00% 10.00%	16V 50V 50V 35V 6.3V 25V 50V 25V 16V 25V 50V 50V 50V 50V 50V
R201 R202 R211 R213 R214 R215 R216 R217 R218	8-729-026-49 8-729-424-08 8-729-120-28 8-729-602-36 1-218-272-11 1-218-272-11 1-216-813-11 1-216-833-11 1-216-833-11 1-216-833-11 1-216-809-11 1-216-809-11	TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR  TRANSISTOR  < RESISTOR >  RES-CHIP METAL CHIP	2SA1037A UN2111-T: 2SC1623- UN2211-T: 2SA1602T 5.1K 5.1K 220 10K 100 10K 10K 100	K-T146-C X T1-L5L6 X P-1EF 5% 5% 5% 5% 5% 5% 5% 5% 5%	1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W	C623 C624 C626 C635  C636 C637 C640 C641 C642  C643 C646 C647 C648 C649  C650 C651	1-162-306-11 1-162-282-31 1-162-927-11 1-124-247-11 1-126-153-11 1-162-927-11 1-162-970-11 1-162-306-11 1-162-306-11 1-162-290-31 1-162-286-31 1-162-286-31 1-162-286-31 1-162-286-31	CERAMIC CERAMIC CHIP ELECT ELECT CERAMIC CHIP CERAMIC CERAMIC CERAMIC CERAMIC CERAMIC CERAMIC CERAMIC CERAMIC CERAMIC	0.01uF 100PF 100PF 10uF 22uF 0.1uF 100PF 0.01uF 0.01uF 0.01uF 470PF 220PF 220PF 220PF	30.00% 10% 5% 20.00% 20% 5% 10% 30.00% 10% 10.00% 10.00% 10.00%	16V 50V 50V 35V 6.3V 25V 50V 25V 16V 25V 50V 50V 50V 50V 50V 50V
R201 R202 R211 R213 R214 R215 R216 R217 R218	8-729-026-49 8-729-424-08 8-729-120-28 8-729-602-36 1-218-272-11 1-218-272-11 1-216-813-11 1-216-833-11 1-216-833-11 1-216-833-11 1-216-809-11 1-216-809-11	TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR  TRANSISTOR  < RESISTOR >  RES-CHIP METAL CHIP	2SA1037A UN2111-T: 2SC1623- UN2211-T: 2SA1602T 5.1K 5.1K 220 10K 100 10K 10K 100	K-T146-C X T1-L5L6 X P-1EF 5% 5% 5% 5% 5% 5% 5% 5% 5%	1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W	C623 C624 C626 C635  C636 C637 C640 C641 C642  C643 C646 C647 C648 C649  C650 C651 C652	1-162-306-11 1-162-282-31 1-162-927-11 1-124-247-11 1-126-153-11 1-164-156-11 1-162-970-11 1-162-306-11 1-162-306-11 1-162-306-11 1-162-286-31 1-162-286-31 1-162-286-31 1-162-286-31 1-162-286-31 1-162-286-31	CERAMIC CERAMIC CHIP ELECT ELECT CERAMIC CHIP CERAMIC	0.01uF 100PF 100PF 10uF 22uF 0.1uF 100PF 0.01uF 0.01uF 470PF 220PF 220PF 220PF 220PF 220PF	30.00% 10% 5% 20.00% 20% 5% 10% 30.00% 10% 10.00% 10.00% 10.00% 10.00%	16V 50V 50V 35V 6.3V 25V 50V 25V 16V 25V 50V 50V 50V 50V 50V 50V 50V

**PANEL** 

**POWER** 

Ref. No.	Part No.	<u>Description</u>			<b>Remarks</b>	Ref. No.	Part No.		<b>Description</b>			<u>Remarks</u>
C655	1-162-286-31	CERAMIC	220PF	10.00%	50\/	R624	1-249-43	3-11	CARBON	22K	5%	1/4W
C656	1-162-286-31		220PF	10.00%		R639	1-216-79		METAL CHIP	10	5%	1/16W
C657	1-162-286-31		220PF	10.00%		R640	1-249-41		CARBON	470	5%	1/4W
C658	1-162-286-31		220PF	10.00%		R641	1-216-819		METAL CHIP	680	5%	1/4W 1/16W
									-			
C659	1-162-286-31	CERAMIC	220PF	10.00%	507	R642	1-216-82	1-11	METAL CHIP	1K	5%	1/16W
C660	1-162-286-31	CEDAMIC	220PF	10.00%	EOV/	R643	1-216-81	7 1 1	METAL CHIP	470	5%	1/16W
							1-216-819		METAL CHIP			
C661	1-162-286-31		220PF	10.00%		R644			-	680	5%	1/16W
C662	1-162-286-31		220PF	10.00%		R645	1-216-82		METAL CHIP	1K	5%	1/16W
C664	1-124-247-11		10uF	20.00%		R646	1-216-81			470	5%	1/16W
C665	1-124-589-11	ELECT	47uF	20%	16V	R647	1-216-819	9-11	METAL CHIP	680	5%	1/16W
		< CONNECTOR >				R648	1-216-82	1-11	METAL CHIP	1K	5%	1/16W
* CN601	1-784-738-11	CONNECTOR, FFC	C 16P						< SWITCH >			
		< DIODE >				S602	1-762-87	5-21	SWITCH, KEYBO			
									,	REC/REC IT/		NORMAL)
D601		DIODE SEL2210				S603	1-762-87					
D602		DIODE SEL5E23			<b>)</b> )	S604			SWITCH, KEYBO			
D603		DIODE SEL5E23				S605	1-762-87				TION●)	
D604		DIODE SEL5E23				S606	1-762-87	5-21	SWITCH, KEYBO	ARD ( <b>I</b> /७)		
D605	8-719-072-76	DIODE SEL5E23	C-TP15 (CI	D <b>_</b> )								
						S607	1-762-87					
D606	8-719-072-76	DIODE SEL5E23	C-TP15 (►	·II)		S608	1-762-87	5-21	SWITCH, KEYBO	ARD (►II)		
D607	8-719-072-76	DIODE SEL5E23	C-TP15 (■	)		S609	1-762-87	5-21	SWITCH, KEYBO	ARD (■)		
D608	8-719-072-76	DIODE SEL5E23	C-TP15 (►	<b>►</b> I)		S610	1-762-87	5-21	SWITCH, KEYBO	ARD (CD SY	'NC HIGH	)
D609	8-719-072-76	DIODE SEL5E23	C-TP15 (Ì <b>◄</b>	<b>(</b>		S611	1-762-87	5-21	SWITCH, KEYBO	ARD (MD📤	)	•
D610		DIODE SEL5E23								•	,	
						S612	1-762-87	5-21	SWITCH, KEYBO	ARD (I◀◀/	<b>⋖⋖</b> /TUN	ING-)
		< FILTER >				S613	1-762-87	5-21	SWITCH, KEYBO	ARD (►►I/I	►►/TUNI	NG+)
						******	******	****	******	******	*****	*****
FL601	1-518-755-11	INDICATOR TUBE	, FLUORES	CENT								
									POWER BOARD,			
		< IC >					A-4476-9	48-A	POWER BOARD,	COMPLETE	(AEP,UK,	AUS)
									******	******		
IC601		IC M66004M8FF										
IC602	8-759-827-69	IC NJL63H400A	-1 ( <b>R</b> )						< CAPACITOR >			
		< TRANSISTOR >				C902	1-126-76			1000uF	20.00%	
						C903	1-126-96			10uF	20.00%	
Q601	8-729-120-28		2SC3052E			C904	1-126-910			1000uF	20.00%	
Q602	8-729-120-28		2SC3052E			C905	1-126-96			10uF	20.00%	
Q604	8-729-120-28	TRANSISTOR	2SC3052E	F-T1-LEF		C906	1-126-920	6-11	ELECT	1000uF	20.00%	10V
		< RESISTOR >				C907	1-126-96		ELECT	10uF	20.00%	
						C908	1-126-93		ELECT	470uF	20.00%	
R601	1-249-441-11	CARBON	100K	5%	1/4W	C909	1-126-96		ELECT	10uF	20.00%	
R602	1-249-441-11	CARBON	100K	5%	1/4W	C910	1-126-910		ELECT	1000uF	20.00%	
R603	1-249-417-11		1K	5%	1/4W	C912	1-126-910	6-11	ELECT	1000uF	20.00%	6.3V
R604	1-249-417-11	CARBON	1K	5%	1/4W							
R607	1-249-441-11	CARBON	100K	5%	1/4W	C914	1-126-93		ELECT	470uF	20.00%	
						C922	1-126-93	3-11	ELECT	100uF	20.00%	16V
R608	1-216-838-11	METAL CHIP	27K	5%	1/16W	C961	1-136-16	5-00	FILM	0.1uF	5.00%	
R609	1-216-821-11	METAL CHIP	1K	5%	1/16W	C962	1-126-94	4-11	ELECT	3300uF	20.00%	25V
R610	1-216-821-11	METAL CHIP	1K	5%	1/16W	C971	1-136-16		FILM	0.1uF	5.00%	50V
R611	1-216-821-11	METAL CHIP	1K	5%	1/16W							
R612	1-216-821-11	METAL CHIP	1K	5%	1/16W	C974	1-126-968	8-11	ELECT	100uF	20.00%	50V
						C975	1-126-96		ELECT	10uF	20.00%	
R614	1-216-813-11	METAL CHIP	220	5%	1/16W	C976	1-126-96		ELECT	10uF	20.00%	
R615	1-216-813-11	METAL CHIP	220	5%	1/16W	C981	1-136-16		FILM	0.1uF	5.00%	50V
R616	1-216-813-11	METAL CHIP	220	5%	1/16W	C982	1-136-16		FILM	0.1uF	5.00%	50V
R617	1-216-813-11	METAL CHIP	220	5%	1/16W		55 100				2.0070	
R618	1-216-809-11	METAL CHIP	100	5%	1/16W	C983	1-135-93	3-11	ELECT	22000uF	20%	16V
11010	0 000 11			J / J	.,	C984	1-128-54		ELECT	4700uF	20.00%	
R619	1-216-813-11	METAL CHIP	220	5%	1/16W	△ C991	1-113-92		CERAMIC	0.01uF	20.00%	
R620	1-216-813-11	METAL CHIP	220	5%	1/16W	C992	1-113-92		ELECT	4.7uF	20.00%	
R621	1-216-813-11	METAL CHIP	220	5%	1/16W	0332	1 120-30	0 11	LLLUI	7.1 UI	20.00/0	30 V
R622	1-216-813-11	METAL CHIP	220	5% 5%	1/16W		г	_		.167		1
R622 R623									components ide			r dotted
NO23	1-216-829-11	METAL CHIP	4.7K	5%	1/16W	I		line	with mark $\triangle$ are	e critical for	r safety.	

Replace only with part number specified.

#### HCD-C5 Ver 1.1 2001.09

POWER	SW	UCOM

Ref. No.	Part No.	<u>Description</u>			<u>Remarks</u>	Ref. No.	Part No.	<u>Description</u>			<u>Remarks</u>
		< CONNECTOR >				<b> ⚠</b> R981	1-219-120-81		0.15	5%	1/4W
						<b> ⚠</b> R982	1-240-877-11		0.15	5%	1/2W
* CN901		CONNECTOR, BO				R991	1-249-429-11		10K	5%	1/4W
CN902	1-778-241-11	CONNECTOR, BO	ARD TO BO	ARD 5P		R992	1-216-833-11		10K	5%	1/16W
CN991		PIN, CONNECTOR				R993	1-249-413-11	CARBON	470	5%	1/4W
* CN992		PIN, CONNECTOR									
* CN995	1-564-511-11	PLUG, CONNECT	OR 8P			R994	1-249-413-11		470	5%	1/4W
						R995	1-216-055-11		1.8K	5%	1/10W
		< DIODE >				R995	1-216-827-11		3.3K	5%	1/16W
						R996	1-247-791-91	CARBON	22	5%	1/4W
D906		DIODE 1SS133T						DEL AV			
D921		DIODE 11ES2-T						< RELAY >			
D961		DIODE 11ES2-T									
D962		DIODE 11ES2-T				<b> ⚠</b> RY991	1-/55-2/6-11	RELAY, POWER			
D963	8-719-200-82	DIODE 11ES2-T	A1B					TD 4 NOTO D1 45	_		
D0C4	0.740.000.00	DIODE 44500 T	A 4 D					< TRANSFORME	K >		
D964 D971		DIODE 11ES2-T				A T001	1 407 040 11	TDANCEODMED	DOWED (C	IID) /AED	THE VITE
						<u></u> 1901		TRANSFORMER,			
D972		DIODE 11ES2-T				<b>△</b> T901		TRANSFORMER, *******			
D973 D974		DIODE 11ES2-T				*******	**********	***********	******	*****	*****
D974	0-7 19-200-02	DIODE TIESZ-II	AID				1-682-099-11	SW BOARD			
D975	8_710_082_24	DIODE MTZJ-T-	77 <b>-</b> 33A				1-002-055-11	******			
D976		DIODE MTZJ-T-						4-4-4-4-4-4-4-4-4-4-4-4-4-4-4-4-4-4-4-4-			
D981		DIODE D3SBA20						< SWITCH >			
D982		DIODE 11ES2-T									
D983		DIODE 11ES2-T				S1	1-786-214-11	SWITCH (DETEC	TION)		
								`		IN/8cm D	isc Detect)
D984	8-719-200-82	DIODE 11ES2-T	A1B			S2	1-786-212-11	SWITCH (DETEC	TION)		,
D985	8-719-200-82	DIODE 11ES2-T	A1B						isc/12cm Di	sc Eject I	End Detect)
D991		DIODE 1SS1337				S3	1-786-213-11	SWITCH (DETEC			
D992		DIODE 1SS133T						(Disc Existe		g, Releas	ing Detect)
D993	8-719-991-33	DIODE 1SS133T	-77			S4	1-786-214-11	SWITCH (DETEC	,	<u>-</u>	
		< BRACKET >				ale ale ale ale ale ale ale ale ale al	to also also also also also also also als	******	•	•	End Detect)
		< DNAUKET >				*******	· · · · · · · · · · · · · · · · · · ·	· · · · · · · · · · · · · · · · · · ·	****	****	****
EB901	4-924-906-21	BRACKET (MT)					Δ-4427-413-Δ	UCOM BOARD, C	OMPLETE (	ALIS HK	KR)
EB902	4-924-906-21	BRACKET (MT)						UCOM BOARD, C		, , ,	1111)
22002	. 02 . 000 2 .	213101121 (1111)						******		,,,,,,	
		< IC >									
						*	4-363-146-00	HEAT SINK, V.OU	IT		
IC901	8-759-231-57	IC TA7810S					7-685-646-79	SCREW +BVTP 3	X8 TYPE2 N	I-S	
IC902	8-759-701-75	IC NJM7805FA									
IC903	8-759-450-49	IC uPC2907HF						< LITHIUM BATT	ERY >		
IC904		IC NJM7805FA									
IC905	8-759-701-75	IC NJM7805FA				BT921	1-528-938-11	BATTERY, LITHIL	JM ION SEC	ONDARY	
10000	0.750.000.70	10 000010417	-					OADAOITOD			
IC906 IC907		IC uPC29L04J-TIC uPC2905HF						< CAPACITOR >			
16907	0-739-047-11	10 UP02905FF				C201	1-126-176-11	ELECT	220uF	20%	10V
		< LINE FILTER >				C201	1-120-170-11		100uF	20.00%	
		CLINE HEILIN				C203	1-164-159-11		0.1uF	20.00 /	50V
<b> △ LF991</b>	1-419-625-11	COIL, LINE FILTE	R			C204	1-104-665-11		100uF	20.00%	
	020	0012, 2.112 1 1212				C206	1-119-941-11		470uF	20.00%	
		< TRANSISTOR >	•								
						C208	1-164-156-11	CERAMIC CHIP	0.1uF		25V
Q971	8-729-141-83	TRANSISTOR	2SB1375			C211	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
Q991	8-729-120-28	TRANSISTOR	2SC1623-	T1-L5L6		C212	1-162-294-31	CERAMIC	0.001uF	10%	50V
						C213	1-162-294-31	CERAMIC	0.001uF	10%	50V
		< RESISTOR >				C216	1-126-786-11	ELECT	47uF	20.00%	6 16V
<b> R</b> 971	1-219-153-11		10	5%	1/4W	C222		CERAMIC CHIP	0.1uF		25V
R972	1-260-103-11		2.2K	5%	1/2W	C223		CERAMIC CHIP	0.1uF	E 655	25V
R973	1-249-429-11		10K	5%	1/4W	C224	1-136-165-00		0.1uF	5.00%	
R974	1-249-413-11		470	5%	1/4W	C225		CERAMIC CHIP	0.1uF	F0/	25V
R975	1-249-413-11	CAKRON	470	5%	1/4W	C226	1-162-927-11	CERAMIC CHIP	100PF	5%	50V

UCOM

Ref. No.	Part No.	Description			Remarks	Ref. No.	Part No.	Description			Remarks
		•						•			
C231		CERAMIC CHIP	100PF	5%	50V	FB213	1-216-864-11	-	0	5%	1/16W
C241	1-127-820-11	-	4.7uF	100/	16V	FB214	1-216-864-11		0	5%	1/16W
C243		CERAMIC CHIP	0.01uF	10%	25V	FB222	1-216-864-11		0	5%	1/16W
C244		CERAMIC CHIP	0.001uF	10%	50V	FB537	1-414-813-21	EMI FERRITE (SN	/ID)		
C294	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V						
								< IC >			
C501	1-126-916-11		1000uF	20.00%							
C502		CERAMIC CHIP	0.1uF		25V	IC212		IC BA8274F-E2			
C503		CERAMIC CHIP	0.01uF	10%	25V	IC221		IC TORX-179			
C504	1-126-160-11	ELECT	1uF	20%	50V	IC222	8-759-548-57	IC SN74LV00AN	ISR		
C505	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	IC501	6-800-396-01	IC uPD703032A	YGF-M01-3	BA	
						IC941	8-759-637-58	IC PST592C-T			
C506	1-164-159-11	CERAMIC	0.1uF		50V						
C507	1-164-156-11	CERAMIC CHIP	0.1uF		25V			< CONDUCTOR >			
C509	1-164-156-11	CERAMIC CHIP	0.1uF		25V						
C510	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	JR200	1-216-864-11	METAL CHIP	0	5%	1/16W
C535	1-162-917-11	CERAMIC CHIP	15PF	5%	50V	JR203	1-216-864-11	METAL CHIP	0	5%	1/16W
						JR205	1-216-864-11	METAL CHIP	0	5%	1/16W
C536	1-162-920-11	CERAMIC CHIP	27PF	5%	50V	JR208	1-216-864-11	METAL CHIP	0	5%	1/16W
C911	1-164-159-11	CERAMIC	0.1uF		50V	JR209	1-216-864-11	METAL CHIP	0	5%	1/16W
C941	1-126-964-11	ELECT	10uF	20.00%	50V						
C942	1-164-156-11	CERAMIC CHIP	0.1uF		25V	JR210	1-216-864-11	METAL CHIP	0	5%	1/16W
C943		CERAMIC CHIP	0.1uF		25V	JR212	1-216-864-11		0	5%	1/16W
						JR213	1-216-864-11		0	5%	1/16W
		< CONNECTOR >				JR214	1-216-864-11		0	5%	1/16W
		(0020.0)				JR215	1-216-864-11		0	5%	1/16W
* CN201	1-784-738-11	CONNECTOR, FFO	C 16P			011210	1 210 001 11	WEINE OIM	· ·	0 70	1, 1011
CN202		CONNECTOR, FFO				JR216	1-216-864-11	METAL CHIP	0	5%	1/16W
CN203		SOCKET, CONNEC		7IF\10P		JR217	1-216-864-11		0	5%	1/16W
CN204		CONNECTOR, FFO	`	211 ) 1 0 1		JR219	1-216-864-11	-	0	5%	1/16W
CN205		CONNECTOR, BO		ΔRD 15P		JR225	1-216-864-11		0	5%	1/16W
014200	1 700 330 11	OOMNEOTOTI, DO	AIID IO DO	AILD IOI		JR226	1-216-864-11		0	5%	1/16W
* CN206	1_77/1_813_11	CONNECTOR, BO	ARD TO BO	ARD 7P		311220	1-210-004-11	WILTAL OTTI	U	J /0	1/ 10VV
CN207		CONNECTOR, RO				JR227	1-216-864-11	METAL CHIP	0	5%	1/16W
CN208		CONNECTOR (DI		O1		011227	1 210 004 11	WEIAL OIIII	U	<b>3</b> /0	17 1000
CN200		CONNECTOR (DI						< CONDUCTOR >			
CN209		PIN, CONNECTOR	,					< GOINDOGTOIN >			
GIVZIZ	1-300-403-11	riiv, GOIVIVLGTOI	1 41			L551	1-216-864-11	METAL CHID	0	5%	1/16W
		< DIODE >				L552	1-216-864-11		0	5%	1/16W
		< DIODL >				L332	1-210-004-11	WILTAL OTHE	U	J /0	1/1000
D214	8_710_088_61	DIODE 1SS3557	ΓF-17					< TRANSISTOR >			
D214 D221		DIODE 1883551						< ITIANUIUTUTE /			
D222		DIODE 1883551				Q202	8_720_424_08	TRANSISTOR	IIN/2111_T	Y	
D232		DIODE 1883551				Q211	8-729-025-28		2SK1828T		
D513		DIODE 1883551				Q212		TRANSISTOR	2SK10201		
D313	0-7 19-900-01	DIODE 1999991	IL-11			Q212		TRANSISTOR	2SC1623-		
D910	0 710 001 40	DIODE MTZJ-T-	77 / 7D			Q222	8-729-120-28		2SC1623-		
D910 D923		DIODE 1881331				Q222	0-729-120-20	INANSISTUN	2301023-	I I-LULO	
						0223	9_720_120_28	TDANGISTOD	2SC1623-	T1_I5I6	
D924 D925		DIODE 1SS1337 DIODE 1SS3557				Q223 Q224	8-729-120-28	TRANSISTOR	2SC1623-		
		DIODE 1883551						TRANSISTOR			
D926	0-7 19-900-01	חוטטב ופפפפו	I E - I /			Q232		TRANSISTOR	2SC1623- UN2211-T		
D927	0.710.000.01	DIODE 1SS3551	FF 47			Q911			RT1P137L		
						Q912	8-729-040-20	INANSISTUR	NI IPIO/L	IP	
D941		DIODE 188355T				0041	8-729-120-28	TDANGICTOD	0001600	T1   E  C	
D942		DIODE 1883557				Q941	8-729-120-28	TRANSISTUR	2SC1623-	I I-LOLO	
D943	8-719-988-01	DIODE 1SS355T	IE-1/					DECICEOD			
		, TEDMINIAL .						< RESISTOR >			
		< TERMINAL >				D010	1-249-429-11	CADRON	101/	50/	1/4W
EDT404	1 507 770 04	TEDMINIAL DOAD	טר פטטוויים	1		R212			10K	5% 5%	
EP1101	1-53/-//0-21	TERMINAL BOAR	เม, นหบบNL	J		R213	1-216-833-11		10K	5%	1/16W
		. CONDUCTOR (	COIL			R214	1-216-825-11		2.2K	5%	1/16W
		< CONDUCTOR /	UUIL >			R215	1-216-825-11		2.2K	5%	1/16W
ED004	1 010 001 11	METAL OUTD	٥	E0/	4/4004	R217	1-216-833-11	WIETAL CHIP	10K	5%	1/16W
FB201	1-216-864-11		0	5%	1/16W	D010	1 016 045 44	METAL CLUD	1001/	E 0/	1/16/1/
FB202	1-216-864-11		0	5%	1/16W	R218	1-216-845-11		100K	5%	1/16W
FB205	1-216-864-11		0 0⊔	5%	1/16W	R219	1-249-417-11		1K	5% 5%	1/4W
FB211	1-412-473-21		0uH	E0/	1/10/1/	R221	1-249-413-11		470	5%	1/4W
FB212	1-216-864-11	WIETAL CHIP	0	5%	1/16W	R222	1-216-809-11		100	5%	1/16W
						R224	1-216-853-11	WIETAL UHIP	470K	5%	1/16W

#### HCD-C5 Ver 1.1 2001.09

## UCOM

Ref. No.	Part No.	Description			Remarks	Ref. No.	Part No.	Description			Remarks
R225	1-216-841-11	METAL CHIP	47K	5%	1/16W	R560	1-249-417-	<del></del>	1K	5%	1/4W
R226	1-216-853-11	METAL CHIP	470K	5%	1/16W	R561	1-249-417-		1K	5%	1/4W
R227	1-216-841-11	METAL CHIP	47K	5%	1/16W	R562	1-216-809-		100	5%	1/16W
R228	1-216-841-11	METAL CHIP	47K	5%	1/16W	R563	1-216-809-		100	5%	1/16W
R236	1-249-429-11	CARBON	10K	5%	1/4W	R564	1-216-809-	11 METAL CHIP	100	5%	1/16W
D040	1 047 007 01	CARRON	100	F0/	4 /4\M	DECE	1 010 005	44 METAL OLUD	451/	F0/	4/4/01/1
R242	1-247-807-31	CARBON	100	5%	1/4W	R565	1-216-835-		15K	5%	1/16W
R243 R244	1-216-821-11 1-216-845-11	METAL CHIP METAL CHIP	1K 100K	5% 5%	1/16W 1/16W	R566 R567	1-216-835- 1-249-429-		15K 10K	5% 5%	1/16W 1/4W
R245	1-216-845-11	METAL CHIP	100K 100K	5% 5%	1/16W	R568	1-249-429-		15K	5%	1/4 VV 1/16W
R292	1-247-807-31	CARBON	100k	5% 5%	1/10VV 1/4W	R569	1-216-809-		100	5% 5%	1/16W
11232	1-247-007-01	OANDON	100	<b>J</b> /0	1/400	11303	1-210-003	TI WEIAL OIII	100	J /0	1/1000
R501	1-247-807-31	CARBON	100	5%	1/4W	R570	1-216-809-	11 METAL CHIP	100	5%	1/16W
R502	1-247-807-31	CARBON	100	5%	1/4W	R572	1-216-823-	11 METAL CHIP	1.5K	5%	1/16W
R503	1-216-825-11	METAL CHIP	2.2K	5%	1/16W	R577	1-216-821-		1K	5%	1/16W
R504	1-247-807-31	CARBON	100	5%	1/4W	R578	1-216-821-		1K	5%	1/16W
R505	1-216-825-11	METAL CHIP	2.2K	5%	1/16W	R579	1-216-821-	11 METAL CHIP	1K	5%	1/16W
R506	1-247-807-31	CARBON	100	5%	1/4W	R580	1-216-833-	11 METAL CHIP	10K	5%	1/16W
R507	1-247-807-31	CARBON	100	5%	1/4W	R581	1-216-833-		10K	5%	1/16W
R508	1-216-809-11	METAL CHIP	100	5%	1/4W 1/16W	R583	1-216-833-		10K	5%	1/16W
R509	1-216-833-11	METAL CHIP	10K	5%	1/16W	R584	1-216-833-		10K	5%	1/16W
R510	1-216-833-11	METAL CHIP	10K	5%	1/16W	11001	1 210 000	TT WEINE OTH	1010	0 70	(AEP,UK)
11010	1 210 000 11	WEINE OIIII	1010	0 70	1/1011	R585	1-216-833-	11 METAL CHIP	10K	5%	1/16W
R511	1-247-807-31	CARBON	100	5%	1/4W						
R512	1-247-887-00	CARBON	220K	5%	1/4W	R586	1-216-833-	11 METAL CHIP	10K	5%	1/16W
R513	1-247-807-31	CARBON	100	5%	1/4W	R587	1-216-833-	11 METAL CHIP	10K	5%	1/16W
R514	1-247-807-31	CARBON	100	5%	1/4W	R588	1-216-833-		10K	5%	1/16W
R515	1-247-807-31	CARBON	100	5%	1/4W	R590	1-249-417-		1K	5%	1/4W
						R591	1-249-437-	11 CARBON	47K	5%	1/4W
R516	1-216-837-11	METAL CHIP	22K	5%	1/16W	5500	4 040 004	44 145741 01115	417	<b>5</b> 0/	4 /4 00 14
R517	1-247-807-31	CARBON	100	5%	1/4W	R592	1-216-821-		1K	5%	1/16W
R518	1-247-807-31	CARBON	100	5%	1/4W	R593	1-216-833-		10K	5%	1/16W
R519	1-247-887-00	CARBON	220K	5%	1/4W	R594	1-216-821-		1K	5%	1/16W
R520	1-249-421-11	CARBON	2.2K	5%	1/4W	R595 R596	1-249-417-	11 CARBON 11 METAL CHIP	1K 1K	5% 5%	1/4W 1/16W
R521	1-216-833-11	METAL CHIP	10K	5%	1/16W	H090	1-210-021-	TI WEIAL UNIP	IN	370	1/1000
R522	1-216-833-11	METAL CHIP	10K	5%	1/16W	R597	1-216-809-	11 METAL CHIP	100	5%	1/16W
R523	1-216-833-11	METAL CHIP	10K	5%	1/16W	R910	1-260-103-		2.2K	5%	1/2W
R524	1-216-809-11	METAL CHIP	100	5%	1/16W	R911	1-216-864-		0	5%	1/16W
R525	1-216-833-11	METAL CHIP	10K	5%	1/16W	R921	1-216-813-		220	5%	1/16W
						R941	1-216-817-	11 METAL CHIP	470	5%	1/16W
R526	1-247-807-31	-	100	5%	1/4W						
R527	1-247-807-31	CARBON	100	5%	1/4W	R942	1-216-833-		10K	5%	1/16W
R528	1-249-429-11	CARBON	10K	5%	1/4W	R943		11 METAL CHIP	47K	5%	1/16W
R529	1-247-807-31	CARBON	100	5%	1/4W	R946	1-216-837-		22K	5%	1/16W
R530	1-249-417-11	CARBON	1K	5%	1/4W	R947	1-216-841-	11 METAL CHIP	47K	5%	1/16W
R531	1-249-417-11	CARBON	1K	5%	1/4W			< VIBRATOR >			
R532	1-249-417-11	CARBON	1K	5%	1/4W			< VIDITATOR >			
R533	1-249-417-11	CARBON	1K	5%	1/4W	X501	1-760-014-	31 VIBRATOR, CERA	AMIC 20MF	łz	
R535	1-249-429-11	CARBON	10K	5%	1/4W	X502		41 VIBRATOR, CRY			
R536	1-216-851-11	METAL CHIP	330K	5%	1/16W	******	******	******	*****	******	*****
B====	101010	0400000	10	<b>F</b> 0'					•		
R538	1-249-429-11	CARBON	10K	5%	1/4W			MISCELLANEOU			
R543	1-216-809-11	METAL CHIP	100	5%	1/16W		4 757 704	********		·=`	
R544	1-216-809-11	METAL CHIP	100	5%	1/16W	1		11 WIRE (FLAT TYP	, ,	,	
R545	1-216-821-11	METAL CHIP	1K	5%	1/16W	6		11 WIRE (FLAT TYP	, ,	iE)	
R546	1-216-809-11	METAL CHIP	100	5%	1/16W	<u></u> 104 <u></u> 104		·11 CORD, POWER ( ·21 CORD, POWER (	,		
R547	1-216-809-11	METAL CHIP	100	5%	1/16W	<u></u>		21 CORD, POWER (	,	)	
R548	1-216-809-11	METAL CHIP	100	5%	1/16W				,	,	
R549	1-216-809-11	METAL CHIP	100	5%	1/16W	105	1-769-943-	11 WIRE (FLAT TYP	E) (11COR	E) (AUS.H	K,KR)
R550	1-216-809-11	METAL CHIP	100	5%	1/16W	105		11 WIRE (FLAT TYP			
R551	1-249-429-11	CARBON	10K	5%	1/4W	106		11 TUNER PACK (FI	, ,	, ,	,
						106		11 TUNER PACK (FI	, ,	,	
R554	1-216-809-11	METAL CHIP	100	5%	1/16W	106		11 TUNER PACK (FI	, ,	. ,	
R556	1-249-421-11	CARBON	2.2K	5%	1/4W						
R557	1-216-833-11	METAL CHIP	10K	5%	1/16W		Γ-	The components ide	entified by	mark 🛆 o	or dotted
R558	1-216-833-11	METAL CHIP	10K	5%	1/16W			ine with mark 🛆 are			
R559	1-216-833-11	METAL CHIP	10K	5%	1/16W	I		Replace only with p	art numbe	r specifie	ed.
							_				

Ref. No.	Part No.	<u>Description</u>	<u>Remarks</u>	Ref. No.	Part No.	Description	<u>Remarks</u>
108	1-773-110-11	WIRE (FLAT TYPE) (19 CORE)				******	
154		WIRE (FLAT TYPE) (19 CORE)				HARDWARE LIST	
156		WIRE (FLAT TYPE) (17 CORE)				******	
157	1-757-080-11	WIRE (FLAT TYPE) (27 CORE)		#1	7-685-870-01	SCREW +BVTT 3X5 (S)	
408		PICK-UP FLEXIBLE BOARD		#2		SCREW +KTP 3X6 TYPE2 NON-SLIT	
400	1 002 101 11	TION OF TELABLE BOARD		#3		SCREW +BVTT 2X5 (S)	
<b></b> 503	1_758_631_11	OPTICAL PICK-UP (OPTIMA-720L1E)		#4		SCREW +BVTT 2.6X5 (S)	
759		FLEXIBLE BOARD		#5		SCREW +BVTP 3X12 TYPE2 N-S	
1759 1∆760		OPTICAL PICK-UP (KMS-260B)		π3	7-003-040-73	JUNEW +DVIF JAIZ IIFEZ N-3	
HR901		HEAD, OVER WRITE		#6	7-682-565-00	SCREW +B 4X16	
M701		MOTOR ASSY. SPINDLE		#0 #7		SCREW +BVTP 3X8 TYPE2 N-S	
IVI7 U I	A-4012-090-A	WOTON ASST, SPINDLE		#1	7-684-024-04		
M702	A 4725 076 A	MOTOR ASSY, SLED		#9		SCREW +P 2X6 TYPE2 NON-SLIT	
M703		MOTOR ASSY, SLED		#9 #10		SCREW +BTP 2X6 TYPE2 N-S	
M901	1-698-997-11	*		#10	7-000-004-19	SUNEW +DIP ZAO ITPEZ N-S	
M902		MOTOR ASSY, LOADING		#11	7 605 101 11	SCREW +P 2X3 NON-SLIT TYPE2	
M903		MOTOR ASSY, ECADING		#11		SCREW +P 2X5 TYPE2 NON-SLIT	
Mana	A-4904-020-1	WOTON ASST, FEED		#12 #13		SCREW, PRECISION +P 2X3	
M904	V 4054 001 1	MOTOR ACCV CRINDLE		#13 #14		SCREW, PRECISION +P 2X2.5	
		MOTOR ASSY, SPINDLE		#14 #15			
S1	1-/80-214-11	SWITCH (DETECTION)	o dotoot\	#15	7-027-003-17	PRECISION SCREW +P 2X2 TYPE 3	
CO	1 700 010 11	(Disc IN/8cm Disc	sc detect)	#1 C	7 007 550 70	CODEM DECICION - D 0V10	
S2	1-786-213-11	SWITCH (DETECTION)		#16		SCREW, PRECISION +P 2X10	
00	1 700 010 11	(12cm Disc/12cm Disc Eject Er	ia aetect)	#17 "10		SCREW, PRECISION +P 2X6 TYPE3	
S3	1-786-213-11	SWITCH (DETECTION)		#18		SCREW, PRECISION +P 1.7X6	
0.4	. 700 014 14	(Disc Existence, Chucking, Releasing)	,	#19		SCREW, PRECISION +P 1.7X2.2	
S4	1-/86-214-11	SWITCH (DETECTION) (8cm Disc Eject	detect)	#20	7-627-551-18	SCREW, PRECISION +P 1.4X2	
S5	1-786-212-11	SWITCH (DETECTION) (LIMIT IN)		#21	7-685-850-04	SCREW +BVTT 2X3 (S)	
S102	1-771-957-11	SWITCH, PUSH (2 KEY) (REFLECT→PF	ROTECT)	#22		SCREW +KTP 2X6 TYPE2 NON-SLIT	
<b> № Т900</b>	1-437-239-11	TRANSFORMER, POWER (AEP,UK,AUS					
<b> ∆</b> T900	1-437-241-11	TRANSFORMER, POWER (HK,KR)	,				
******	********	**********	*****				

## **REVISION HISTORY**

Clicking the version allows you to jump to the revised page.

Also, clicking the version at the upper right on the revised page allows you to jump to the next revised page.

Ver.	Date	Description of Revision
1.1	2001.09	Addition of Australian, Hong Kong and Korean models.
1.0	2001.07	New